Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KCLASO V10

KCLASO Lightweight Vacuum User Manual

Model: V10

Introduction

Thank you for choosing the KCLASO Lightweight Vacuum. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new vacuum cleaner. Please read it thoroughly before first use and retain it for future reference.

Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not handle plug or vacuum with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without dust cup and/or filters in place.
- This appliance includes Lithium-ion batteries. Do not incinerate batteries or expose to high temperatures, as they may explode.

Package Contents

Please check the package contents to ensure all parts are present:

- Main Vacuum Unit (with dust cup and filter)

- Extension Wand
- Motorized Floor Brush
- Crevice Tool
- 2-in-1 Brush Tool
- Power Adapter/Charger
- Wall Mount Bracket (optional, if included)
- User Manual (this document)

Setup and Assembly

Follow these steps to assemble your KCLASO Lightweight Vacuum:

1. **Attach the Extension Wand:** Insert the top end of the extension wand into the main vacuum unit until it clicks securely into place.
2. **Attach the Floor Brush:** Insert the bottom end of the extension wand into the motorized floor brush until it clicks securely into place.
3. **Alternative Attachments:** For handheld use, you can directly attach the crevice tool or the 2-in-1 brush tool to the main vacuum unit.



Figure 1: Various assembly configurations of the KCLASO Lightweight Vacuum, demonstrating its versatility from a full-size stick vacuum to a compact handheld unit with different attachments.

Operating Instructions

Charging the Battery

Before first use, fully charge the vacuum for approximately 4-5 hours. Connect the power adapter to the charging port on the main vacuum unit and plug it into a wall outlet. The indicator lights will show charging status.

Powering On/Off and Suction Modes

Press the power button to turn the vacuum on. The vacuum typically starts in standard suction mode. Press the mode button to switch between the two available power levels (standard and max suction) for different cleaning needs.

Using Attachments

- **Motorized Floor Brush:** Ideal for hard floors and low-pile carpets. The integrated LED lights illuminate the cleaning path.
- **Crevice Tool:** Perfect for narrow gaps, corners, and edges.
- **2-in-1 Brush Tool:** Use the brush bristles for delicate surfaces like upholstery or curtains, and retract the bristles for a wider suction nozzle for general dusting.

Maintenance

Regular maintenance ensures optimal performance and extends the life of your vacuum.

Emptying the Dust Cup

Press the dust cup release button to detach the dust cup from the main unit. Hold it over a trash bin and press the bottom release latch to empty the contents. Close the latch securely after emptying.

Cleaning the Filter

The foam filter should be cleaned regularly, ideally after every few uses or when suction power decreases. Remove the filter from the dust cup. Tap off loose dirt. Rinse the filter under cool running water until the water runs clear. Allow the filter to air dry completely for at least 24 hours before reinserting it into the vacuum. Do not use the vacuum with a wet filter.

Cleaning the Brush Roll

Periodically check the brush roll for tangled hair or debris. To remove the brush roll, locate the release tab on the side of the floor brush head, unlock it, and pull out the brush roll. Use scissors to cut away any tangled hair or threads. Reinsert the brush roll and secure the tab.

Troubleshooting

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is not charged.	Charge the battery fully.
Low suction power.	Dust cup is full; Filter is clogged; Obstruction in nozzle/hose/brush roll.	Empty dust cup; Clean or replace filter; Remove any obstructions.
Brush roll not spinning.	Brush roll is jammed by debris; Brush roll is not properly installed.	Clean brush roll; Ensure brush roll is securely installed.
Battery indicator lights flashing.	Battery low or charging error.	Recharge the battery. If issue persists, contact customer support.

Specifications

Feature	Detail
Brand	KCLASO
Model Name	V10
Special Feature	Cordless

Feature	Detail
Filter Type	Foam
Included Components	Battery
Capacity	3.3 Pounds (Dust Cup)
Recommended Uses	Hard Floor
Form Factor	Stick
Color	Orange
Product Dimensions	15"L x 12"W x 7"H
Item Weight	7.5 pounds
Number of Power Levels	2
Indoor/Outdoor Usage	Indoor
Batteries	6 Lithium Ion batteries (included)
UPC	788046612899

Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or visit the official KCLASO website. You may also contact KCLASO customer service directly for assistance with product issues or inquiries.

KCLASO Store: Visit the KCLASO Store on Amazon

© 2024 KCLASO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DLP77MK2

More documents and user manuals: **https://manuals.plus/**