Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok RM-RC49141-HT015

Azwok RC49141 Remote Control Instruction Manual

Replacement Remote Control for Hitachi Smart TV Models

1. Introduction

This manual provides instructions for the Azwok RC49141 replacement remote control, designed for various Hitachi Smart TV models. This remote control offers the primary functions of the original remote without requiring complex programming.

2. Product Overview

The Azwok RC49141 is a direct replacement remote control. It is ready for use upon battery installation and is compatible with a wide range of Hitachi Smart TV models.





Figure 1: Azwok RC49141 Remote Control. This image displays the full layout of the remote control, including all buttons for power, channel, volume, navigation, and specific app access like Netflix.

3. Setup

3.1 Battery Installation

The remote control requires batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open the compartment.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Once batteries are installed, the remote control is ready for immediate use with compatible Hitachi Smart TVs. No programming is required.

4. Operating Instructions

This section details the functions of the buttons on your Azwok RC49141 remote control.

4.1 Button Functions

- **Power Button ( ):** Turns the TV on or off.
- **Netflix Button:** Direct access to the Netflix application.
- **Number Buttons (0-9):** Select channels directly or input numbers.
- **TV Button:** Switches to TV input mode.
- **Volume Up/Down (V+/V-):** Adjusts the sound volume.
- **Mute Button:** Mutes or unmutes the TV sound.
- **Channel Up/Down (P+/P-):** Changes channels sequentially.
- **Menu Button:** Opens the main TV menu.
- **Q.MENU Button:** Accesses quick menu options.
- **Navigation Buttons (Up, Down, Left, Right):** Navigates through menus and options.
- **OK Button:** Confirms selections.
- **Back Button:** Returns to the previous screen or menu.
- **Exit Button:** Exits the current menu or application.
- **Info Button (i):** Displays information about the current program or input.
- **Colored Buttons (Red, Green, Yellow, Blue):** Functionality varies depending on the TV model and current application.
- **Language (LANG.) Button:** Changes audio language or subtitle language.
- **Subtitle (SUBT.) Button:** Toggles subtitles on or off.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward, Record):** Controls media playback.

5. Compatible Models

This remote control is compatible with the following Hitachi Smart TV models:

- 32HB4T41, 43HB6T62, 43HB6T62H, 43HB6W62I, 32HB1W66I, 32HB5W66, 43HL15W64, 32HB6T61A, 32HB4W65I, 32HB4T62, 40HB1W66I, 32HB4T62A, 32HB4T61, 32HB4T61H, 32HB4T62H, 32HB6T41A, 43HB5T62, 32HB4T61-Z, 43HK4W64, 43HK5W64, 43HL15W69, 43HL5W69, 48HB6W62A, 49HB5W62, 49HB6W62H, 49HK4W64, 49HK5W64, 49HK5W64A, 49HK5W64H, 49HL15W69, 49HL5W69, 55HB6W62A, 55HGW69K, 55HK4W64, 55HK5W64, 55HK5W64A, 55HK5W64H, 55HL15W69, 65HL15W64, 65HL15W64A, 65HZ6W69A, 55HL5W69

Note: If your specific model number is not listed, or if your original remote control differs significantly in appearance, please contact customer support for compatibility verification.

6. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Avoid using liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote control's response becomes inconsistent or stops working. Always replace both batteries at the same time with new ones of the same type.

- **Storage:** Store the remote control in a dry place, away from direct sunlight and extreme temperatures.

7. Troubleshooting

Problem	Possible Cause	Solution
Remote control does not work.	• Batteries are dead or inserted incorrectly. • Obstruction between remote and TV. • Remote control is too far from the TV.	• Replace batteries with new ones, ensuring correct polarity. • Remove any objects blocking the line of sight to the TV's infrared receiver. • Move closer to the TV.
Some buttons do not respond.	• Specific button malfunction. • TV model incompatibility for certain advanced functions.	• Ensure the remote is pointed directly at the TV. • Verify your TV model is fully compatible with all remote functions. Contact support if issues persist.

8. Specifications

- **Model:** RM-RC49141-HT015
- **Compatible Devices:** Hitachi Smart Televisions
- **Power Source:** 2 x AAA Batteries (not included)
- **Special Features:** No Programming Required
- **Connectivity:** Infrared

9. Warranty and Support

This remote control comes with a 12-month replacement warranty. If the product is found to be defective or incompatible with your device within this period, returns are accepted for refund or exchange.
For further assistance, compatibility inquiries, or troubleshooting not covered in this manual, please contact Azwok customer support.

© 2024 Azwok. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DLV916B2

More documents and user manuals: **https://manuals.plus/**