Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok YAP1FB

Azwok YAP1FB Remote Control Replacement for Gree Air Conditioner User Manual

1. Introduction

This document provides comprehensive instructions for the Azwok YAP1FB Remote Control, designed as a direct replacement for specific Gree Air Conditioner models. It outlines the setup, operation, maintenance, and troubleshooting procedures to ensure proper functionality.





Image 1: Front view of the Azwok YAP1FB Remote Control. The remote is white with a digital display at the top showing '25°C' and '12:00'. Below the display are various control buttons, including ON/OFF, MODE, TURBO, FAN, and other function buttons.

2. Setup

2.1 Battery Installation

The Azwok YAP1FB Remote Control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

No programming is required. The remote control is ready for use once batteries are installed.

3. Operating Instructions

This section details the functions of each button on the Azwok YAP1FB Remote Control.

- **ON/OFF Button:** Powers the air conditioner unit on or off.
- **Temperature Adjustment Buttons (Δ / ∇):** Increases or decreases the set temperature. These buttons may also be used for navigation in menu settings.
- **MODE Button:** Cycles through the available operating modes: Auto, Cool, Dry, Fan, and Heat (if supported by your AC unit).
- **TURBO Button:** Activates the Turbo function for rapid cooling or heating, quickly reaching the desired temperature.
- **FAN Button:** Adjusts the fan speed. Options typically include Auto, Low, Medium, and High.
- **Swing/Louver Button (Icon with horizontal lines):** Controls the vertical swing of the air conditioner's louver, directing airflow up and down.
- **I FEEL Button:** Activates the 'I Feel' function, where the remote control's built-in sensor measures the ambient temperature and sends the data to the air conditioner for more precise temperature control around the remote.
- **T-ON / T-OFF Buttons:** Used to set the timer for the air conditioner to automatically turn on (T-ON) or turn off (T-OFF) at a specified time.
- **Airflow Direction Button (Icon with vertical lines):** Controls the horizontal swing of the air conditioner's louver, directing airflow left and right.
- **TEMP Button:** Toggles the temperature display between Celsius and Fahrenheit, or displays the set temperature.
- **CLOCK Button:** Used to set the current time on the remote control's display.
- **LIGHT Button:** Controls the display light on the air conditioner unit.
- **X-FAN Button:** Activates the X-Fan (or Anti-mildew) function, which keeps the indoor fan running for a short period after the unit is turned off to dry the evaporator and prevent mold growth.
- **SLEEP Button:** Activates Sleep mode, which adjusts temperature and fan speed automatically over time to maintain comfort during sleep and save energy.

4. Maintenance

4.1 Cleaning the Remote Control

To maintain the remote control's appearance and functionality:

- Wipe the surface with a soft, dry cloth.
- Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote.

4.2 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or the display fades. Always replace both batteries simultaneously with new ones of the same type.

5. Troubleshooting

5.1 Remote Control Not Responding

- **Check Batteries:** Ensure batteries are correctly installed with the correct polarity and are not depleted. Replace if necessary.
- **Line of Sight:** Ensure there is a clear line of sight between the remote control and the air conditioner's

receiver. Obstructions can block the infrared signal.

- **Distance:** Operate the remote within the recommended range of the air conditioner.
- **Interference:** Strong light sources, such as direct sunlight or fluorescent lamps, can interfere with the infrared signal.

6. Specifications

Feature	Detail
Brand	Azwok
Model Number	RM-YAP1FB-GR007 (Compatible with YAP1FB)
Compatible Devices	Gree Air Conditioners (YAP1FB models)
Connectivity Technology	Infrared
Special Feature	No Programming Required
Power Source	2 x AAA Batteries (not included)
Item Weight	2.72 ounces
Package Dimensions	6.26 x 1.96 x 0.78 inches

7. Warranty and Support

7.1 Warranty Information

This Azwok remote control comes with a 12-month replacement warranty. If the product is found to be defective or does not function as expected with your compatible device within this period, please contact the seller for assistance.

7.2 Customer Support

For further assistance, troubleshooting, or to confirm compatibility with your specific air conditioner model, please contact the seller or manufacturer. Providing your air conditioner's model number will help expedite support.

© 2024 Azwok. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DLV9742R

More documents and user manuals: **https://manuals.plus/**