Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LIVIVOX Z06

LIVIVOX Walking Pad with Incline User Manual

MODEL: Z06

Your guide to a healthier, more active lifestyle.

Introduction

Thank you for choosing the LIVIVOX Walking Pad with Incline. This compact and versatile treadmill is designed to integrate seamlessly into your home or office, promoting an active lifestyle. With its innovative 5% fixed incline, powerful 3HP motor, and smart app connectivity, it offers an effective and convenient way to achieve your fitness goals. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new walking pad.



Figure 1: LIVIVOX Walking Pad with Incline in both under-desk and open-space usage scenarios.

Setup

The LIVIVOX Walking Pad is designed for minimal assembly. Please follow these steps for initial setup:

1. **Unpacking:** Carefully remove the walking pad and all components from the packaging. Verify that all included components are present: the walking pad unit, remote control, power cord, and a bottle of lubricant.
2. **Placement:** Choose a flat, stable surface for the walking pad. Ensure there is adequate clearance around the unit for safe operation. Its compact design allows it to be placed under beds (requires 6.77" clearance) or vertically against walls for storage.
3. **Power Connection:** Connect the power cord to the walking pad's power input port and then plug it into a standard electrical outlet.

4. **Initial Lubrication:** Before first use, apply a small amount of the provided lubricant to the running belt as instructed in the Maintenance section to ensure smooth operation and longevity.



Figure 2: The walking pad features built-in wheels for easy movement and storage.

Operating Instructions

Familiarize yourself with the controls and features for optimal use:

- **Power On/Off:** Press the power button on the walking pad or the remote control to turn the unit on or off.
- **Remote Control:** The included remote control allows you to adjust speed, start/stop the belt, and switch modes without bending down.
- **LED Display:** The integrated LED display shows key metrics including speed, distance, time, and calories burned.
- **Speed Adjustment:** The walking pad offers a speed range of 0.5 to 4.0 MPH. Use the '+' and '-' buttons on the remote to increase or decrease the speed.
- **Incline Feature:** This model features a patented 5% fixed incline, designed to enhance your workout by engaging more

muscle groups and increasing calorie burn compared to flat walking pads.

- **Smart App Connectivity:** Download the

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DM14QLZZ

More documents and user manuals: **https://manuals.plus/**