Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Techwood TAN-8005R

Techwood TAN-8005R Rechargeable Spot Cleaner User Manual

Model: TAN-8005R

Introduction
Safety Instructions
Package Contents
Setup
Operation
Maintenance
Troubleshooting
Specifications
Warranty & Support

1. Introduction

The Techwood TAN-8005R is a cordless, rechargeable spot cleaner designed for effective removal of everyday stains from various surfaces. Its portable design and dual-tank system make it ideal for cleaning carpets, upholstery, vehicle interiors, and stairs. This manual provides essential information for the safe and efficient use of your new appliance.

2. Important Safety Instructions

Please read all instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is switched off and unplugged before cleaning or performing maintenance.
- This appliance is for household use only. Do not use outdoors or for commercial purposes.
- Do not immerse the appliance, charging adapter, or cord in water or other liquids.
- Keep the appliance out of reach of children and pets.
- Use only the charging adapter supplied with the appliance.
- Do not use the appliance if the power cord or plug is damaged.
- Use only recommended cleaning solutions suitable for spot cleaners. Do not use flammable or abrasive

liquids.

- Do not block ventilation openings.
- Exercise caution when cleaning stairs.

3. Package Contents

Carefully unpack your Techwood TAN-8005R and ensure all items are present:

- Techwood TAN-8005R Spot Cleaner Unit
- 2-in-1 Suction Nozzle (with brush)
- Crevice Nozzle
- Charging Adapter



Image 1: The Techwood TAN-8005R spot cleaner shown with its main unit, flexible hose, 2-in-1 suction nozzle, crevice nozzle, and charging adapter.

4. Setup

4.1 Charging the Appliance

Before first use, or if the battery is low, fully charge the appliance:

1. Connect the charging adapter to the charging port on the cleaner.

2. Plug the adapter into a suitable power outlet.
3. The charging indicator light will illuminate, indicating that the unit is charging.
4. A full charge takes approximately 4-5 hours. Disconnect the charger once fully charged.

4.2 Filling the Clean Water Tank

The cleaner has two separate tanks: one for clean water/solution and one for dirty water.

1. Locate the clean water tank (1.5 L capacity), typically marked with a 'MAX' fill line.
2. Open the tank cap.
3. Fill the tank with clean water. For enhanced cleaning, add a suitable, low-foaming cleaning solution according to the solution manufacturer's instructions. Do not overfill.
4. Securely close the tank cap.

4.3 Attaching Accessories

Select the appropriate nozzle for your cleaning task:

- **2-in-1 Suction Nozzle:** Ideal for larger areas like carpets, upholstery, and general spot cleaning.
- **Crevice Nozzle:** Best for tight spaces, corners, and edges.

To attach a nozzle, align it with the end of the flexible hose and push firmly until it clicks into place.

5. Operating Instructions

5.1 Powering On/Off

Press the power button located on the handle to turn the cleaner ON. Press it again to turn the cleaner OFF.

5.2 Speed Selection

The appliance offers two adjustable speeds to suit different cleaning needs. Press the speed selection button (usually next to the power button) to toggle between the two modes. Use a lower speed for delicate surfaces or light stains, and a higher speed for tougher stains or more durable materials.

5.3 Cleaning Process

1. Position the selected nozzle directly over the stained area.
2. Press the spray trigger on the nozzle to dispense the clean water and cleaning solution onto the stain.
3. Move the nozzle slowly over the stain, applying gentle pressure, to scrub the area and extract the dirty water. The 2-in-1 nozzle features a brush for effective scrubbing.
4. Continue to spray and extract until the stain is removed and the extracted water appears clean.
5. For best results, work in small sections and overlap your passes.



Image 2: The Techwood TAN-8005R cleaner being used on a carpet, demonstrating its effectiveness in removing stains.

5.4 Multi-Surface Cleaning

The Techwood TAN-8005R is versatile and suitable for various surfaces:

- **Carpets and Rugs:** Ideal for spot cleaning spills and pet accidents.
- **Upholstery:** Refresh sofas, chairs, and cushions.
- **Vehicle Interiors:** Clean car seats, floor mats, and other fabric surfaces.
- **Stairs:** The compact design and flexible hose make it easy to clean carpeted stairs.



Image 3: A collage illustrating the multi-surface capabilities of the cleaner, including cushions, stairs, curtains, and vehicle interiors.

6. Maintenance

Regular maintenance ensures optimal performance and extends the life of your cleaner.

6.1 Emptying and Cleaning the Dirty Water Tank

After each use, or when the dirty water tank (0.850 L capacity) reaches its maximum fill line:

1. Switch off the appliance and remove any attached nozzles.
2. Carefully remove the dirty water tank from the main unit.
3. Empty the dirty water into a sink or drain.
4. Rinse the tank thoroughly with clean water to remove any residue.
5. Allow the tank to air dry completely before reattaching it to the unit.

6.2 Cleaning Nozzles and Hose

1. Remove the nozzle from the hose.
2. Rinse the nozzle under running water, ensuring any debris or hair is removed from the brush and suction path.
3. If the hose appears dirty, rinse it by drawing clean water through it (without solution) and then emptying the dirty water tank.
4. Allow all parts to air dry before reassembly and storage.

6.3 Storage

Store the cleaner and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the tanks are empty and clean before storage.

7. Troubleshooting

If you encounter issues with your Techwood TAN-8005R, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on	Battery is depleted	Charge the appliance fully (4-5 hours).
No spray from nozzle	Clean water tank is empty or not properly seated	Refill the clean water tank and ensure it is securely in place.
No spray from nozzle	Spray nozzle is clogged	Clean the nozzle thoroughly to remove any blockages.
Poor suction	Dirty water tank is full	Empty and clean the dirty water tank.
Poor suction	Nozzle or hose is blocked	Remove and clean the nozzle and check the hose for obstructions.
Reduced battery runtime	Battery degradation over time	This is normal with rechargeable batteries. Ensure full charges before use.

8. Specifications

Brand	Techwood
Model Number	TAN-8005R
Product Dimensions (L x W x H)	35 x 28.5 x 36.8 cm
Item Weight	4.32 kg
Clean Water Tank Capacity	1.5 Liters
Dirty Water Tank Capacity	0.850 Liters
Battery Type	Lithium
Battery Voltage	22.2 V

Battery Capacity	2200 mAh
Runtime	Up to 40 minutes
Charging Time	4-5 hours
Number of Speeds	2
Spare Parts Availability	5 Years

9. Warranty & Support

Techwood is committed to providing quality products. Your Techwood TAN-8005R comes with a 30-day satisfaction guarantee. For specific warranty details, product support, spare parts, or to make a warranty claim, please refer to the official Techwood website or contact their customer service directly.
You can visit the Techwood brand store for more information:**Techwood Brand Store**

© 2024 Techwood. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DM2HPMG5

More documents and user manuals: **https://manuals.plus/**