Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SOBERNA

Tikland Wireless Ear Buds Bluetooth 5.3 Headphones User Manual

Brand: SOBERNA

Introduction | What's in the Box | Product Overview | Setup | Operating | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Introduction

This manual provides detailed instructions for the proper use and maintenance of your Tikland Wireless Ear Buds Bluetooth 5.3 Headphones. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

2. What's in the Box

Upon opening your product package, please verify that all the following items are included:

- Tikland Wireless Ear Buds (Left and Right)
- Charging Case
- Charging Cable
- User Manual

3. Product Overview

The Tikland Wireless Ear Buds feature an in-ear design with rounded tips and ear hooks for a secure fit, ideal for sports. The charging case provides portable power and includes a digital display for battery status.



Image: The Tikland Wireless Ear Buds in their rose gold charging case. One earbud is shown being magnetically drawn into its charging slot, while the other rests in its slot. The charging case features a digital display showing 'L 100 R', indicating the charge level of both left and right earbuds.

4. Setup

4.1 Charging the Earbuds and Case

1. Place the earbuds into the charging case. Ensure they are correctly seated in their respective slots.
2. Connect the provided charging cable to the charging port on the case and to a USB power source.
3. The digital display on the charging case will indicate the charging status. A full charge is indicated by '100'.
4. Allow approximately 1-2 hours for a full charge of both the earbuds and the case.

4.2 Bluetooth Pairing

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, indicated by a flashing LED light on the earbuds.
3. On your device (e.g., smartphone, tablet, laptop), go to the Bluetooth settings.
4. Search for new devices. Select "Tikland X17-Pro" from the list of available devices.
5. Once connected, the LED light on the earbuds will stop flashing, and your device will confirm the connection.
6. The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

5. Operating the Earbuds

5.1 Basic Controls (Remote Control Method)

- **Power On:** Open the charging case or long-press the touch area on both earbuds.
- **Power Off:** Place the earbuds back into the charging case and close the lid, or long-press the touch area on both earbuds.
- **Play/Pause:** Single tap the touch area on either earbud.
- **Next Track:** Double tap the touch area on the right earbud.
- **Previous Track:** Double tap the touch area on the left earbud.
- **Answer/End Call:** Single tap the touch area on either earbud during an incoming call.
- **Reject Call:** Long-press the touch area on either earbud during an incoming call.
- **Activate Voice Assistant:** Triple tap the touch area on either earbud.

5.2 Compatible Devices

These earbuds are compatible with a wide range of Bluetooth-enabled devices, including:

- Laptops
- Desktops
- Tablets
- Telephones (Smartphones)
- Smart Speakers
- Televisions
- Car Audio Systems

6. Maintenance

Proper care will extend the life of your earbuds. Follow these guidelines:

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use abrasive cleaners or solvents.
- **Water Resistance:** The earbuds are IPX7 waterproof, meaning they can withstand immersion in water up to 1 meter for 30 minutes. However, the charging case is not waterproof. Avoid exposing the charging case to liquids.
- **Storage:** Store the earbuds in their charging case when not in use to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.
- **Avoid Impact:** Do not drop or subject the earbuds or charging case to strong impacts.

7. Troubleshooting

If you encounter issues with your earbuds, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Earbuds not pairing	Low battery; Bluetooth off; Earbuds not in pairing mode; Device already connected to another Bluetooth device.	Charge earbuds and case; Ensure Bluetooth is enabled on your device; Place earbuds in case, close, then open to re-enter pairing mode; Disconnect from other devices.
No sound from earbuds	Volume too low; Earbuds not connected; Media paused.	Increase volume on your device; Reconnect earbuds; Check if media is paused.

Problem	Possible Cause	Solution
One earbud not working	Low battery on one earbud; Earbud not properly seated in case for charging.	Ensure both earbuds are fully charged; Clean charging contacts on earbud and case.
Charging case not charging	Faulty cable or power source.	Try a different charging cable and USB power adapter.

8. Specifications

Feature	Detail
Model Name	X17-Pro
Brand	SOBERNA
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth
Bluetooth Version	5.3
Ear Placement	In Ear
Form Factor	In Ear
Earpiece Shape	Rounded tips
Water Resistance Level	IPX7 Waterproof
Battery Life	80 Hours (with charging case)
Audio Driver Type	Dynamic Driver
Control Method	Remote
Color	Rose Gold
Specific Uses For Product	Sport
Manufacturer	soberna
Country of Origin	China
ASIN	B0DM4J3D11

9. Warranty and Support

9.1 Warranty Information

Your Tikland Wireless Ear Buds are covered by a limited warranty against defects in materials and workmanship from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty period and terms may vary by region. For specific warranty details, please refer to the warranty card included in your product packaging or contact

customer support.

9.2 Customer Support

If you have any questions, require technical assistance, or need to report an issue with your product, please contact our customer support team. Contact information can typically be found on the product packaging, our official website, or through your retailer.

© 2024 SOBERNA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DM4J3D11

More documents and user manuals: **https://manuals.plus/**