Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SOBERNA s33

SOBERNA Tikland Wireless Earbuds User Manual

Model: s33

Introduction

Thank you for choosing the SOBERNA Tikland Wireless Earbuds, model s33. These earbuds are designed to provide a superior audio experience with advanced features such as Bluetooth V5.3 connectivity, CVC8.0 clear call technology, deep bass, and IPX7 waterproofing. This manual will guide you through the setup, operation, maintenance, and troubleshooting to ensure you get the most out of your new earbuds.



This image displays the SOBERNA Tikland Wireless Earbuds, black in color, resting within their sleek charging case. The case features a digital LED display on the front, indicating a 100% charge level. The earbuds themselves are visible, with their stems extending upwards, suggesting they are ready for use or charging.

What's in the Box

- SOBERNA Tikland Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual

Setup

Charging the Earbuds and Charging Case

1. **Initial Charge:** Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case.
2. **Charge Case:** Connect the provided USB charging cable to the charging port on the case and plug the other end into a USB power adapter (not included) or a computer's USB port.
3. **LED Display:** The LED display on the charging case will show the battery percentage. It will indicate 100% when fully charged. The earbuds will show a charging indicator (e.g., a light) while charging inside the case.
4. **Playtime:** A full charge provides up to 60 hours of playtime with the charging case.

Pairing with Your Device

1. **Power On:** Open the charging case. The earbuds will automatically power on and enter pairing mode. You may hear a voice prompt indicating they are ready to pair.
2. **Activate Bluetooth:** On your device (smartphone, tablet, laptop), go to the Bluetooth settings and turn on Bluetooth.
3. **Select Device:** Look for "Tikland s33" or a similar name in the list of available Bluetooth devices and select it to connect.
4. **Confirmation:** Once connected, you will hear a voice prompt confirming the successful pairing. The earbuds are now ready for use.
5. **Automatic Reconnection:** After the initial pairing, the earbuds will automatically connect to the last paired device when taken out of the case, provided Bluetooth is enabled on the device.

Wearing the Earbuds

Gently insert each earbud into your ear canal. Adjust them slightly until they fit snugly and comfortably. A proper fit ensures optimal sound quality and noise isolation.

Operating Instructions

Touch Controls

The Tikland s33 earbuds feature intuitive touch controls on each earbud. The following table outlines common functions:

Action	Left Earbud	Right Earbud
Play/Pause	Single Tap	Single Tap
Next Track	Double Tap	Double Tap
Previous Track	Triple Tap	Triple Tap
Volume Up	N/A	Long Press
Volume Down	Long Press	N/A
Answer/End Call	Single Tap	Single Tap
Reject Call	Long Press	Long Press
Activate Voice Assistant	Quadruple Tap	Quadruple Tap

LED Display Indicators

The charging case features an LED display that provides important information:

- **Battery Percentage:** Shows the remaining battery life of the charging case.
- **Charging Status:** Indicates when the case and earbuds are charging.

Maintenance

Cleaning

Regular cleaning helps maintain the performance and longevity of your earbuds:

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Do not use harsh chemicals, aerosols, or abrasive cleaners.
- Ensure charging contacts on both earbuds and case are clean and dry.

Water Resistance (IPX7)

The earbuds are IPX7 waterproof, meaning they can withstand immersion in water up to 1 meter for 30 minutes. This makes them suitable for workouts and light rain. However, they are not designed for swimming or prolonged submersion. Always ensure the earbuds are dry before placing them back into the charging case to prevent damage.

Storage

When not in use, store the earbuds in their charging case to protect them from dust, dirt, and physical damage. Store the case in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Earbuds not pairing or connecting:

Ensure Bluetooth is enabled on your device. Make sure the earbuds are charged and out of the case. Try forgetting the device in your Bluetooth settings and re-pairing. If issues persist, try resetting the earbuds (refer to specific reset instructions if available in a separate quick start guide, or place them back in the case and try again).

No sound or low volume:

Check the volume level on both your device and the earbuds. Ensure the earbuds are properly seated in your ears. Confirm they are connected to the correct device. Clean any debris from the earbud grilles.

Charging case not charging:

Verify the USB cable is securely connected to both the case and the power source. Try a different USB cable or power adapter. Ensure the charging port is free of debris.

One earbud not working:

Place both earbuds back into the charging case, close the lid, wait a few seconds, then open it again. This often re-syncs them. Ensure both earbuds are charged.

Specifications

Feature	Detail
Model Name	s33
Brand	SOBERNA
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth
Bluetooth Version	5.3
Playtime	Up to 60 hours (with charging case)
Call Technology	CVC8.0 Clear Call
Water Resistance Level	IPX7 Waterproof
Control Method	Touch
Earbud Weight	Mini 3.2g (per earbud)
Earpiece Shape	In-Ear
Included Components	Cable
Compatible Devices	Laptops, Desktops, Tablets, Telephones, Smart Speakers, Televisions, Car Audio Systems, Cellphones

Warranty and Support

SOBERNA products are manufactured to high-quality standards. For specific warranty information, please refer to the warranty card included with your purchase or visit the official SOBERNA website. If you encounter any issues or require technical assistance, please contact SOBERNA customer support through the contact information provided on the product packaging or the official website. Please have your model number (s33) and purchase details ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DM7HBRSR

More documents and user manuals: **https://manuals.plus/**