Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VECELO KHD-TC17-BMB

VECELO 3-Piece 63" Extendable Kitchen Table with Benches (Model KHD-TC17-BMB) Instruction Manual

Your guide to assembly, operation, and care.

Introduction

Thank you for choosing the VECELO 3-Piece 63" Extendable Kitchen Table with Benches. This dining set is designed for versatility and space efficiency, featuring an extendable tabletop and benches that store neatly underneath. This manual provides essential information to ensure safe assembly, proper use, and long-term maintenance of your product.



Image: The VECELO 3-Piece Extendable Kitchen Table with Benches, showcasing its design in a kitchen environment.

Important Safety Information

- Exercise caution around sharp edges during assembly and use.
- Always assemble the product strictly according to the provided instructions to prevent tip-over risks and ensure structural integrity.
- Do not place excessively heavy objects on the tabletop, as this may compromise the structural stability and cause damage.
- Ensure all screws and fasteners are securely tightened before use and periodically check for tightness.
- Keep small parts and packaging materials away from children to prevent choking hazards.

Package Contents

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- 1 x Dining Table
- 2 x Benches
- 1 x Storage Bag (optional attachment)
- Assembly Tools (e.g., Allen wrench)
- Instruction Manual (this document)



Image: Detail of the optional storage bag, which can be attached to the table frame for convenient storage.

Product Specifications

Model Number	KHD-TC17-BMB
Tabletop Material	MDF, Metal
Bench Material	MDF, Sponge, PU
Table Dimensions (L x W x H)	47.3" - 63" x 28" x 30" (Extendable)
Bench Dimensions (L x W x H)	42" x 12" x 18"
Item Weight	Approximately 48 pounds
Table Weight Capacity	330 lbs
Bench Weight Capacity	550 lbs
Color	Black



Image: Detailed dimensions and weight capacities for the table and benches.

Assembly Instructions

Assembly typically takes approximately 1.5 hours for one person. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches. Refer to the package contents list to ensure all pieces are present.
2. **Assemble Table Frame:** Attach the table legs to the main table frame using the provided hardware. Ensure all connections are finger-tight before fully tightening.
3. **Attach Tabletop Panels:** The tabletop consists of multiple panels. Align the panels with the pre-drilled holes on the table frame. **Important:** For proper alignment of the tabletop, partially screw in the fasteners on one side of a large slab. Then, adjust the metal slide on the opposite side to align with the remaining holes before fully tightening all screws. This method helps ensure a flush fit.
4. **Assemble Benches:** Attach the bench legs to the bench seats using the provided hardware. Ensure all connections are secure.
5. **Final Tightening:** Once all components are assembled, go back and securely tighten all screws and fasteners. Do not overtighten.

6. **Optional Storage Bag:** If desired, attach the storage bag to the designated area on the table frame.



Image: Detail of the sturdy metal construction and support bracket for the bench legs.

Operating Instructions

Extending and Retracting the Tabletop

The VECELO dining table features an extendable design to accommodate varying needs, from small gatherings to larger meals.

1. **To Extend:** Gently pull the two main tabletop sections apart. The extension leaf, stored underneath, will slide into place or can be manually positioned. Ensure the leaf is securely seated before pushing the main sections back together to lock it in place.
2. **To Retract:** Reverse the extension process. Pull the main tabletop sections apart, remove or slide the extension leaf back into its storage position underneath the table, then push the main sections back together until they meet.



Image: Detail of the table's smooth slide mechanism, facilitating easy extension and retraction.

Space-Saving Bench Storage

The benches are designed to fit completely underneath the table when not in use, optimizing space in your living area.

- Simply push the benches inward towards the table legs until they are fully tucked away.
- To use, pull the benches out from under the table.



Image: Visual representation of the table and benches in both their operational and space-saving stored positions.

Care and Maintenance

- **Cleaning:** Wipe the tabletop and benches with a dry cloth. For spills, use a slightly damp cloth and mild soap, then dry immediately. The MDF board is waterproof and scratch-resistant, but prompt cleaning is recommended.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, strong detergents, or chemical solvents, as these can damage the finish.
- **Regular Checks:** Periodically inspect all screws and fasteners to ensure they remain tight. Retighten as necessary to maintain stability.
- **Protect Surfaces:** Use placemats or coasters to protect the tabletop from hot items, spills, and scratches.



Image: A hand wiping the tabletop, illustrating the ease of cleaning the waterproof surface.

Troubleshooting

This section addresses common issues you might encounter.

- **Tabletop Panels Do Not Align Flush:**

  Ensure that the metal slides for the extension mechanism are correctly positioned. During assembly, partially screw in the fasteners on one side of a large slab. Then, adjust the metal slide on the opposite side to align with the remaining holes before fully tightening all screws. If the issue persists, loosen all tabletop screws, adjust alignment, and retighten carefully.

- **Table or Benches Feel Unstable:**

  Check all assembly screws and fasteners. Tighten any loose connections. Ensure the product is placed on a flat, level surface.

- **Difficulty Extending/Retracting Table:**

  Ensure no debris is obstructing the slide mechanism. Apply a small amount of silicone-based lubricant to the slides if movement is stiff. Do not force the mechanism.

If you encounter problems not listed here or require further assistance, please contact VECELO customer support.

Warranty and Customer Support

Warranty Information

VECELO products are manufactured with quality and durability in mind. For specific warranty details regarding your 3-Piece Extendable Kitchen Table, please refer to the warranty card included with your purchase or visit the official VECELO website. Keep your purchase receipt as proof of purchase for any warranty claims.

Customer Support

Should you have any questions, require assistance with assembly, or need to report a missing/damaged part, VECELO customer support is available to help. Please have your model number (KHD-TC17-BMB) ready when contacting support for faster service.
For support, please visit the VECELO Store on Amazon or refer to the contact information provided in your product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DMJZVMY2

More documents and user manuals: **https://manuals.plus/**