Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LONPOO LP-609

LONPOO LP-609 100W Compact CD Stereo System User Manual

Model: LP-609

1. Important Safety Instructions

Please read these instructions carefully before operating the unit. Keep this manual for future reference.

- Do not block any ventilation openings.
- Do not install near any heat sources.
- Protect the power cord from being walked on or pinched.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

2. Package Contents

Verify that all items are included in the package:

- Main Unit (CD Player/Receiver)
- 2 x Speakers
- Remote Control (AAA batteries not included)
- Power Cord (1.2m)
- Speaker Cables
- Instruction Manual



Image: Overview of package contents and product dimensions, including the main unit, speakers, remote, cables, and manual.

3. Product Overview

3.1 Front Panel Controls



Image: Detailed view of the front panel with labels for USB input, headphone jack, mode button, play/pause, stop, skip tracks, volume knob, and CD tray open/close.

- **Power Button:** Turns the unit on/off.
- **CD Tray Open/Close Button:** Ejects or retracts the CD tray.
- **Mode Button:** Switches between CD, FM, Bluetooth, USB, and AUX input modes.
- **Play/Pause Button:** Starts or pauses playback.
- **Stop Button:** Stops playback.
- **Skip/Search Buttons:** Skips to the next/previous track or fast-forwards/rewinds.
- **Volume Knob:** Adjusts the master volume level.
- **USB Input:** For connecting USB storage devices.
- **Headphone Jack (3.5mm):** For private listening.

3.2 Rear Panel Connections



Image: Rear view of the main unit showing speaker outputs, AUX input, FM antenna, and power input.

- **Speaker Outputs:** Connect the included speakers.
- **AUX IN (3.5mm):** For connecting external audio devices.
- **FM Antenna:** For FM radio reception.
- **AC Power Input:** Connect the power cord.

4. Setup

4.1 Speaker Connection

1. Connect the speaker cables from the main unit's speaker outputs to the corresponding inputs on each speaker. Ensure correct polarity (+ to + and - to -).
2. Place the speakers on a stable surface, ideally equidistant from the listening position for optimal stereo sound.

4.2 Power Connection

1. Insert the power cord into the AC power input on the rear of the main unit.
2. Plug the other end of the power cord into a wall outlet.

4.3 Remote Control Setup

1. Open the battery compartment on the back of the remote control.
2. Insert two AAA batteries (not included), observing the correct polarity (+/-).
3. Close the battery compartment.

5. Operating Instructions

5.1 Basic Operation

1. Press the Power button to turn on the unit.
2. Press the Mode button repeatedly to select your desired input source (CD, FM, Bluetooth, USB, AUX).
3. Adjust the volume using the Volume knob on the front panel or the volume buttons on the remote control.

5.2 CD Playback

1. Press the Mode button to select "CD" mode.

2. Press the CD Tray Open/Close button to open the CD tray.
3. Place a CD (CD/CD-R/CD-RW/MP3) with the label side facing up into the tray.
4. Press the CD Tray Open/Close button again to close the tray. The unit will start playing automatically.
5. Use the Play/Pause, Stop, and Skip/Search buttons to control playback.



Image: A hand inserting a CD into the front-loading CD tray of the stereo system.

5.3 FM Radio Operation

1. Press the Mode button to select "FM" mode.
2. Extend the FM antenna for better reception.
3. Press and hold the Play/Pause button (or Scan button on remote) to automatically scan and store available FM stations (up to 30 stations).
4. Use the Skip/Search buttons to navigate through the stored stations.

5.4 Bluetooth Connection

1. Press the Mode button to select "Bluetooth" mode. The display will show "BT" and start flashing, indicating it's in pairing mode.
2. On your Bluetooth device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
3. Select "LONPOO LP-609" from the list. Once connected, the "BT" indicator will stop flashing.
4. You can now play audio from your Bluetooth device through the stereo system. (Note: Bluetooth earphones are not supported).



Image: A smartphone screen showing Bluetooth pairing with the stereo system, with the unit displaying 'BT'.

5.5 USB Playback

1. Insert a USB flash drive (up to 64GB, formatted as FAT32) containing MP3/WMA audio files into the USB port on the front panel.
2. Press the Mode button to select "USB" mode. The unit will automatically detect and start playing audio files from the USB drive.
3. Use the Play/Pause, Stop, and Skip/Search buttons to control playback.



Image: A USB flash drive inserted into the front USB port of the stereo system, with the unit displaying track information.

5.6 AUX Input

1. Connect an external audio device (e.g., smartphone, MP3 player) to the AUX IN jack on the rear panel using a 3.5mm audio cable (not included).
2. Press the Mode button to select "AUX" mode.
3. Play audio from your connected device. The sound will be output through the stereo system.



Image: Close-up of the AUX IN port on the rear panel of the stereo system, highlighted for easy identification.

5.7 Headphone Listening

Plug 3.5mm headphones into the headphone jack on the front panel for private listening. The main speakers will be muted automatically.

5.8 Advanced Playback Features (Remote Control)

- **Treble/Bass Adjustment:** Use the dedicated Treble and Bass buttons on the remote to fine-tune the sound to your preference.
- **Repeat Modes:**
  - **Repeat One:** Repeats the current track.
  - **Repeat All:** Repeats all tracks on the disc/USB.
  - **Random Play:** Plays tracks in a random order.
- **Resume Playback:** The unit will resume playback from the last stopped position when a disc or USB is re-inserted or playback is resumed (does not apply if the Stop button was pressed).

6. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the unit. Do not use abrasive cleaners or solvents.
- **CD Care:** Handle CDs by their edges. Keep them clean and free of scratches.
- **Ventilation:** Ensure the unit has adequate ventilation. Do not block any vents.
- **Storage:** If not used for a long period, unplug the unit and store it in a cool, dry place.

7. Troubleshooting

Problem	Possible Cause	Solution
No power	Power cord not connected; Power outlet not working.	Check power cord connection; Try a different outlet.
No sound	Volume too low; Incorrect input mode; Speaker cables loose.	Increase volume; Select correct input mode; Check speaker connections.

Problem	Possible Cause	Solution
CD not playing	CD inserted incorrectly; CD is dirty or scratched; Disc format not supported.	Reinsert CD correctly; Clean or replace CD; Ensure disc is CD/CD-R/CD-RW/MP3.
Poor FM reception	Antenna not extended; Weak signal.	Extend and adjust FM antenna; Try repositioning the unit.
Bluetooth not connecting	Unit not in pairing mode; Device too far; Device already connected to another unit.	Ensure unit is in Bluetooth pairing mode; Move device closer; Disconnect from other devices.
USB not playing	USB drive not formatted correctly; File format not supported; USB drive capacity too large.	Ensure USB is FAT32; Use MP3/WMA files; Use USB drive up to 64GB.

8. Specifications

Brand	LONPOO
Model Number	LP-609
Connectivity Technology	AUX, Bluetooth, USB
Color	Black
Speaker Type	Stereo
Product Dimensions (LxWxH)	52 x 27.5 x 25 cm
Power Source	Corded Electric
Wattage	100 W (50W + 50W)
Supported Disc Formats	CD, CD-R, CD-RW, MP3
Supported Audio Formats (USB)	MP3, WMA
USB Max Capacity	64GB
FM Frequency Range	76.0 MHz - 95.0 MHz
Number of Speakers	2
Speaker Configuration	4-inch woofer, 1-inch tweeter per speaker
Item Weight	7.4 Kilograms
Country of Origin	China

9. Warranty and Support

9.1 Warranty Information

This product comes with a**1-year warranty** from the date of purchase. The warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper installation. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

If you encounter any issues or have questions about your LONPOO LP-609 Compact CD Stereo System, please contact our customer support team. Refer to the contact information provided on the product packaging or the official LONPOO website.

For faster assistance, please have your model number (LP-609) and purchase details ready.

© 2026 LONPOO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DMNB5P85

More documents and user manuals: **https://manuals.plus/**