Disney MIC-68

Disney Mickey Mouse Waffle and Donut Maker Instruction Manual

Model: MIC-68

Introduction

Thank you for purchasing the Disney Mickey Mouse Waffle and Donut Maker. This appliance is designed to create delicious Mickey-shaped waffles and donuts with ease. Please read this instruction manual thoroughly before use to ensure safe and optimal operation. Keep this manual for future reference.

Important Safety Instructions

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical hazards, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- A short power-supply cord is provided to reduce the risk resulting from becoming entangled in or tripping over a

longer cord.

- Extension cords may be used if care is exercised in their use. If an extension cord is used, the marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance. The longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over.

Product Components

The Disney Mickey Mouse Waffle and Donut Maker includes the following main components:

- **Main Unit Base:** Houses the heating elements and controls.
- **Removable Cooking Plates:** Three interchangeable sets for different shapes (6" Mickey waffle, 4 Mickey icon waffles, 4 Mickey donuts).
- **Locking Latch:** Secures the cooking plates and the unit during operation.
- **Power Light:** Indicates when the unit is powered on and heating.
- **Rotating Handle:** Allows the unit to rotate for even cooking.
- **Drip Tray:** Collects any overflow during cooking.
- **Cooking Plate Storage Bag:** For convenient storage of unused plates.



Image: The main unit of the Mickey Mouse Waffle and Donut Maker, showing its closed position with the Mickey Mouse emblem on top. The unit is silver and black with a drip tray at the bottom.



Image: A composite image highlighting key features: locking handle, power light, plate release latch, and the rotating action for even cooking.

Setup and First Use

1. **Unpack:** Carefully remove all packaging materials and labels from the appliance.
2. **Clean Plates:** Before first use, wash the removable cooking plates in warm, soapy water, rinse, and dry thoroughly. The plates are dishwasher safe.
3. **Wipe Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
4. **Insert Plates:** Open the unit and align the desired cooking plates with the slots on the upper and lower heating elements. Press down firmly until they click into place. Ensure the plates are securely seated.
5. **Position:** Place the waffle and donut maker on a stable, heat-resistant surface. Ensure there is adequate ventilation around the unit.

6. **Pre-heat:** Close the unit and plug it into a 120V AC electrical outlet. The power light will illuminate, indicating the unit is heating. Allow the unit to pre-heat for approximately 5-7 minutes, or until the power light indicates it's ready (if applicable, some models have a ready indicator).



Image: A hand demonstrating the removal of a cooking plate from the waffle maker, showing the ease of interchangeability. The image also shows the three different plate types.

Operating Instructions

This appliance features a rotating action for more even cooking and browning. Always ensure the unit is pre-heated before adding batter.

Making Waffles (6-inch Mickey Character or 4 Mickey Icon)

1. Ensure the desired waffle plates are securely installed and the unit is pre-heated.
2. Lightly grease the cooking plates with cooking spray or a small amount of oil, if desired, especially for the first batch.
3. Pour the waffle batter onto the center of the lower cooking plate. For the 6-inch waffle, pour enough to fill the Mickey

shape. For the 4-icon waffles, pour batter into each individual Mickey shape. Do not overfill.

4. Close the lid and secure the locking latch.
5. Immediately rotate the unit 180 degrees using the handle. This helps distribute the batter evenly.
6. Cook for approximately 3-6 minutes, or until the waffles are golden brown and cooked to your preference. Cooking time may vary based on batter type and desired crispness.
7. Once cooked, unlock the latch, open the unit, and carefully remove the waffles using a heat-resistant plastic or wooden utensil. Do not use metal utensils, as they can damage the nonstick coating.
8. Close the unit and allow it to pre-heat again before making additional waffles.



Image: The waffle maker open, showing the cooking plates for four Mickey icon waffles. An inset shows cooked Mickey icon waffles on a plate.



Image: The waffle maker open, showing the cooking plate for a single 6-inch Mickey character waffle. An inset shows a cooked 6-inch Mickey character waffle on a plate.

Making Donuts (4 Mickey Donuts)

1. Ensure the donut plates are securely installed and the unit is pre-heated.
2. Lightly grease the cooking plates with cooking spray or a small amount of oil, if desired.
3. Carefully pour donut batter into each of the four Mickey-shaped molds on the lower plate. Do not overfill.
4. Close the lid and secure the locking latch.
5. Immediately rotate the unit 180 degrees using the handle.
6. Cook for approximately 4-7 minutes, or until the donuts are golden brown and cooked through. Cooking time may vary.

7. Once cooked, unlock the latch, open the unit, and carefully remove the donuts using a heat-resistant plastic or wooden utensil.
8. Close the unit and allow it to pre-heat again before making additional donuts.



Image: The waffle maker open, showing the cooking plates for four Mickey donuts. An inset shows cooked Mickey donuts on a plate.



Image: A collage showing the three types of cooked items: a large 6-inch Mickey waffle, four smaller Mickey icon waffles, and four Mickey donuts, demonstrating the versatility of the appliance.

Maintenance and Cleaning

Proper cleaning and maintenance will extend the life of your appliance.

1. **Unplug and Cool:** Always unplug the appliance from the electrical outlet and allow it to cool completely before cleaning.
2. **Remove Plates:** Press the plate release latches and carefully remove the cooking plates.
3. **Clean Plates:** The ceramic coated nonstick cooking plates are dishwasher safe. Alternatively, they can be washed by hand in warm, soapy water using a non-abrasive sponge or cloth. Rinse thoroughly and dry completely before storing or re-installing.
4. **Clean Main Unit:** Wipe the exterior of the main unit with a soft, damp cloth. For stubborn stains, use a mild detergent. Do not use abrasive cleaners or scouring pads, as they can damage the finish. Never immerse the main unit, cord, or plug in water or any other liquid.

5. **Clean Drip Tray:** Remove and empty the drip tray. Wash it in warm, soapy water, rinse, and dry.
6. **Storage:** Store the clean, dry cooking plates in the provided storage bag. Store the appliance in a clean, dry place.



Image: The three sets of cooking plates neatly stacked and placed inside a black storage bag, indicating the included storage solution.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet not working.	Ensure the appliance is securely plugged into a working 120V outlet. Check circuit breaker.
Waffles/Donuts are not cooking evenly.	Insufficient pre-heating; uneven batter distribution; not rotating the unit.	Allow the unit to fully pre-heat. Ensure batter is spread evenly. Remember to rotate the unit 180 degrees immediately after closing the lid.
Waffles/Donuts stick to plates.	Plates not greased; too much sugar in batter; plates not clean.	Lightly grease plates before each use, especially the first batch. Ensure plates are clean and free of residue. Reduce sugar in batter if necessary.
Smoke or unusual odor during first use.	Residual manufacturing oils burning off.	This is normal for first use. Ensure good ventilation. If smoke persists after initial use, unplug and contact customer support.

Specifications

Model: MIC-68

Brand: Disney

Power: 120V, 700 Watts

Dimensions: 13.5"D x 7.8"W x 7.1"H

Special Feature: Removable Plates, Rotating Action

Plate Material: Ceramic Coated Nonstick (PFAS free)

Included Components: Base, 3 sets of baking plates, storage bag

UPC: 655772022240

Manufacturer: Select Brands



Image: A diagram showing the dimensions of the waffle and donut maker: 13.5 inches deep, 7.8 inches wide, and 7.1 inches high.

Warranty and Support

This product comes with a Limited Warranty from the manufacturer, Select Brands. For specific warranty details, claims,

or technical support, please refer to the warranty card included with your purchase or contact the manufacturer directly. Do not attempt to repair the appliance yourself.

For further assistance, you may visit the Disney Store on Amazon.

© 2025 Disney. All rights reserved. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question