Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MYPIN CE0406

MYPIN Portable Cordless Pressure Washer (Model CE0406) User Manual

Model: CE0406 | Brand: MYPIN

1. Introduction

Thank you for choosing the MYPIN Portable Cordless Pressure Washer. This device is designed for efficient and convenient cleaning of various surfaces, including vehicles, fences, gardens, and floors. Its cordless design and powerful 600 PSI output make it suitable for a wide range of outdoor cleaning tasks. Please read this manual thoroughly before operation to ensure safe and effective use.



Image 1.1: MYPIN Portable Cordless Pressure Washer with two 2.0Ah batteries.

2. Safety Information

Always observe basic safety precautions when using this product to reduce the risk of injury, electric shock, or fire.

- **Eye Protection:** Always wear appropriate eye protection (safety glasses) when operating the pressure washer.
- **High Pressure Warning:** The maximum water pressure is 600 PSI. Keep hands, face, and other body parts away from the water stream. Do not direct the spray at people, pets, or electrical equipment.
- **Electrical Safety:** Ensure batteries are charged using the provided charger in a dry environment. Do not expose the charger or battery to water.
- **Water Source:** Use clean water only. Do not use corrosive liquids or chemicals that are not designed for pressure washers.
- **Children and Pets:** Keep children and pets away from the operating area.
- **Secure Grip:** Always maintain a firm grip on the pressure washer during operation.

3. Package Contents

Verify that all items are present in your package:



Image 3.1: All components included in the MYPIN Portable Cordless Pressure Washer package.

- 1x Cordless High Pressure Washer
- 1x 6-in-1 Nozzle
- 1x Water Filter
- 1x Quick Connector
- 1x 5-meter (196.8 inch) PVC Hose
- 2x 2.0Ah Li-Batteries
- 1x Foam Bottle (100ml)
- 1x Cleaning Mitten
- 1x Charging Plug
- 1x Suitcase
- 1x User Manual

4. Setup Instructions

Follow these steps to assemble and prepare your pressure washer for use:

1. **Charge Batteries:** Before first use, fully charge both 2.0Ah Li-batteries using the provided charging plug. The charger will show a red light when charging and a green light when fully charged.



Image 4.1: Battery charging indicator lights.

2. **Connect Water Filter:** Attach the water filter to one end of the PVC hose. This filter prevents impurities from entering and damaging the pressure washer.



Image 4.2: Water filter connection and function.

3. **Install Quick Connector:** Install the quick connector onto the other end of the PVC hose.
4. **Attach Hose to Sprayer Gun:** Connect the quick connector (with the hose) to the inlet on the sprayer gun.
5. **Install Nozzle:** Press and twist the 6-in-1 nozzle onto the front of the sprayer gun until it clicks securely into place.
6. **Insert Battery:** Slide a fully charged battery into the battery slot at the base of the pressure washer until it locks.
7. **Prepare Water Source:** Place the end of the PVC hose with the water filter into a bucket of water, a pool, or any suitable water source.



Image 4.3: Step-by-step assembly guide.

Setup and Usage Video

Your browser does not support the video tag.

Video 4.1: A detailed guide on product introduction and usage, demonstrating assembly and initial operation.

5. Operating Instructions

5.1 Starting the Pressure Washer

Once assembled and the hose is in a water source, press the trigger on the handle to start the water flow. It may take a few seconds for water to prime and begin spraying consistently.

5.2 6-in-1 Nozzle Operation

The pressure washer features a versatile 6-in-1 nozzle. Rotate the nozzle head to switch between different spray patterns:

- **0° (High Pressure):** A concentrated, powerful stream for stubborn stains. Use with caution.
- **15° (Spark Water Cleaning):** A narrow, powerful spray for focused cleaning.
- **25° (Big Sector Cleaning):** A wider spray for general cleaning tasks.
- **40° (Wide Angle Cleaning):** A broad, gentle spray for larger areas or delicate surfaces.
- **Straight Mode:** A direct stream.
- **Shower Mode:** A gentle, wide spray suitable for rinsing or garden watering.



Image 5.1: 6-in-1 Multifunction Spray Nozzle settings.

5.3 Foam Cleaning

For deeper cleaning, use the included foam bottle:

1. Fill the 100ml foam bottle with your preferred detergent.
2. Attach the foam bottle to the pressure washer.
3. Spray foam onto the desired surface.
4. Allow the foam to sit for a few minutes (refer to detergent instructions).

5. Rinse thoroughly with a suitable nozzle setting.



Image 5.2: Foam cleaning application.

Product Usage Demonstration

Your browser does not support the video tag.

Video 5.1: A brief demonstration of the pressure washer in action, showcasing its usage for various cleaning tasks.

6. Maintenance

- **After Each Use:** Disconnect the battery. Remove the hose from the water source and the pressure washer. Run the pressure washer briefly to clear any remaining water from the pump and hose.
- **Clean Water Filter:** Regularly inspect and clean the water filter to ensure optimal performance and prevent clogging. A clogged filter can reduce pressure and damage the pump.
- **Battery Care:** Store batteries in a cool, dry place. Do not store fully discharged batteries for extended periods. Recharge them periodically if not in use.

- **Storage:** Store the pressure washer and all accessories in the provided suitcase in a dry, protected area, away from extreme temperatures.

7. Troubleshooting

Problem	Possible Cause	Solution
Pressure washer does not start.	Battery not inserted correctly or not charged.	Ensure battery is fully charged and securely inserted.
Low water pressure.	Clogged water filter; insufficient water supply; air in the system.	Clean water filter. Ensure water source is adequate. Run the unit for a moment to purge air.
Water leaks from connections.	Loose connections; worn O-rings.	Tighten all connections. Inspect and replace O-rings if damaged.
Battery not charging.	Charger malfunction; faulty battery.	Ensure charger is properly connected to power. If problem persists, contact customer support.

8. Specifications

Feature	Specification
Brand	MYPIN
Model Number	CE0406
Power Source	Battery Powered (2x 2.0Ah Li-ion)
Maximum Pressure	600 PSI
Hose Length	5 meters (196.8 inches)
Item Weight	5.7 pounds
Product Dimensions (L x W x H)	18.1" x 10.2" x 2.95"
UPC	342976982974

9. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact MYPIN customer service directly. Keep your purchase receipt as proof of purchase.
For further assistance, you may visit the MYPIN Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DMSW7FLK

More documents and user manuals: **https://manuals.plus/**