Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Wet Brush BWR833FRPKAZ

Wet Brush Smooth Styler Hair Brush - Pink Frost Instruction Manual

Model: BWR833FRPKAZ

Introduction

The Wet Brush Smooth Styler is designed to enhance hair shine and promote hair health. It features a combination of exclusive Ultra-soft IntelliFlex bristles and synthetic boar bristles to gently detangle hair, reduce frizz, and distribute natural oils for a smooth, shiny finish. This brush is suitable for all hair types, whether wet or dry.



Image: The Wet Brush Smooth Styler in Pink Frost, showcasing its design.

Key Features

- **IntelliFlex Bristles:** Exclusive ultra-soft bristles glide through tangles with ease, resulting in up to 55% less breakage for healthier-looking hair.
- **Synthetic Boar Bristles:** Designed to reduce frizz and evenly distribute the hair's natural oils from root to tip, promoting a shiny and smooth finish.
- **Versatile Use:** Effective on all hair types, including straight, wavy, textured, curly, and thick hair. Can be used on both wet and dry hair.
- **Ergonomic Design:** Features an ergonomic handle for comfortable grip and ease of use.
- **Shine-Boosting:** Helps to enhance natural shine and smooth the hair cuticle.



Image: A visual breakdown of the Smooth Styler's features, including less breakage, smooth bristles for shine, dry shampoo distribution, and ergonomic handle.

Setup

The Wet Brush Smooth Styler requires no assembly or complex setup. It is ready for immediate use upon removal from its packaging.

1. **Unpack:** Carefully remove the brush from its packaging.
2. **Inspect:** Before first use, inspect the bristles and handle for any signs of damage. If any damage is observed, do not use the brush and contact customer support.



Image: Front view of the Wet Brush Smooth Styler packaging, highlighting key features.

Operating Instructions

Follow these steps for optimal use of your Wet Brush Smooth Styler:

1. **Detangling:** Start brushing from the ends of your hair and work your way up to the roots. This technique helps to gently loosen knots without pulling or snagging, minimizing breakage.
2. **Smoothing and Shining:** For a smooth and shiny finish, brush your hair from root to tip. The synthetic boar bristles will help distribute your hair's natural oils evenly.
3. **Wet Hair Use:** The IntelliFlex bristles are designed to glide through wet hair without causing damage. Use after showering to detangle and prepare hair for styling.
4. **Dry Hair Use:** Use on dry hair to smooth, add shine, and refresh your style. It can also assist in distributing dry shampoo evenly.



Image: A comparison of hair before and after using the Smooth Styler, demonstrating its smoothing and detangling effects.

Demonstration Video

[redacted]

Video: Official demonstration of the Wet Brush Smooth Styler in use, showcasing its detangling and smoothing capabilities.

Maintenance

Regular cleaning and care will extend the life of your Wet Brush Smooth Styler.

1. **Remove Hair:** After each use, or as needed, gently remove any trapped hair from the bristles. A comb or another brush can be used to help lift the hair.
2. **Washing:** Wash the brush periodically with mild soap and lukewarm water. Avoid harsh chemicals or abrasive cleaners.
3. **Drying:** Allow the brush to air dry completely with the bristles facing down to prevent water from accumulating in the cushion.

4. **Storage:** Store the brush in a clean, dry place away from direct sunlight or extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Bristles appear bent or damaged.	Improper storage, excessive force during brushing, or heat exposure.	Store brush carefully. Avoid using with heat styling tools (e.g., blow dryers) as high heat can damage IntelliFlex bristles. If bristles are severely bent, consider replacing the brush.
Brush not detangling effectively.	Excessive hair buildup, improper brushing technique, or extremely tangled hair.	Ensure brush is clean of hair and debris. Start detangling from ends and work upwards. For very tangled hair, use a detangling spray.
Hair appears frizzy after brushing.	Static electricity, dry hair, or improper use of boar bristles.	Ensure hair is adequately moisturized. Brush gently to distribute natural oils. Consider using an anti-frizz serum.

Specifications

Model Number: BWR833FRPKAZ

UPC: 736658449310

Dimensions: 1.57 x 2.76 x 10.63 inches

Weight: 3.21 ounces

Bristle Material: IntelliFlex (Nylon), Synthetic Boar

Handle Material: Plastic

Color: Pink Frost

Product Benefits: Anti-Frizz, Shine Enhancing, Detangling

Hair Type Compatibility: All hair types

Warranty Information

Specific warranty details for the Wet Brush Smooth Styler are not provided in the product information. For warranty inquiries, please refer to the manufacturer's official website or contact their customer service directly.

Customer Support

For further assistance, questions, or concerns regarding your Wet Brush Smooth Styler, please visit the official Wet Brush website or contact their customer support team.

Official Website: Wet Brush Store on Amazon

© 2026 Wet Brush. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DMZTBN5N

More documents and user manuals: **https://manuals.plus/**