Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NIXON A1444-5210-00

User Manual

NIXON Fremont 40 A1444-100m Water Resistant Men's Analog Field Watch

Model: A1444-5210-00



This image displays the NIXON Fremont 40 watch with its model name and "100 Meter" water resistance rating, highlighting its design.

Introduction

Thank you for choosing the NIXON Fremont 40 A1444-100m Water Resistant Men's Analog Field Watch. This timepiece is engineered for durability and style, featuring a unique "squircle" case design and robust construction. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your watch to ensure optimal performance and longevity.



A detailed front view of the NIXON Fremont 40 watch, showcasing its silver stainless steel case, blue textured dial, and luminous hands and markers.



This image provides a close-up view of the NIXON Fremont 40 watch, highlighting the intricate dial texture, applied indices, and the unique "squircle" case shape.

Setup

1. Unboxing and Initial Inspection

Upon receiving your NIXON Fremont 40 watch, carefully remove it from its packaging. Inspect the watch for any visible damage or defects. Ensure all components, including the watch and any accompanying documentation, are present.

2. Setting the Time

1. Locate the crown on the right side of the watch case.
2. Gently pull the crown outwards to the time-setting position. You may feel a slight click.
3. Rotate the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
4. Once the time is set, push the crown back into its original position to engage the movement and start the watch.



A close-up image showing the watch crown, which is used for setting the time and winding the watch.

3. Adjusting the Bracelet

The NIXON Fremont 40 features a custom 3-link stainless steel bracelet with a quick-adjust locking clasp for an effortless and secure fit.

- To open the clasp, gently press the release buttons on the sides of the clasp.
- To adjust the length, locate the micro-adjustment holes on the clasp. Use a small tool (like a spring bar tool or a paperclip) to depress the spring bar and slide the clasp to the desired position.
- For significant size adjustments, it may be necessary to remove or add links. This procedure typically requires specialized tools and is best performed by a professional watchmaker or jeweler.



This image shows a side profile of the NIXON Fremont 40 watch, highlighting the stainless steel bracelet and the deployment clasp mechanism.

Operating Instructions

Timekeeping

Your NIXON Fremont 40 watch is powered by a reliable Japanese Miyota 2035 quartz 3-hand movement. This movement ensures consistent and accurate timekeeping with minimal maintenance. The watch displays hours, minutes, and seconds through its three hands.



A detailed view of the watch dial, showing the hour, minute, and second hands, along with the applied stick and Arabic indices for clear readability.

Water Resistance

The Fremont 40 is rated for 10 ATM (100 meters) water resistance. This means the watch is suitable for everyday use, including splashes, rain, and recreational swimming.

- **Do not operate the crown or pushers while the watch is wet or submerged.**This can compromise the water resistance.
- Avoid exposing the watch to hot water, steam, or extreme temperature changes, as this can affect the seals.
- After exposure to saltwater, rinse the watch with fresh water and dry it thoroughly with a soft cloth.

Maintenance

Cleaning Your Watch

To maintain the appearance of your NIXON Fremont 40, regularly clean the case and bracelet.

- Use a soft, damp cloth to wipe down the watch case and bracelet.
- For stubborn dirt on the metal bracelet, a soft brush (like a toothbrush) with mild soap and water can be used. Ensure to rinse thoroughly and dry completely.
- Avoid using harsh chemicals, solvents, or abrasive cleaning materials, as these can damage the watch's finish.

Battery Replacement

The NIXON Fremont 40 is powered by a 9V battery (included). When the watch stops running or the second hand begins to skip, it indicates that the battery needs replacement.
Battery replacement should ideally be performed by a qualified watch technician to ensure the water resistance is maintained after the case back is opened and resealed.



This image displays the back of the NIXON Fremont 40 watch case, showing the engraved details including the brand name, model, water resistance, and movement type.

Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight and extreme temperatures. Keeping it in its original box or a watch case can protect it from dust and scratches.

Troubleshooting

Problem	Possible Cause	Solution
Watch is not running.	Battery is depleted.	Replace the battery. (Refer to Battery Replacement section).
Time is inaccurate.	Crown is not fully pushed in.	Ensure the crown is fully pushed into the closed position.
Condensation under crystal.	Exposure to extreme temperature changes or compromised water resistance.	Seek professional service immediately to prevent damage to the movement.

Specifications

- **Model Number:** A1444-5210-00
- **Case Dimensions:** 40mm (diameter)
- **Movement:** Japanese Miyota 2035 Quartz 3-Hand
- **Water Resistance:** 10 ATM / 100 Meters
- **Case Material:** Solid Stainless Steel
- **Crystal:** Hardened Mineral Crystal
- **Band Material:** 3-Link Stainless Steel
- **Clasp Type:** Quick-adjust locking clasp (Deployment Clasp)
- **Battery:** 1 x 9V battery (included)
- **Package Dimensions:** 4.65 x 3.7 x 3.03 inches; 8 ounces
- **Date First Available:** November 15, 2024
- **Manufacturer:** Nixon

Warranty and Support

Warranty Information

NIXON products are manufactured to high standards and come with a limited warranty against defects in materials and workmanship. Specific warranty terms and conditions are typically provided with your purchase or can be found on the official NIXON website. Please retain your proof of purchase for warranty claims.
Protection plans are also available for extended coverage. For details on these plans, please refer to the information provided at the time of purchase or contact your retailer.

Customer Support

For further assistance, technical support, or service inquiries regarding your NIXON Fremont 40 watch, please contact NIXON customer support.
You can find contact information and additional resources by visiting the official NIXON website or their Amazon Brand Store: NIXON Amazon Store.

© 2024 NIXON. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DN6NKMH5

More documents and user manuals: **https://manuals.plus/**