Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

qrcamule HX8072/11

qrcamule Replacement Tongue Care Cleaner for Philips Sonicare HX8072/11 User Manual

Model: HX8072/11

1. Introduction

Thank you for choosing the qrcamule Replacement Tongue Care Cleaner. This product is designed to provide effective tongue cleaning for improved oral hygiene and fresh breath. It is compatible with Philips Sonicare toothbrush handles that support the HX8072/11 model.
Please read this manual carefully before first use to ensure proper operation and maintenance of your tongue care cleaner.

2. Product Overview

The qrcamule Replacement Tongue Care Cleaner features a specialized design for gentle yet effective removal of bacteria and food particles from the tongue surface. Each pack contains two replacement heads.



Image 1: Two qrcamule replacement tongue care cleaner heads. These heads are designed to attach to compatible Philips Sonicare toothbrush handles.

3. Setup

1. **Unpack:** Carefully remove the tongue care cleaner head from its packaging.
2. **Attach to Handle:** Align the tongue care cleaner head with the metal shaft of your compatible Philips Sonicare toothbrush handle. Push the head down firmly until it clicks into place. Ensure it is securely attached.
3. **First Use Rinse:** Before first use, rinse the tongue care cleaner head thoroughly under running water.

4. Operating Instructions

For optimal results, use the tongue care cleaner as part of your daily oral hygiene routine.

1. **Moisten:** Wet the bristles of the tongue care cleaner head.
2. **Apply to Tongue:** Place the tongue cleaner head on the back of your tongue.
3. **Clean Gently:** Turn on your Sonicare toothbrush handle. Gently move the tongue cleaner forward from the back of your tongue to the tip, applying light pressure. Do not scrub aggressively.
4. **Rinse and Repeat:** After each stroke, rinse the tongue cleaner head under running water to remove debris. Repeat the process 2-3 times, covering the entire surface of your tongue.
5. **Duration:** A typical tongue cleaning session should last approximately 20-30 seconds.
6. **Frequency:** Use the tongue cleaner once or twice daily, preferably after brushing your teeth.

5. Maintenance

- **After Each Use:** After each tongue cleaning session, rinse the tongue care cleaner head thoroughly under running water to remove any residue.
- **Storage:** Store the tongue cleaner head upright in a clean, dry place, allowing it to air dry.
- **Replacement:** For optimal hygiene and performance, it is recommended to replace your tongue care cleaner head every 3 months, or sooner if the bristles appear worn or damaged.

6. Troubleshooting

- **Difficulty Attaching/Removing Head:** If the tongue cleaner head is difficult to push onto or pull off the handle, ensure it is correctly aligned with the metal shaft. Apply firm, steady pressure. Avoid twisting or forcing the head, as this may cause damage. If the issue persists, ensure your Sonicare handle is compatible with HX8072/11 type heads.
- **Ineffective Cleaning:** Ensure you are using the correct technique as described in the Operating Instructions. Make sure the bristles are not overly worn; if they are, replace the head.

7. Specifications

Model	HX8072/11 (Replacement)
Compatibility	Compatible with Philips Sonicare toothbrush handles
Quantity	2-pack
Batteries Required	No (Powered by toothbrush handle)

8. Warranty and Support

For any questions, concerns, or support regarding your qrcamule Replacement Tongue Care Cleaner, please contact the seller directly through the platform where you made your purchase. Please refer to your purchase documentation for specific warranty information, if applicable.

© 2026 qrcamule. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DNCND4Y4

More documents and user manuals: **https://manuals.plus/**