W-KING T9 PRO

WKING T9 PRO Bluetooth Speaker User Manual

Model: T9 PRO

Introduction

Thank you for choosing the WKING T9 PRO 250W Peak Bluetooth Speaker. This manual provides detailed instructions for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.



The WKING T9 PRO Bluetooth Speaker, showcasing its powerful design and illuminated woofers.

Package Contents

Please check the package contents upon unboxing to ensure all items are present:

- WKING T9 PRO Bluetooth Speaker
- Power Adapter/Charging Cable
- User Manual
- Replacement Battery (1 Piece)

Product Features

- **High Power Output:** 250W Peak output for robust sound.
- **Wireless Connectivity:** Bluetooth technology for seamless audio streaming.
- **Versatile Inputs:** Supports RCA and XLR connections for various audio sources.
- **Portable Design:** Battery-powered for use in multiple locations.
- **Dual Channel Audio:** Provides stereo sound experience.
- **Floor Standing Design:** Stable and optimized for sound projection.

Setup Guide

1. Battery Installation

The WKING T9 PRO speaker utilizes a removable battery pack. Ensure the battery is properly installed before first use.

1. Locate the battery compartment on the rear or side of the speaker.
2. Open the battery compartment cover.
3. Insert the battery pack into the compartment, ensuring the connectors align correctly.
4. Gently push the battery until it clicks into place.
5. Close the battery compartment cover securely.



Illustration of the battery being inserted into the dedicated compartment on the speaker.



A detailed view of the WKING T9 PRO speaker's removable battery pack.

2. Charging the Speaker

Before initial use, fully charge the speaker's battery.

1. Connect the power adapter to the charging port on the speaker.
2. Plug the power adapter into a standard electrical outlet.
3. The charging indicator light will illuminate. It will typically change color or turn off when fully charged.

3. Initial Power On

Press and hold the Power button (usually located on the control panel) for a few seconds until the speaker powers on and you hear an audible prompt or see the display light up.

Operating Instructions

1. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth mode (indicated by a flashing Bluetooth icon or audible prompt).
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "WKING T9 PRO" from the list of found devices.
4. Once paired, the speaker will confirm with an audible sound, and the Bluetooth indicator will become solid.

2. Connecting via RCA/XLR

For wired connections, use the RCA or XLR input ports.

1. Connect one end of the appropriate audio cable (RCA or XLR) to your audio source device.
2. Connect the other end to the corresponding input port on the WKING T9 PRO speaker.
3. Switch the speaker's input mode to RCA or XLR if necessary (refer to control panel buttons).

3. Volume Control

Adjust the master volume using the dedicated volume knob or buttons on the speaker's control panel. You can also control the volume from your connected device.

4. Power On/Off

To power off the speaker, press and hold the Power button until the speaker shuts down. To power on, press and hold the Power button again.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners or solvents.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods. Store in a cool, dry place.
- **Storage:** When storing the speaker for a long time, ensure it is powered off and disconnected from the power source.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is low or depleted; Power button not pressed correctly.	Charge the speaker; Press and hold the Power button for 3-5 seconds.
No sound from speaker.	Volume too low; Incorrect input mode; Device not paired/connected.	Increase volume; Select correct input mode (Bluetooth, RCA, XLR); Re-pair Bluetooth device or check wired connection.
Bluetooth connection unstable.	Device too far from speaker; Interference; Low battery.	Move device closer to speaker; Avoid obstacles; Charge speaker; Disconnect and re-pair.

Specifications

Feature	Detail
Brand	W-KING
Model Number	T9 PRO
Output Wattage	250 Watts (Peak)

Feature	Detail
Connectivity Technology	Bluetooth
Power Source	Battery Powered
Connector Type	RCA, XLR
Number of Channels	2
Audio Input	Bluetooth
Color	Black
Compatible Devices	Laptop, MP3 Player, Tablet, Smartphone
Mounting Type	Floor Standing

Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official W-KING website. You may also contact W-KING customer service directly for assistance.

Manufacturer: W-KING

ASIN: B0DNCQJM9J

© 2024 W-KING. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question