Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOMCOM 700-056V80LG

HOMCOM Swivel Rocker Recliner Chair with Massage

Model: 700-056V80LG

Important Safety Instructions

Please read and understand all instructions before assembling and using this product. Failure to follow these instructions may result in injury or product damage. Keep this manual for future reference.

- Ensure all components are present and undamaged before assembly.
- Do not use this product if any parts are missing or damaged.
- Assemble the chair on a soft, clean surface to prevent scratches.
- Keep children and pets away during assembly.
- Do not exceed the maximum load capacity of 330 lbs (150 kg).
- Ensure the power cord for the massage function is not pinched or damaged.
- Unplug the chair from the power outlet when not in use or before cleaning.
- This manual recliner requires manual effort to recline and return to an upright position. It is not recommended for individuals with limited physical strength.

Product Overview

The HOMCOM Swivel Rocker Recliner Chair is designed for comfort and relaxation. It features a manual reclining mechanism, 360-degree swivel, rocking function, and an 8-point vibration massage system. The chair is upholstered in PU leather and includes convenient side pockets.



Image: The HOMCOM Swivel Rocker Recliner Chair in its upright position, showcasing its light grey PU leather upholstery and side pocket.

Key Features:

- **8-Point Vibration Massage:** Targets back, lumbar, thighs, and legs with 8 modes and a 15/30-minute timer, controlled by a wired remote.
- **Adjustable Recline:** Manual recline up to 150 degrees with an integrated footrest.
- **360° Swivel and Rock Function:** Allows for versatile movement and relaxation.
- **Durable Material:** Soft PU leather for easy cleaning and maintenance.
- **Comfortable Padding:** High-density foam padding with a pocket spring system for support.
- **Convenient Storage:** Two side pockets for remote controls or small items.

Package Contents

Verify that all the following components are included in your package:

- 1 x Massage Recliner Chair (main body, backrest, armrests, footrest components)
- 1 x Wired Remote Control for Massage Function
- 1 x Power Adapter for Massage Function
- 1 x Instruction Manual

Setup / Assembly Instructions

Assembly is estimated to take approximately 15 minutes. No special tools are required.

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a clean, soft surface to prevent damage.
2. **Attach Backrest:** Align the metal brackets on the backrest with the corresponding slots on the chair base. Push down firmly until the backrest locks into place. You should hear a click.
3. **Connect Power:** Locate the power cable for the massage unit. Connect it to the provided power adapter, then plug the adapter into a standard electrical outlet. Ensure the cable is routed safely and not under the chair where it could be pinched.
4. **Final Check:** Ensure all connections are secure and the chair is stable before use.

Operating Instructions

Reclining Function

To recline the chair:

1. Locate the ring-style handle on the side of the chair.
2. Pull the handle firmly to release the footrest and initiate the recline mechanism.
3. Lean back gently to adjust the recline angle up to 150 degrees. The chair will hold its position.

To return to the upright position:

1. Push your heels against the footrest to retract it.
2. Lean forward to bring the backrest to its upright position. Ensure the footrest is fully locked before standing.



Image: The recliner chair shown in a partially reclined position, highlighting the extended footrest and headrest support.

Massage Function

The chair features an 8-point vibration massage system controlled by a wired remote.

1. Ensure the chair is plugged into a power outlet.
2. Use the wired remote control, stored in the side pocket, to operate the massage functions.
3. The remote allows you to select from 8 vibration points (back, lumbar, thighs, legs), choose from 8 massage modes, and set a timer for 15 or 30 minutes.
4. Press the power button on the remote to turn the massage function on or off.



Image: An illustration of the chair highlighting the 8 vibration massage points and the remote control used to operate them.

Swivel and Rocking Function

The chair base allows for 360-degree swivel and a gentle rocking motion.

- To swivel, simply rotate the chair in any desired direction.
- To rock, lean back and forth gently. Ensure the chair is on a stable, flat surface for optimal rocking.



Image: A graphic illustrating the multi-functional capabilities of the chair, including manual reclining up to 150 degrees, rocking, and 360-degree swiveling.

Maintenance and Care

Cleaning

- **PU Leather:** Wipe clean with a damp cloth. For stubborn stains, use a mild soap solution and wipe immediately with a clean, damp cloth, then dry thoroughly.
- Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the upholstery.
- Do not expose the chair to direct sunlight for prolonged periods, as this may cause fading or cracking of the material.

General Care

- Regularly check all bolts and screws to ensure they are tight. Retighten if necessary.
- Avoid placing heavy or sharp objects on the chair that could puncture or tear the upholstery.

- Keep the chair away from heat sources and open flames.



Image: A close-up view of the PU leather material on the chair, demonstrating its smooth texture.

Troubleshooting

- **Chair does not recline:** Ensure the recline handle is pulled completely. Check for any obstructions under the footrest mechanism.
- **Massage function not working:** Verify that the power adapter is securely plugged into both the chair and a working electrical outlet. Check the remote control for any damage.
- **Chair feels unstable:** Inspect all assembly points to ensure they are properly secured. Tighten any loose connections. Ensure the chair is on a flat, even surface.

If you encounter issues not listed here or if troubleshooting steps do not resolve the problem, please contact customer support.

Specifications

Feature	Specification
Brand	HOMCOM
Model Number	700-056V80LG
Color	Light Grey
Material	PU Leather, Steel, Foam
Upright Dimensions (W x D x H)	36.2" x 38.2" x 40.9" (92 x 97 x 104 cm)
Reclining Dimensions (W x D x H)	36.2" x 64.6" x 31.9" (92 x 164 x 81 cm)
Seat Size (W x D x H)	20.9" x 21.3" x 19.7" (53 x 54 x 50 cm)
Back Size (W x H x D)	35.4" x 22.4" x 9.4" (90 x 57 x 24 cm)
Maximum Reclining Angle	150°
Input Voltage	AC 110-240V, 50/60Hz
Output Voltage	DC 12V/0.5A/6W
Cord Length	4.9' (1.5 m)
Maximum Load Capacity	330 lbs (150 kg)
Recommended User Height	Up to 6'3" (190 cm)
Assembly Time	Approx. 15 minutes



Image: Detailed diagram showing the dimensions of the chair in both upright and reclined positions, along with a user height guide.

Warranty and Support

For warranty information or customer support, please refer to the documentation included with your purchase or contact HOMCOM customer service directly. Keep your purchase receipt for warranty claims.

© 2025 HOMCOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DNGJN1DX

More documents and user manuals: **https://manuals.plus/**