MILTON 5.0L Black

Milton Rapid Digital Air Fryer 5L Instruction Manual

Model: 5.0L Black

1. Introduction

Thank you for choosing the Milton Rapid Digital Air Fryer 5L. This appliance uses rapid hot air circulation to cook your favorite foods with significantly less oil, offering a healthier alternative to traditional frying. Please read this manual thoroughly before first use to ensure safe and optimal operation. Keep this manual for future reference.

2. Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury.

- Read all instructions before operating the appliance.
- Do not immerse the main unit, cord, or plug in water or other liquids.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Keep the appliance and its cord out of reach of children.
- Do not block any air vents. Ensure adequate space around the appliance during operation.
- Use the appliance on a stable, level, heat-resistant surface.
- Do not overfill the air fryer basket.
- Unplug the appliance from the outlet when not in use and before cleaning. Allow it to cool completely before handling.
- Do not touch hot surfaces. Use handles or knobs.
- Only use accessories recommended by the manufacturer.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.

3. Product Overview

Familiarize yourself with the components of your Milton Rapid Digital Air Fryer 5L.



Figure 3.1: Milton Rapid Digital Air Fryer 5L main unit. This image shows the complete air fryer with its digital control panel and the pull-out basket.

Components:

1. **Main Unit:** Houses the heating element and fan.
2. **Digital Control Panel:** Touch-sensitive display for setting time, temperature, and selecting presets.
3. **Air Fryer Basket:** Removable non-stick basket for holding food.
4. **Handle:** For safely pulling out and inserting the air fryer basket.
5. **Air Inlet:** Located on the top of the appliance.
6. **Air Outlet Vents:** Located at the rear of the appliance.

4. Before First Use

Follow these steps before using your air fryer for the first time.

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Clean the air fryer basket and pan thoroughly with hot water, dish soap, and a non-abrasive sponge. These parts are dishwasher safe.
3. Wipe the inside and outside of the appliance with a damp cloth. Do not immerse the main unit in water.
4. Place the air fryer on a stable, level, heat-resistant surface, ensuring there is at least 10 cm of free space on the back and sides, and 10 cm above the appliance.

5. Operating Instructions

Learn how to operate your Milton Rapid Digital Air Fryer for various cooking tasks.

5.1. Basic Operation

1. Plug the power cord into a grounded wall outlet. The digital display will illuminate.
2. Carefully pull the air fryer basket out of the appliance using the handle.
3. Place your ingredients into the air fryer basket. Do not exceed the MAX fill line indicated inside the basket.
4. Slide the air fryer basket back into the appliance until it clicks into place.
5. Press the Power button to turn on the appliance.
6. Use the temperature control buttons (up/down arrows) to set the desired cooking temperature (80°C to 200°C).
7. Use the timer control buttons (up/down arrows) to set the desired cooking time (1 to 60 minutes).
8. Press the Start/Pause button to begin the cooking process.
9. During cooking, for even results, some foods may require shaking the basket halfway through. Carefully pull out the basket, shake the contents, and then slide it back in. The appliance will resume cooking automatically.
10. When the cooking time is complete, the appliance will beep and automatically shut off.
11. Carefully pull out the basket and transfer the cooked food to a plate.



Figure 5.1: Digital control panel with touch buttons for temperature, time, and preset menus.

5.2. Using Preset Functions

The Milton Rapid Digital Air Fryer 5L features 8 preset menus for common dishes. These presets automatically set the optimal temperature and time.

1. After placing food in the basket and turning on the appliance, press the Menu button to cycle through the available presets.
2. The digital display will show the icon for the selected preset (e.g., fries, chicken, fish, pizza, cookies, grill, veggies, reheat).
3. Once you have selected your desired preset, press the Start/Pause button to begin cooking.
4. You can manually adjust the temperature and time even after selecting a preset if needed.



Figure 5.2: The control panel displaying various preset menu options for different food types.

5.3. 360° High-Speed Air Circulation

This air fryer utilizes 360° high-speed air circulation technology to ensure even cooking and crispy results with minimal oil. The powerful 1450W motor facilitates rapid heating and efficient cooking.



Figure 5.3: The air fryer in operation, demonstrating the 360° air circulation for even cooking, as shown with a whole chicken.

6. Cooking Guide

Here are some general tips for cooking with your air fryer:

- **Preheating:** For best results, preheat the air fryer for 3-5 minutes at the desired cooking temperature before adding food.
- **Oil Usage:** While the air fryer requires significantly less oil, a small amount of oil (1-2 teaspoons) can enhance crispiness and flavor for some foods.
- **Food Quantity:** Avoid overcrowding the basket. Cook food in smaller batches for optimal air circulation and even cooking.
- **Shaking:** Shake the basket every 5-10 minutes for foods like fries, nuggets, or vegetables to ensure even browning.
- **Doneness:** Always ensure food is cooked to a safe internal temperature.

6.1. Less Oil Usage

The Milton Rapid Digital Air Fryer uses up to 90% less oil compared to traditional deep frying, providing a healthier way to enjoy

fried foods.



Figure 6.1: Visual comparison illustrating the difference between deep-fried food and air-fried food, highlighting reduced oil content.

7. Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your air fryer.

1. Always unplug the appliance and allow it to cool completely before cleaning.
2. Clean the air fryer basket and pan after every use. These parts have a non-stick coating and are dishwasher safe. For hand washing, use hot water, dish soap, and a non-abrasive sponge.
3. Wipe the exterior of the appliance with a damp cloth. Do not use harsh abrasive cleaners or scouring pads, as they can damage the surface.
4. Clean the interior of the appliance with a damp cloth and mild detergent if necessary. Ensure no water enters the heating element area.
5. Ensure all parts are completely dry before storing or reusing the appliance.



Figure 7.1: The air fryer basket removed from the main unit, ready for cleaning.

8. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
The air fryer does not turn on.	The appliance is not plugged in. The power outlet is not working.	Ensure the power cord is securely plugged into a working electrical outlet. Check the circuit breaker.
Food is not cooked thoroughly.	Temperature or time setting is too low. Basket is overcrowded.	Increase cooking temperature or time. Cook food in smaller batches.
Food is not crispy.	Basket is overcrowded. Food not shaken. Not enough oil (for some foods).	Reduce food quantity. Shake the basket halfway through cooking. Lightly brush or spray food with oil.

Problem	Possible Cause	Solution
White smoke comes from the appliance.	Fatty ingredients are being cooked. Oil residue from previous use.	This is normal for fatty foods. Clean the basket and pan thoroughly after each use to remove oil residue.

9. Technical Specifications

Detailed specifications for the Milton Rapid Digital Air Fryer 5L.

- **Model Name:** 5.0L Black
- **Capacity:** 5 Liters
- **Output Wattage:** 1450 Watts
- **Min Temperature Setting:** 80 Degrees Celsius
- **Max Temperature Setting:** 200 Degrees Celsius
- **Control Method:** Touch Control Panel
- **Product Dimensions (D x W x H):** 30.5D x 29.5W x 30.5H Centimeters
- **Item Weight:** 3.8 Kilograms
- **Material:** Plastic (Exterior), Nonstick Coating (Basket)
- **Special Features:** Automatic Shut-Off, Temperature Control, Timer
- **Dishwasher Safe:** Yes (Basket and Pan)
- **Country of Origin:** China

10. Warranty and Customer Support

Your Milton Rapid Digital Air Fryer 5L comes with a manufacturer's warranty and dedicated customer support.

- **Warranty:** 1-year manufacturer's warranty.
- **Customer Support:** For any assistance, please contact HYDRO VALVES.
- **Customer Support Call:** 9355645866
- **Customer Support Email:** Info@miltonhomeappliances.com
- **Operating Hours:** Monday to Saturday, 10:00 AM to 5:30 PM (excluding National Holidays).

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question