Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

REVOTRA MK-B-DCM01

REVOTRA 12-Cup Programmable Coffee Maker Instruction Manual

Model: MK-B-DCM01 | Brand: REVOTRA

1. Introduction

Thank you for choosing the REVOTRA 12-Cup Programmable Coffee Maker. This manual provides essential information for the safe and efficient operation of your new appliance. Please read all instructions carefully before first use and retain for future reference.



Image 1.1: Front view of the REVOTRA 12-Cup Programmable Coffee Maker.

2. Important Safety Instructions

- Read all instructions before using the coffee maker.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and

before cleaning the appliance.

- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Never brew with boiling water.

3. Parts Diagram

Familiarize yourself with the components of your coffee maker:



Image 3.1: Overview of the coffee maker, highlighting its dimensions (8.6"D x 6.7"W x 12.6"H) and showing the removable filter and brew basket.



Image 3.2: The removable filter basket, designed for easy cleaning and reuse.



Image 3.3: The easy-view water window with clear markings for 1-12 cups, including a 'MAX ICED' line.



Image 3.4: Cord storage area located at the back of the appliance for neat organization.

4. Setup

4.1 Initial Cleaning

Before first use, it is recommended to clean the coffee maker. Run two full cycles with water only, then one cycle with a vinegar solution (equal parts water and white vinegar) to descale and remove any manufacturing residues. Follow with two more cycles of fresh water.

4.2 Setting the Clock

To set the current time:

1. Plug in the coffee maker. The LED display will show '12:00'.
2. Press the 'HOUR' button to adjust the hour. Hold to advance quickly.
3. Press the 'MIN' button to adjust the minutes. Hold to advance quickly.
4. Ensure the AM/PM indicator is correct. The PM indicator will light up when PM is selected.

Video 4.1: Demonstrates how to set the clock on the coffee maker.

Your browser does not support the video tag. This video demonstrates setting the clock and various brew options on the REVOTRA coffee maker, including 1-4 cup and ice coffee settings.

5. Operating Instructions

5.1 Brewing Regular Coffee

1. Fill the water reservoir with fresh, cold water up to the desired level using the water window on the side. Do not exceed the 'MAX' line.
2. Place the reusable filter basket into the brew basket holder. Add your desired amount of ground coffee into the

filter. (Refer to the manual for recommended coffee-to-water ratios).

3. Close the top lid securely.
4. Place the empty glass carafe on the warming plate.
5. Press the 'ON/OFF' button. The red indicator light will illuminate, and brewing will begin.

5.2 Adjusting Brew Strength (Regular & Strong)

The coffee maker offers adjustable brew strength:

- After adding coffee grounds, press the 'STRONG' button once for regular strength.
- Press the 'STRONG' button again to cycle through stronger brew options (indicated by multiple coffee bean icons on the display).



Image 5.1: The control panel illustrating the 'STRONG' button for selecting brew intensity.

5.3 1-4 Cup Setting

For smaller batches (1-4 cups), press the 'PROG' button twice after setting up your coffee. This optimizes extraction for smaller servings.



Image 5.2: The coffee maker in a kitchen setting, demonstrating the 1-4 cup brewing option.

5.4 Ice Coffee Mode

To brew iced coffee, press the 'PROG' button three times. This setting is designed to create a perfectly balanced cold brew when poured over ice.

5.5 Programmable Auto Brew

Set your coffee to start brewing at a preferred time:

1. Press the 'PROG' button once. The green 'AUTO' indicator will flash.
2. Use the 'HOUR' and 'MIN' buttons to set your desired start time. Ensure the AM/PM setting is correct.
3. Once the time is set, the 'AUTO' indicator will stop flashing and remain steady, indicating the program is active.
4. The coffee maker will automatically begin brewing at the set time.



Image 5.3: The digital display showing the 24-hour programmable timer function.

5.6 Pause & Serve

The anti-drip system allows you to pause brewing and pour a cup of coffee before the full cycle is complete. Simply remove the carafe, and the flow will stop. Replace the carafe within 30 seconds to prevent overflow and resume brewing.

5.7 Keep Warm Function

After brewing, the coffee maker's built-in warming plate will keep the coffee at an optimal temperature for up to 2 hours. The auto shut-off feature will activate after 2 hours for safety and energy efficiency.



Image 5.4: The warming plate, illustrating the 2-hour keep-warm and auto shut-off features.

6. Maintenance

6.1 Daily Cleaning

- Unplug the coffee maker and allow it to cool completely.
- Remove the filter basket and discard used coffee grounds. Wash the filter basket and glass carafe with warm, soapy water. Rinse thoroughly.
- Wipe the exterior of the coffee maker with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- The non-stick warming plate can be wiped clean with a damp cloth.



Image 6.1: The removable filter basket being cleaned, demonstrating the easy clean-up feature.

6.2 Descaling (Automatic Cleaning Cycle)

After approximately 60 brews, the LED display will show a "CLEAN" reminder, indicating that descaling is needed to remove mineral buildup and maintain optimal coffee flavor.

1. Fill the water reservoir with a solution of equal parts white vinegar and water.
2. Place the empty carafe on the warming plate.
3. Hold the 'STRONG' brew button for 3 seconds to activate the cleaning cycle. The "CLEAN" indicator will flash.
4. Do not unplug or press the 'ON/OFF' button during the cleaning cycle, or the reminder will not clear.
5. Once the cycle finishes, the "CLEAN" message will disappear, and your coffee maker is ready to brew again.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Coffee does not brew.	No water in reservoir; coffee maker not plugged in; 'ON/OFF' button not pressed.	Fill water reservoir; ensure power cord is securely plugged in; press 'ON/OFF' button.
Coffee overflows from filter basket.	Too much coffee grounds; filter basket not seated correctly; carafe not on warming plate.	Reduce coffee grounds; ensure filter basket is properly inserted; place carafe correctly.
Coffee tastes weak.	Not enough coffee grounds; 'STRONG' brew not selected; descaling needed.	Increase coffee grounds; select 'STRONG' brew; perform descaling cycle.
"CLEAN" reminder does not clear.	Cleaning cycle interrupted.	Ensure the cleaning cycle runs to completion without interruption.

8. Specifications

- **Brand:** REVOTRA
- **Model Name:** 12Cup Digital Coffee Maker
- **Item Model Number:** MK-B-DCM01
- **Color:** Silver/Black
- **Product Dimensions:** 8.6"D x 6.7"W x 12.6"H
- **Coffee Maker Type:** Drip Coffee Machine
- **Special Features:** 1-4 Cup Setting, 1.8 L Capacity, Digital Display, Ice Coffee Mode, Programmable Timer
- **Operation Mode:** Fully Automatic
- **Voltage:** 120 Volts
- **Included Components:** Carafe, Coffee Maker, User Manual
- **Exterior Finish:** Stainless Steel
- **Coffee Input Type:** Ground Coffee
- **Item Weight:** 4.5 pounds
- **Is Dishwasher Safe:** No

9. Warranty and Support

For any questions or support needs, please contact our customer service team. We are here to assist you with anything you may require regarding your REVOTRA coffee maker.
While specific warranty details are not provided in this manual, please refer to your purchase documentation or contact customer support for warranty information.

© 2024 REVOTRA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why does my REVOTRA MK-B-DCM01 coffee maker turn off after approximately 1 hour when the manual states it should stay on for 2 hours?

According to the REVOTRA MK-B-DCM01 instruction manual (Section 5.7), the built-in warming plate is designed to keep coffee at an optimal temperature for up to 2 hours, after which the auto shut-off feature activates...

Read full answer

How do I start the cleaning cycle on my REVOTRA MK-B-DCM01 coffee maker when the light is flashing and it won't reset?

To start the cleaning cycle and clear the flashing "CLEAN" reminder on your REVOTRA MK-B-DCM01, follow these specific steps:Prepare the Solution: Fill the water reservoir with a mixture of equal parts white vinegar and...

Read full answer

Why does the REVOTRA MK-B-DCM01 coffee maker dispense different amounts of water when I select the ounce size?

The REVOTRA MK-B-DCM01 is a drip coffee machine that typically brews based on the amount of water you manually pour into the reservoir, rather than having an internal flow meter to measure specific ounces...

Read full answer

Why does my REVOTRA MK-B-DCM01 coffee maker sometimes overfill when I select the 12oz size?

Based on the manual for the REVOTRA MK-B-DCM01, this model is a traditional drip coffee maker that brews based on the amount of water you pour into the reservoir, rather than a single-serve machine...

Read full answer

Open the live page

https://manuals.plus/asin/B0DNSHVP14

More documents and user manuals: **https://manuals.plus/**