topzee AF200EDK

TOPZEE 2.1Qt Small Air Fryer

Model: AF200EDK | Brand: topzee

1. Introduction and Overview

The TOPZEE 2.1Qt Small Air Fryer is a compact and efficient kitchen appliance designed for healthier cooking. Utilizing 1000W power and advanced air frying technology, it delivers crispy and moist results with significantly less oil, making it ideal for guilt-free indulgence. Its versatile functions allow for air frying, roasting, baking, and reheating a variety of foods quickly and easily.

This mini air fryer is perfect for 1-2 servings, making it suitable for apartments, dorms, RVs, or small kitchens where space is a consideration. It features a sleek design, intuitive digital controls with 7 preset menus, adjustable temperature and timer settings, and convenient shake reminders for optimal cooking. The non-stick, BPA-free basket ensures hassle-free cooking and easy cleanup.



Image: The TOPZEE 2.1Qt Small Air Fryer, showcasing its compact design and the types of crispy food it can prepare, such as chicken wings and french fries.

2. Safety Instructions

Please read all instructions carefully before using the appliance to ensure safe and optimal operation. Keep this manual for future reference.

- Always place the air fryer on a stable, heat-resistant surface, away from walls or other appliances to allow for proper air circulation.
- Do not immerse the main unit, cord, or plug in water or any other liquid.
- Ensure the voltage indicated on the appliance matches your local power supply before connecting.
- Supervise children closely when the appliance is in use.
- Do not operate the air fryer if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way.
- Avoid using abrasive cleaning agents or sharp objects on the non-stick surfaces.
- Unplug the air fryer from the outlet when not in use and before cleaning. Allow it to cool down

completely before handling.

- Do not block any air vents during operation.
- Never fill the basket with oil or other liquids, as this could create a fire hazard.

3. Product Components

The TOPZEE 2.1Qt Small Air Fryer consists of the following main components:

- **Main Unit:** Houses the heating element, fan, and control panel.
- **Digital Touch Control Panel:** Features a rotary dial for temperature and time adjustment, along with preset icons.
- **Removable Basket:** The primary cooking container where food is placed.
- **Food Tray/Crisper Plate:** Sits inside the basket, allowing air to circulate around food for even cooking.
- **Handle:** For safely pulling out and inserting the basket.



Image: A visual representation of the TOPZEE Air Fryer, highlighting its main parts including the main unit, removable

basket, and handle.

4. Setup

1. **Unpack:** Carefully remove all packaging materials from the air fryer and its accessories.
2. **Clean:** Before first use, wash the removable basket and food tray with warm, soapy water. Rinse thoroughly and dry completely. Wipe the main unit with a damp cloth.
3. **Placement:** Place the air fryer on a stable, level, and heat-resistant surface. Ensure there is at least 6 inches (15 cm) of clear space around the back and sides of the unit for proper ventilation.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

5. Operating Instructions

The TOPZEE Air Fryer features an intuitive digital touch control panel for easy operation.

General Operation:

1. **Power On:** Plug in the air fryer. The display will illuminate briefly.
2. **Preheat (Optional):** For best results, preheat the air fryer. Select a desired temperature and time, then press the start button.
3. **Load Food:** Place the food tray into the basket, then add your ingredients. Do not overfill the basket to ensure even cooking. Slide the basket back into the main unit until it clicks into place.
4. **Select Settings:** Use the rotary dial to select a preset menu or manually adjust the temperature (120°F to 400°F) and time.
5. **Start Cooking:** Press the Play/Pause button to begin the cooking cycle.
6. **Shake Reminder:** For certain foods, the air fryer will beep to remind you to shake the basket for even crisping. Pull out the basket, shake the contents, and reinsert it to resume cooking.
7. **Completion:** The air fryer will beep when the cooking cycle is complete. Carefully pull out the basket and remove the cooked food.



Image: The digital control panel of the TOPZEE Air Fryer, illustrating the intuitive rotary dial and the 7 smart presets for various food types.

Cooking Presets:

The air fryer comes with 7 convenient preset menus for common dishes. These settings provide recommended temperature and time, which can be adjusted as needed.

Preset	Temperature	Time Range
Fries	400°F	14-19 min
Pizza	400°F	15-20 min
Drumstick	400°F	18-23 min
Steak	360°F	20-25 min
Fish or Shrimp	360°F	12-18 min
Meatball	360°F	14-19 min

Preset	Temperature	Time Range
Dehydrate	140°F	4-12 hours



Image: Close-up of golden french fries, illustrating the crispy results achievable with the air fryer's 1000W power, cooking from frozen to crispy in approximately 15 minutes.



Image: The 2.1Qt air fryer basket shown alongside typical meal portions for 1-2 people, such as 0.8 lbs of french fries or 5 chicken wings, demonstrating its compact capacity.



Image: A woman enjoying food prepared with the TOPZEE Air Fryer in a kitchen, highlighting its quiet operation (52dB) and suitability for various small living spaces like dorms, RVs, apartments, and offices.

6. Maintenance and Cleaning

Proper maintenance ensures the longevity and performance of your TOPZEE Air Fryer. The non-stick basket and food tray are designed for easy cleaning.

- **Unplug and Cool:** Always unplug the air fryer and allow it to cool completely before cleaning.
- **Basket and Tray:** The BPA-free basket and food tray are dishwasher safe. For hand washing, use warm, soapy water and a non-abrasive sponge. Rinse thoroughly and dry completely. Wipe the main unit with a damp cloth.
- **Interior:** For stubborn residue inside the main unit, gently wipe with a damp cloth. Ensure no water enters the electrical components.



Image: Demonstrates the ease of cleaning the air fryer, showing the basket and crisper plate both in a dishwasher and being hand-washed under a faucet.



Image: Illustrates the ultralight and compact design of the air fryer, showing how it can be easily stored in a cabinet or on a countertop, emphasizing its space-saving benefits.

7. Troubleshooting

If you encounter any issues with your air fryer, please refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet malfunction; basket not fully inserted.	Check power cord connection; try a different outlet; ensure basket is securely closed.
Food is not cooked evenly.	Basket overloaded; food not shaken/flipped; incorrect temperature/time.	Do not overload; shake or flip food halfway through cooking; adjust temperature and time as needed.
White smoke coming from the appliance.	Grease residue from previous use; high-fat food cooking.	Clean the basket and tray thoroughly; for high-fat foods, drain excess fat during cooking.

Problem	Possible Cause	Solution
Food is not crispy.	Too much moisture; not enough oil (if desired); basket overloaded.	Pat food dry before air frying; lightly coat with oil; ensure proper air circulation by not overloading.

If the problem persists, please contact customer support.

8. Specifications

Feature	Detail
Brand	topzee
Model Name	AF200EDK
Capacity	2.1 Quarts
Color	Black
Product Dimensions	9.4"D x 9.4"W x 12"H
Material	Plastic
Output Wattage	1000 Watts
Voltage	120 Volts
Control Method	Touch
Max Temperature Setting	400 Degrees Fahrenheit
Nonstick Coating	Yes
Dishwasher Safe Parts	Yes (Basket)
Item Weight	4.95 pounds (2.25 Kilograms)
UPC	860013281120

9. Warranty and Support

For any questions, concerns, or support regarding your TOPZEE 2.1Qt Small Air Fryer, please contact our customer support team. We are dedicated to ensuring your satisfaction with our products.

Email: Support@topzee.com



Image: Contact information for TOPZEE customer support, including the support email address.

© 2025 topzee. All rights reserved.