ALLIMITY Q55QA221B

ALLIMITY Voice Remote Control User Manual

Model: Q55QA221B

Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your ALLIMITY Voice Remote Control. This remote is designed for seamless compatibility with specific Qilive TV models, including Q55QA2318, Q55QA221B, Q43QA231 (600129953), Q43QA231 (600144096), and Q32HA231B. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

Setup

1. Battery Installation

The ALLIMITY Voice Remote Control requires batteries for operation (not included). Please follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries (not supplied), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery cover by sliding it back into place until it clicks securely.





Figure 1: Rear view of the remote control, highlighting the battery compartment for installation.

2. Initial Connection

This remote control is designed for immediate use with compatible Qilive TV models without requiring any programming or complex installation. Once batteries are correctly installed, the remote should function directly with your television.

Operating Instructions

The ALLIMITY Voice Remote Control is designed for intuitive operation, covering all essential functions of your television. Its ergonomic design ensures comfortable handling and stable performance.





Figure 2: Front view of the ALLIMITY Voice Remote Control, displaying all buttons and their layout.

Key Functions:

- **Power Button (⏻):** Turns the TV on or off.
- **Number Buttons (0-9):** Direct channel selection.
- **Volume Control (VOL +/-):** Adjusts the audio volume.
- **Channel Control (CH +/-):** Changes TV channels.
- **Navigation Pad (Up, Down, Left, Right, OK):** Navigates menus and confirms selections.
- **Back Button:** Returns to the previous screen or menu.
- **Exit Button:** Exits the current menu or application.
- **Home Button (⌂):** Accesses the TV's home screen or smart hub.
- **Voice Control Button (Microphone icon):** Activates voice commands (if supported by your TV model).
- **Dedicated App Buttons (Netflix, YouTube, Prime Video, Google Play):** Provides quick access to streaming services.

For specific functions related to your Qilive TV model, refer to your television's user manual.

Maintenance

Cleaning the Remote Control

To maintain the remote control's appearance and functionality, clean it regularly:

- Use a soft, dry cloth to wipe the surface of the remote.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- Do not use harsh chemicals, solvents, or abrasive cleaning agents, as these can damage the remote's finish or internal components.

Battery Replacement

Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type (AAA). Dispose of used batteries responsibly according to local regulations.

Storage

When not in use for extended periods, it is recommended to remove the batteries to prevent leakage and potential damage to the remote control.

Troubleshooting

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly installed batteries. Obstruction between remote and TV. Remote out of range.	Check battery polarity and replace batteries if necessary. Remove any objects blocking the signal path. Ensure you are within effective operating range of the TV.
Buttons not working.	Dirt or debris under buttons. Internal malfunction.	Clean the remote surface. If cleaning does not resolve the issue, the remote may require replacement.
Voice control not working.	TV does not support voice control. Microphone blocked.	Verify your Qilive TV model supports voice control. Ensure the microphone on the remote is not covered.

Specifications

Feature	Detail
Brand	ALLIMITY
Model	Q55QA221B
Compatible Devices	Q55QA2318, Q55QA221B, Q43QA231 (600129953), Q43QA231 (600144096), Q32HA231B
Dimensions (L x W x H)	17 x 5 x 1 cm
Item Weight	59 Grams
Connector Type	Infrared
Special Features	Ergonomic
Batteries Required	Yes (AAA, not included)

Warranty and Support

For any questions regarding your ALLIMITY Voice Remote Control, please refer to the product listing or contact the seller directly. Information regarding specific warranty terms may be available through your point of purchase.
Please note that this remote control is a replacement part and its functionality is dependent on the compatibility with your specific Qilive TV model. Always verify the model numbers before purchase.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question