onerbl B0DNZ32Y9D

onerbl AC Power Cord Instruction Manual

For YOSUDA YSD-SE-Plus 01 & 02 Under Desk Ellipticals

1. Introduction

This manual provides essential information for the safe and effective use of your onerbl AC Power Cord. This power cord is designed as a replacement or spare for YOSUDA YSD-SE-Plus 01 and YSD-SE-Plus 02 Under Desk Ellipticals and Electric Leg Exercisers. Please read these instructions carefully before use and retain them for future reference.

2. Safety Information

- **Electrical Safety:** Always ensure the power outlet is easily accessible and properly grounded.
- **Voltage Compatibility:** This power cord is designed for 100V-240V AC input. Verify that your device and power source are compatible with these specifications.
- **Avoid Damage:** Do not bend, twist, or pull the cord excessively. Avoid placing heavy objects on the cord.
- **Environment:** Use the power cord in dry indoor environments only. Do not expose to water, moisture, or extreme temperatures.
- **Inspection:** Regularly inspect the cord for any signs of damage, such as fraying, cuts, or exposed wires. Discontinue use immediately if damage is found.
- **Unplugging:** Always grasp the plug, not the cord, when disconnecting from the power outlet or device.

3. Package Contents

- 1 x onerbl AC Power Cord

4. Setup

Follow these steps to properly connect your onerbl AC Power Cord:

1. Ensure the YOSUDA YSD-SE-Plus elliptical is turned off and unplugged from any power source.
2. Locate the power input port on your YOSUDA YSD-SE-Plus 01 or 02 Under Desk Elliptical.
3. Insert the device connector end of the onerbl AC Power Cord firmly into the elliptical's power input port.
4. Insert the wall plug end of the onerbl AC Power Cord into a standard 100V-240V AC electrical outlet.
5. Verify that both connections are secure.



Image: The onerbl AC Power Cord, showing its connection to a YOSUDA YSD-SE-Plus elliptical and a power outlet. This illustrates the correct setup procedure for powering the device.

5. Operation

Once the onerbl AC Power Cord is securely connected to both your YOSUDA YSD-SE-Plus elliptical and a power outlet, the elliptical is ready for use. Turn on your elliptical according to its own instruction manual. The power cord facilitates the necessary electrical current for the device to function.

6. Maintenance and Care

- **Cleaning:** Disconnect the power cord from both the elliptical and the power outlet before cleaning. Wipe the cord with a dry, soft cloth. Do not use liquid cleaners or abrasive materials.

- **Storage:** When not in use, store the power cord in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling or kinking the cord.
- **Regular Inspection:** Periodically check the entire length of the cord, including the plugs, for any signs of wear, damage, or overheating.

7. Troubleshooting

Issue: Elliptical does not power on.

- **Check Connections:** Ensure the power cord is firmly plugged into both the elliptical and the wall outlet.
- **Verify Power Outlet:** Test the wall outlet with another device to confirm it is supplying power.
- **Inspect Cord:** Examine the power cord for any visible damage. If damaged, discontinue use and replace.
- **Elliptical Power Switch:** Ensure the power switch on the YOSUDA elliptical itself is in the 'ON' position.

8. Specifications

Brand	onerbl
Model (ASIN)	B0DNZ32Y9D
Compatibility	YOSUDA YSD-SE-Plus 01, YSD-SE-Plus 02 Under Desk Ellipticals
Input Voltage	100V-240V AC
Color	Black
Manufacturer	Shenzhen Waweis Technology Co., Ltd

9. Warranty and Support

For warranty information or technical support regarding your onerbl AC Power Cord, please refer to the purchase documentation or contact the seller directly through the platform where the product was purchased. Ensure you have your order details and product model (ASIN: B0DNZ32Y9D) available when contacting support.

© 2024 onerbl. All rights reserved.