Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl AC Power Cord

onerbl AC Power Cord Replacement for Putnen FZH834 Elliptical Machine

User Manual

1. Introduction

This manual provides essential instructions for the safe and effective use of your onerbl AC Power Cord Replacement. This power cord is specifically designed for compatibility with the Putnen FZH834 Under Desk Elliptical Machine, ensuring reliable power supply for its operation.

2. Product Overview

The onerbl AC Power Cord is a durable replacement cable designed to provide electrical power to your compatible elliptical machine. It features a standard 2-prong US plug on one end and a C7 (figure-8) connector on the other, suitable for various electronic devices requiring this connection type.



Figure 2.1: The onerbl AC Power Cord. This image displays the black power cord in a coiled state, clearly showing the standard two-prong plug for wall outlets and the figure-8 connector for device input.

- **Length:** Approximately 6 feet (1.8 meters)
- **Voltage Compatibility:** 100V-240V AC
- **Color:** Black
- **Connectors:** NEMA 1-15P (US 2-prong male) to IEC C7 (Figure-8 female)

3. Setup Instructions

1. **Identify Power Port:** Locate the power input port on your Putnen FZH834 Under Desk Elliptical Machine. This port typically resembles the figure-8 shape of the cord's female connector.
2. **Connect to Machine:** Firmly insert the figure-8 (female) end of the onerbl AC Power Cord into the corresponding power input port on your elliptical machine. Ensure a snug fit.
3. **Connect to Power Outlet:** Plug the standard 2-prong (male) end of the power cord into a functional 100V-240V AC electrical wall outlet.
4. **Verify Connection:** Confirm that both ends of the power cord are securely connected before attempting to operate the elliptical machine.

4. Operation

Once the power cord is correctly connected to both the elliptical machine and a power outlet, the machine should receive power. Refer to your Putnen FZH834 Elliptical Machine's specific user manual for instructions on how to power on and operate the device. The onerbl AC Power Cord acts solely as a power supply conduit.

5. Maintenance

Proper care of your power cord ensures longevity and safe operation.

- **Storage:** When not in use, coil the power cord loosely. Avoid tight coiling or sharp bends, which can damage the internal wires.
- **Cleaning:** Disconnect the power cord from both the outlet and the device before cleaning. Wipe the cord with a dry, soft cloth. Do not use liquid cleaners or immerse the cord in water.
- **Inspection:** Periodically inspect the cord for any signs of damage, such as cuts, fraying, or exposed wires.

6. Troubleshooting

If your elliptical machine is not receiving power after connecting the cord, consider the following:

- **No Power to Machine:**
  - Ensure both ends of the power cord are fully and securely plugged in.
  - Test the electrical outlet with another device to confirm it is functional.
  - Check your home's circuit breaker or fuse box to ensure the outlet has power.
- **Damaged Cord:** If the power cord shows any signs of physical damage (e.g., cuts, exposed wires, bent prongs), discontinue use immediately and replace it with a new, compatible cord. Do not attempt to repair a damaged power cord.

7. Specifications

Feature	Specification
Product Type	AC Power Cord Replacement
Brand	onerbl
Compatibility	Putnen FZH834 Under Desk Elliptical Machine
Input Voltage	100-240V AC
Cord Length	6 feet (approximately 1.8 meters)
Connector Type (Wall)	NEMA 1-15P (US 2-prong male)

Connector Type (Device)	IEC C7 (Figure-8 female)
Color	Black
Manufacturer	Shenzhen Waweis Technology Co., Ltd

8. Warranty and Support

For specific warranty information or technical support regarding your onerbl AC Power Cord Replacement, please refer to the product packaging or contact the retailer from whom the product was purchased. Keep your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DNZ3G4G9

More documents and user manuals: **https://manuals.plus/**