Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl DS-258

onerbl USB-C Charging Cable for NBONEBS DS-258 Electric Spin Scrubber

User Manual

Introduction

This manual provides essential information for the safe and effective use of your onerbl USB-C charging cable. This cable is specifically designed as a replacement power supply for the NBONEBS DS-258 Electric Spin Scrubber (Model A/ModleA) with 3000mAh or 2600mAh batteries, requiring a DC5V (5VDC, 5V, 5.0V) power input. Please read this manual thoroughly before use.

Setup

1. **Inspect the Cable:** Before first use, carefully inspect the USB-C charging cable for any signs of damage, such as frayed wires or bent connectors. Do not use if damaged.
2. **Identify Ports:** Locate the USB-C charging port on your NBONEBS DS-258 Electric Spin Scrubber. Identify a compatible USB power adapter (not included) with a DC5V output.
3. **Connect to Power Source:** Insert the standard USB-A end of the charging cable into a compatible USB power adapter (e.g., wall charger, computer USB port, power bank). Ensure the power adapter is plugged into a functional power outlet.
4. **Connect to Scrubber:** Insert the USB-C end of the charging cable firmly into the charging port of your NBONEBS DS-258 Electric Spin Scrubber.

Operating

Once properly connected, the NBONEBS DS-258 Electric Spin Scrubber should indicate that it is charging. This is typically shown by an indicator light on the scrubber itself. Refer to your scrubber's manual for specific charging indicators.

- **Charging Time:** Charging time will vary depending on the scrubber's battery capacity (3000mAh or 2600mAh) and the output of your USB power adapter.
- **Optimal Charging:** For optimal battery life, avoid fully discharging the scrubber's battery frequently. Charge the device when the battery level is low.
- **Disconnecting:** Once the scrubber is fully charged, or if you need to stop charging, gently pull the USB-C connector straight out from the scrubber's port. Then, disconnect the USB-A end from the power adapter.

Maintenance

- **Cleaning:** Keep the cable clean and free from dust and debris. Use a soft, dry cloth to wipe the cable and connectors. Do not use liquid cleaners.
- **Storage:** When not in use, store the cable in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling or bending the cable sharply, as this can damage the internal wires.
- **Handling:** Always grasp the connector ends when plugging or unplugging the cable. Do not pull on the cable itself, as this can cause damage.

Troubleshooting

- **Scrubber Not Charging:**
  - Ensure both ends of the cable are securely connected.
  - Try a different USB power adapter or a different power outlet.
  - Check the scrubber's charging port for any obstructions or damage.
  - Verify that the USB power adapter provides DC5V output.
- **Slow Charging:**
  - Ensure your USB power adapter provides sufficient current (amperage) for faster charging.
  - Avoid using the scrubber while it is charging, as this can slow down the process.
- **Cable Damage:** If the cable shows any signs of physical damage (e.g., cuts, exposed wires, bent connectors), discontinue use immediately to prevent potential hazards.

Specifications

Brand	onerbl
Connector Type	USB-A to USB-C
Cable Type	USB
Compatible Devices	NBONEBS DS-258 DS258 Modle A ModleA Electric Spin Scrubber Cordless Cleaning Brush (3000mAh, 2600mAh Barrety)
Power Input Requirement	DC5V / 5VDC / 5V / 5.0V
Special Feature	Fast Charging (dependent on power adapter)
Color	Black
Connector Gender	Male-to-Female

Warranty and Support

For warranty information or technical support regarding your onerbl USB-C charging cable, please refer to the documentation provided with your purchase or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.
Manufacturer: Shenzhen Waweis Technology Co., Ltd

© 2024 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DNZ3JKZW

More documents and user manuals: **https://manuals.plus/**