Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl AC-DC Adapter

onerbl AC-DC Adapter User Manual for VTOMAN X1 JS-211 Jump Starter

1. Introduction

This manual provides essential information for the safe and efficient use of your onerbl AC-DC Adapter. This adapter is specifically designed as a replacement power supply for the **VTOMAN X1 JS-211 JS211 Jump Starter with Air Compressor 2500A Portable Battery Booster**. It converts standard AC wall power into the DC power required to charge your jump starter.

The adapter is manufactured with high-quality materials and tested to ensure compatibility and reliable performance with your device. It features an input range of AC 100-240V, making it suitable for worldwide use.



Image 1.1: The onerbl AC-DC Adapter. This image displays the compact design of the adapter, typically featuring a power brick with a barrel connector cable for connecting to the jump starter and a standard AC plug for wall outlets.

2. Safety Instructions

Please read and understand all safety instructions before using the adapter. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Use the adapter only with the specified**VTOMAN X1 JS-211 JS211 Jump Starter**. Using it with incompatible devices may cause damage or safety hazards.
- Do not expose the adapter to water, rain, or excessive moisture.
- Do not operate the adapter if it has been damaged in any way (e.g., frayed cord, cracked casing).
- Ensure the power outlet voltage matches the adapter's input specifications (AC 100-240V).
- Unplug the adapter from the power outlet when not in use or during electrical storms.
- Do not disassemble or attempt to repair the adapter yourself. Refer all servicing to qualified personnel.
- Keep the adapter away from heat sources and direct sunlight.
- This adapter features **Short Circuit Protection** to enhance safety during operation.

3. Package Contents

Verify that all items are present in your package:

- 1 x onerbl AC-DC Adapter (with integrated power cord and barrel connector)

4. Setup

Follow these steps to set up your AC-DC adapter for charging:

1. Locate the charging port on your **VTOMAN X1 JS-211 Jump Starter**. This is typically a DC input port.
2. Connect the barrel connector of the onerbl AC-DC Adapter firmly into the charging port of the jump starter.
3. Plug the AC power cord of the adapter into a standard wall electrical outlet (AC 100-240V).
4. Ensure all connections are secure before proceeding.

5. Operating Instructions

Once the adapter is properly connected, the jump starter should begin charging. Refer to your jump starter's own manual for specific charging indicators (e.g., LED lights, display screens).

- Allow the jump starter to charge fully before its first use or after extended periods of non-use.
- Disconnect the adapter from the jump starter and the wall outlet once charging is complete.
- **Important Note on Battery Life:** Rechargeable batteries have a finite lifespan, typically 1 to 3 years. If the jump starter's internal battery is damaged or has reached the end of its life cycle, it may not accept a charge, even with a functional adapter. This is a characteristic of the jump starter's battery, not an issue with the onerbl AC-DC Adapter.

6. Maintenance

Proper care will extend the life of your adapter:

- Keep the adapter clean and dry. Wipe with a soft, dry cloth if necessary.
- Store the adapter in a cool, dry place when not in use.
- Avoid bending or crimping the power cord excessively.
- Regularly inspect the adapter and its cables for any signs of damage.

7. Troubleshooting

Problem	Possible Cause	Solution
Jump starter is not charging.	◦ Adapter not properly connected. ◦ Power outlet is not active. ◦ Jump starter's battery is damaged or at end of life. ◦ Adapter is faulty.	◦ Ensure adapter is securely plugged into both the jump starter and the wall outlet. ◦ Test the wall outlet with another device. ◦ As noted in Section 5, if the jump starter's battery is old or damaged, it may not accept a charge. This is not an adapter fault. ◦ If other solutions fail, contact customer support.

Problem	Possible Cause	Solution
Adapter feels unusually hot.	◦ Normal operation (slight warmth). ◦ Overload or internal fault.	◦ A slight warmth is normal during charging. ◦ If it's excessively hot, unplug immediately and discontinue use. Contact customer support.

8. Specifications

Brand	onerbl
Input Voltage	AC 100-240V, 50/61Hz (Worldwide AC Input)
Output Voltage/Current	DC 5V 2A (5VDC 2000mA, 5.0V 2.0A)
Connector Type	Barrel Connector
Compatible Devices	VTOMAN X1 JS-211 JS211 Jump Starter with Air Compressor 2500A Portable Battery Booster
Special Feature	Short Circuit Protection
Color	Black
Manufacturer	Shenzhen Waweis Technology Co., Ltd

9. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the retailer/manufacturer directly. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DNZ3SR5M

More documents and user manuals: **https://manuals.plus/**