Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Mova K30 (HMH14A)

Mova K30 Wet and Dry Vacuum Cleaner Instruction Manual

Model: K30 (HMH14A)

Brand: Mova

1. Introduction

The Mova K30 is an advanced wet and dry vacuum cleaner designed to provide a comprehensive cleaning solution for your floors. It combines powerful suction with innovative features to tackle both wet and dry messes efficiently. Its lightweight design and intelligent functions make floor cleaning less strenuous and more effective.

2. Important Safety Instructions

Please read all instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- This appliance is for household use only. Do not use it for commercial or industrial purposes.
- Always ensure the power adapter is compatible with your local voltage before plugging in.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Unplug the appliance from the power outlet before cleaning, maintenance, or when not in use.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with a damaged cord or plug. If the appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Close supervision is necessary when any appliance is used by or near children.

3. Package Contents

Carefully unpack your Mova K30 and check that all items are present and in good condition. If any items are missing or damaged, please contact customer support.



Image: All components included in the Mova K30 box, laid out for clear identification.

- Main Unit x1
- Handle x1
- Replacement Roller Brush x1
- Replacement Filter x1
- Charging Base x1
- Cleaning Brush x1
- Detergent Solution x1

4. Product Components

Familiarize yourself with the different parts of your Mova K30 vacuum cleaner.



Image: The Mova K30 wet and dry vacuum cleaner in its upright position, showcasing its sleek design.

- **Handle:** Ergonomically designed for comfortable grip and control.
- **Clean Water Tank:** Holds clean water and detergent solution for washing floors.
- **Dirty Water Tank:** Collects dirty water and debris after cleaning.
- **Roller Brush:** The primary cleaning component that scrubs and washes the floor.
- **Main Body:** Contains the motor, battery, and control panel.
- **Charging Base:** Used for charging the vacuum cleaner and performing self-cleaning.

5. Setup and First Use

Follow these steps to prepare your Mova K30 for its first use.

1. **Assembly:** Insert the handle into the main unit until it clicks into place. Ensure both the clean and dirty water tanks are securely installed.
2. **Charging:** Place the main unit onto the charging base. Connect the power adapter to the charging base and a power outlet. The indicator lights will show the charging status. A full charge takes approximately 4-5 hours.
3. **Filling the Clean Water Tank:** Remove the clean water tank. Fill it with clean tap water up to the MAX line. For enhanced cleaning, add a small amount of the provided detergent solution according to the instructions on the bottle. Reinstall the tank securely.

6. Operation

The Mova K30 offers various cleaning modes and features for optimal performance.



Image: The Mova K30 demonstrating its powerful 18000 Pa suction, effectively cleaning both wet and dry debris.

Powering On/Off

Press the Power button on the handle to turn the appliance on or off.

Cleaning Modes



Image: Visual representation of the different cleaning modes available on the Mova K30: Automatic, Ultra, Suction, and Turbo.

- **Automatic Mode:** The vacuum cleaner intelligently adjusts suction power based on the detected dirt level. Ideal for daily cleaning.
- **Ultra Mode:** Provides maximum suction and water flow for heavily soiled areas.
- **Suction Mode:** Primarily for vacuuming dry debris without dispensing water.
- **Turbo Mode:** Offers a burst of high power for stubborn stains.

Special Features



Image: The Mova K30 demonstrating its 180° flat design, allowing it to reach under low furniture for thorough cleaning.

- **180° Flat Design:** The unique design allows the main unit to lay almost flat, enabling easy access under furniture and other low-clearance areas.
- **Dual-Sided Edge Cleaning:** The roller brush extends to both sides, ensuring thorough cleaning along baseboards and in corners, leaving no gaps.



Image: The Mova K30 cleaning along the edge of a wall, highlighting its dual-sided brush for complete edge-to-edge cleaning.

- **Intelligent Suction Adjustment:** The K30 automatically detects the level of dirt and adjusts suction power accordingly, optimizing cleaning efficiency and battery life.

7. Maintenance

Regular maintenance ensures the longevity and optimal performance of your Mova K30.

Self-Cleaning Function



Image: An illustration showing the Mova K30's self-cleaning process, including hot air drying and dual-rotation brush cleaning.

After each use, place the vacuum cleaner on its charging base and press the self-cleaning button. The K30 will automatically clean the roller brush and internal pipes. This process includes:

- **One-Button Self-Cleaning:** Initiates the cleaning cycle with a single press.
- **Hot Air Drying (60°C):** After cleaning, the brush is dried with 60°C hot air for 30 minutes to prevent odors and mildew.
- **Dual-Rotation Brush Cleaning:** The brush rotates back and forth, simulating manual scrubbing to remove tangled hair and stubborn dirt.

Cleaning Water Tanks and Filter

- **Dirty Water Tank:** Empty and rinse the dirty water tank after each use. Ensure no debris remains.
- **Clean Water Tank:** Empty any remaining clean water if the appliance will not be used for an extended period.
- **HEPA Filter:** Remove and rinse the HEPA filter regularly (e.g., once a week or as needed). Allow it to air dry completely before reinstalling. Do not use the appliance without a dry filter.

8. Troubleshooting

If you encounter any issues with your Mova K30, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Appliance does not turn on.	Battery is low or depleted.	Charge the appliance fully.
Poor suction.	Dirty water tank is full, filter is clogged, or roller brush is tangled.	Empty dirty water tank. Clean or replace HEPA filter. Clean roller brush.
Water leakage.	Water tanks not installed correctly or damaged.	Ensure tanks are securely latched. Check for cracks or damage.
Unpleasant odor from brush.	Brush not dried properly after use.	Perform self-cleaning with hot air drying. Ensure brush is completely dry before storage.

If the problem persists after trying these solutions, please contact Mova customer support.

9. Specifications

Detailed technical specifications for the Mova K30 Wet and Dry Vacuum Cleaner.

Feature	Specification
Brand	Mova
Model	HMH14A (K30)
Color	White
Product Dimensions	22.5 x 25 x 110 cm
Weight	3.9 kg
Clean Water Tank Capacity	1100 Milliliters
Wattage	300 watts
Noise Level	76 dB
Runtime	Up to 30 minutes
Special Features	Cordless, HEPA Filter, Spotless Cleaning, Rechargeable, Wet/Dry Function
Filter Type	HEPA Filter

10. Warranty and Support

Mova is committed to providing innovative smart home appliances and excellent customer service.
The Mova K30 comes with a **3-year reliable quality warranty**. For warranty claims, technical support, or any inquiries, please refer to the contact information provided in your product packaging or visit the official Mova store online.
Visit the Mova Store for more information and product updates.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DP37MXYN

More documents and user manuals: **https://manuals.plus/**