Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ODK B0DP4K6B8Z

ODK Adult Bedroom Dresser User Manual

Model: B0DP4K6B8Z
Brand: ODK

1. Introduction

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your ODK Adult Bedroom Dresser. This dresser features adjustable 10-color LED strips, integrated charging capabilities with 2 USB ports and 2 standard power outlets, and 8 large fabric drawers for organized storage. Please read this manual thoroughly before assembly and use to ensure proper function and safety.



Figure 1: ODK Adult Bedroom Dresser with LED lighting and integrated power strip.

2. Safety Information

- Always follow the assembly instructions carefully. Incorrect assembly can lead to instability and potential injury.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten if necessary.
- Install the anti-tip anchors provided to prevent the dresser from tipping over, especially in households with children or pets.
- Do not overload drawers. Distribute weight evenly to maintain stability.
- Keep electrical components (LEDs, power strip) away from water and moisture.
- Use only the provided power cord and ensure it is not pinched or damaged.



Figure 2: Illustration of the dresser's stability features, including the anti-tip kit, X-shaped crossbar, and adjustable feet.

3. Package Contents

Before beginning assembly, verify that all parts listed below are present and undamaged. Each component is typically labeled with letters and numbers for easy identification.

- Top wooden board
- Metal frame components
- 8 Fabric drawers (various sizes)
- Integrated power strip with 2 USB ports and 2 power outlets
- LED light strip with controller
- Adjustable feet
- Anti-tip kit
- Assembly hardware (screws, bolts, Allen wrench)
- Instruction manual

4. Setup and Assembly

Assembly is designed to be straightforward, with each part clearly marked. It is recommended to assemble the dresser on a soft, clean surface to prevent scratches.

1. **Unpack and Identify Parts:** Lay out all components and hardware. Match them with the parts list in the separate assembly guide.
2. **Assemble the Metal Frame:** Connect the metal frame components according to the numbered steps in the assembly guide. Ensure all connections are secure. The X-shaped crossbar at the back enhances structural stability.
3. **Attach the Top Board:** Secure the wooden top board to the assembled metal frame using the provided screws.
4. **Install Adjustable Feet:** Screw the adjustable feet into the bottom of the frame. Adjust them to level the dresser on uneven surfaces.
5. **Install Power Strip and LED Lights:** Integrate the power strip and LED light strip into their designated slots on the dresser. Connect the power cord.
6. **Assemble Fabric Drawers:** Construct the fabric drawers by inserting the bottom panels and handles. The drawers are

made from a durable cationic fabric with MDF panels for structure.

7. **Insert Drawers:** Place the assembled fabric drawers into their respective compartments.
8. **Install Anti-Tip Anchors:** Secure the dresser to the wall using the anti-tip kit provided. This is a critical safety step.



Figure 3: Diagram illustrating the overall product dimensions and individual drawer sizes for assembly reference.



Figure 4: Exploded view showing the construction of the fabric drawers, including the plastic handle, non-woven fabric, MDF panel, and double screws for durability.

5. Operating Instructions

5.1. LED Lighting System

The integrated LED strip offers customizable lighting to enhance your room's ambiance.

- **Power On/Off:** Use the inline controller to turn the LED lights on or off.
- **Color Selection:** Choose from 10 adjustable colors to match your mood or decor.
- **Dynamic Modes:** Select from 10 dynamic modes for various lighting effects.
- **Brightness Adjustment:** Adjust the light intensity with 7 brightness settings.
- **Memory Function:** The LED system retains your last selected settings when powered off and on.



Figure 5: Detailed view of the LED light strip and its control panel, showing options for color, mode, and brightness adjustments.

5.2. Integrated Charging Station

The dresser includes a convenient power strip for charging electronic devices.

- **Power Outlets:** Two standard European power outlets (220-250V/15A) are available for larger electronics.
- **USB Ports:** Two USB ports (5V/2A) are provided for charging smartphones, tablets, and other USB-powered devices.
- **Power Cord:** Ensure the dresser's main power cord (150cm length) is securely plugged into a wall outlet.



Figure 6: Close-up view of the integrated power strip, highlighting the two standard power outlets and two USB charging ports.

6. Maintenance

- **Cleaning the Wooden Top:** Wipe the wooden surface with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Cleaning Fabric Drawers:** The cationic fabric drawers are wear-resistant. For light cleaning, use a lint roller or a soft brush. For stains, gently spot clean with a mild detergent and a damp cloth, then air dry. Do not machine wash.
- **Frame Care:** Wipe the metal frame with a damp cloth. Ensure it is dry to prevent rust.
- **Electrical Components:** Keep the power strip and LED lights free from dust. Do not attempt to clean with liquids while plugged in.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight.

7. Troubleshooting

Problem	Possible Cause	Solution
LED lights do not turn on.	Power cord not plugged in; loose connection; faulty LED strip.	Ensure the main power cord is securely plugged into a working wall outlet. Check connections of the LED strip to the power source and controller. If issues persist, contact support.
Charging ports (USB/Outlets) are not working.	Power cord not plugged in; power strip switch off; device cable faulty.	Verify the main power cord is connected. Ensure the power strip is switched on (if applicable). Test with a different device or cable.
Dresser feels unstable or wobbly.	Loose screws; uneven floor; anti-tip kit not installed.	Check and tighten all assembly screws. Adjust the leveling feet to compensate for uneven floors. Ensure the anti-tip kit is properly installed and secured to the wall.
Drawers are difficult to open/close.	Overloaded drawer; misaligned drawer; foreign object.	Reduce the weight in the drawer. Ensure the drawer is inserted correctly and not obstructed. Check for any items caught in the drawer mechanism.

8. Specifications

- **Model:** B0DP4K6B8Z
- **Dimensions (L x W x H):** 110 cm x 30 cm x 89 cm (43.3 x 11.8 x 35 inches)
- **Weight:** Approximately 15.6 kg (34.4 lbs)
- **Material:** Wooden top, Steel frame, Cationic fabric drawers, MDF panels
- **Drawers:** 8 large fabric drawers
- **LED Lighting:** 10 adjustable colors, 10 dynamic modes, 7 brightness levels, Memory function
- **Power Outlets:** 2 x European Standard (220-250V/15A)
- **USB Ports:** 2 x USB (5V/2A)
- **Power Cord Length:** 150 cm
- **Stability Features:** X-shaped crossbar, Adjustable feet, Anti-tip anchors

9. Warranty and Support

ODK provides a 30-day free trial period for this product. For any questions, concerns, or assistance with assembly or operation, please contact ODK customer support. Our professional online service team is available 24 hours a day to resolve any issues you may encounter.

Please refer to your purchase documentation for specific warranty details and contact information.

© 2025 ODK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DP4K6B8Z

More documents and user manuals: **https://manuals.plus/**