Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY ARC802N YUI1

ALLIMITY ARC802N YUI1 Replacement Remote Control Instruction Manual

1. Introduction

This manual provides essential information for the proper use and maintenance of your ALLIMITY ARC802N YUI1 replacement remote control. Please read these instructions carefully before use.

Package Contents:

- 1 x ALLIMITY ARC802N YUI1 Replacement Remote Control

Compatibility:

This remote control is compatible with various TCL TV models, including but not limited to:

- ARC802N YU14
- 06-IRPT45-URC802NP
- 06-IRPT45-ARC802NP
- 40S6800FS
- 49C2US
- U65S9906
- 75C2US
- 43P20US
- 32S6500
- 55C2US
- 32S6800S
- 32ES568
- 65C2US
- 49S6500
- 40S6500
- 43S6500

2. Setup

Battery Installation:

1. Open the battery compartment cover on the back of the remote control.
2. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals match the indicators

inside the compartment.

3. Close the battery compartment cover securely.

First Use:

The remote control operates using infrared (IR) technology. For optimal performance:

- Point the remote control directly towards the IR sensor on your TCL TV.
- Ensure there are no obstacles between the remote control and the TV sensor.
- The remote does not require any programming or pairing for compatible TCL TV models.





Figure 1: Front view of the ALLIMITY ARC802N YUI1 replacement remote control. This image displays the front of the remote control, showing all buttons clearly arranged. The remote is black with grey and red buttons, including a prominent red Netflix button at the bottom.

3. Operating Instructions

Familiarize yourself with the buttons and their functions:



Figure 2: Angled view of the ALLIMITY ARC802N YUI1 replacement remote control. This angled perspective highlights the ergonomic shape and button layout from a side-front view, illustrating the remote's physical design.

Button	Function
(Mute)	Mutes or unmutes the TV audio.
(Power)	Turns the TV on or off.
0-9	Direct channel selection.
LIST	Displays the channel list or other relevant lists.
⚙ (Settings)	Accesses the TV's settings menu.
↶ (Back)	Returns to the previous screen or menu.
VOL +/-	Adjusts the volume level.
CH +/-	Changes the TV channel.
(Home)	Accesses the TV's home screen or smart TV interface.
OK	Confirms a selection or enters a menu.
▲ ▼ ◀ ▶ (Navigation Arrows)	Navigates through menus and options.
EXIT	Exits the current menu or application.
GUIDE	Displays the electronic program guide (EPG).
TEXT	Activates or deactivates Teletext.
SUBT.	Toggles subtitles on or off.
CLANG	Changes the audio language.
Red, Green, Yellow, Blue Buttons	Context-sensitive functions within menus or applications.
◀◀ (Rewind)	Rewinds media playback.
▮▮ (Play/Pause)	Plays or pauses media playback.
▶▶ (Fast Forward)	Fast forwards media playback.
ZOOM	Adjusts the screen zoom level.
NETFLIX	Direct access to the Netflix application.

4. Maintenance

Cleaning:

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these may damage the surface or internal components.

Storage:

Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage.

Battery Replacement:

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries with

new ones of the same type (AAA).

5. Troubleshooting

Remote Control Not Responding:

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity and are not depleted. Replace with fresh batteries if necessary.
- **Line of Sight:** Verify that there are no obstructions between the remote control and the TV's IR sensor.
- **TV Sensor:** Ensure the TV's IR sensor is clean and not blocked.
- **Distance:** Make sure you are within the effective operating range of the remote control.

Limited Functionality:

- Confirm that your TV model is listed as compatible in the 'Introduction' section. While this remote is broadly compatible, some specific TV models or functions may vary.

6. Specifications

Feature	Detail
Brand	ALLIMITY
Model Number	ARC802N YUI1
Product Dimensions	5 x 1 x 0.5 inches
Item Weight	1 ounces
Special Feature	Ergonomic
Color	Black
Max Number of Supported Devices	1 (Television)
Compatible Devices	Television

7. Support

If you encounter any issues not covered in this manual or require further assistance, please contact the seller directly through your purchase platform. Provide your product model number and a detailed description of the issue for efficient support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DP5Z8FPT

More documents and user manuals: **https://manuals.plus/**