Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YHFTAJX B0DP6SK4JF

YHFTAJX Portable Vacuum Sealer User Manual

Model: B0DP6SK4JF | Brand: YHFTAJX

1. Introduction

Thank you for choosing the YHFTAJX Portable Vacuum Sealer. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new vacuum packaging machine. Please read this manual thoroughly before using the product and retain it for future reference.
This compact and wireless handheld vacuum sealer is designed for convenient food preservation and other vacuum sealing needs. Its portable design makes it easy to store and carry, offering strong suction and multiple operating modes for various applications.

2. Safety Instructions

- Read all instructions before use.
- Keep the appliance out of reach of children.
- Do not immerse the appliance in water or any other liquid.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only manufacturer-recommended accessories.
- Do not use the appliance outdoors.
- Unplug from outlet when not in use and before cleaning.
- Avoid contact with moving parts.
- This appliance is for household use only.

3. Product Overview

3.1 Components

The YHFTAJX Portable Vacuum Sealer features a streamlined design with intuitive controls.



Figure 3.1: Front view of the vacuum sealer with digital display and buttons.

This image displays the main unit of the YHFTAJX Portable Vacuum Sealer in beige. The digital display is visible on the left, along with four control buttons labeled 'Poweron/Temperature', 'Vacuum seal', 'Seal it', and 'Point pumping'. The overall design is compact and elongated.




Figure 3.2: Key features including charging port and external connector.

This image highlights three key features: (01) The Type-C charging port for convenient power, (02) The replacement outer joint (external connector) for non-vacuum applications, and (03) The bag clip design ensuring accurate positioning for vacuum bags.

3.2 Features

- **Compact and Portable:** Small size, easy to store and carry, ideal for various kitchen sizes and travel.
- **Wireless Handheld Design:** Offers greater convenience and flexibility, eliminating the need for direct power connection during operation.
- **Versatile Compatibility:** Suitable for a variety of fresh-keeping bags.
- **Simple One-Button Operation:** Easy to use with a single button start.
- **Strong Suction:** Ensures efficient air removal for optimal preservation.
- **Three Adjustable Modes:** Provides flexibility for different sealing needs.
- **Multi-purpose External Connector:** Can be used to inflate items like basketballs and swimming rings after replacing the external connector.

4. Setup

4.1 Initial Charging

Before first use, fully charge the vacuum sealer. Connect the provided Type-C charging cable to the charging port on the device and plug the other end into a compatible USB power adapter (not included). The digital display may indicate charging status. A full charge can provide power for approximately 5-6 months of normal use.




Figure 4.1: Connecting the Type-C charging cable.

This image shows a close-up of the vacuum sealer's Type-C charging port with a white charging cable inserted, illustrating the charging process.

4.2 Preparing for Use

Ensure the sealing area is clean and free of debris before each use. For vacuum sealing, use compatible vacuum sealer bags.

5. Operating Instructions

5.1 Control Buttons

- **Poweron/Temperature:** Press to power on the device. This button may also be used to adjust temperature settings for sealing, depending on the mode.
- **Vacuum seal:** Initiates the vacuuming process followed by sealing.
- **Seal it:** Initiates the sealing process without vacuuming. Useful for sealing bags that do not require vacuuming.
- **Point pumping:** Likely for controlled or partial vacuuming, allowing for manual control over the vacuum level.

5.2 Vacuum Sealing Bags

1. Place the item to be sealed inside a compatible vacuum sealer bag. Ensure there is enough space (at least 2-3 inches) between the item and the top edge of the bag for proper sealing.
2. Lay the open end of the bag flat into the sealing channel of the vacuum sealer. Ensure the bag is positioned correctly over the sealing bar and within the vacuum chamber (if applicable). The bag clip design helps with accurate positioning.
3. Close the lid or press down firmly on the top of the sealer to engage the sealing mechanism.
4. Press the "Vacuum seal" button. The machine will automatically remove air from the bag and then seal it.
5. Once the process is complete, the indicator light will change, or the machine will stop. Open the lid and remove the sealed bag.



Figure 5.1: Sealing meat for preservation.

This image shows the YHFTAJX Portable Vacuum Sealer in action, sealing a bag containing a cut of meat. The user's finger is near the control buttons, indicating active operation.



Figure 5.2: Sealing pastries to maintain freshness.

The image depicts the vacuum sealer being used to seal a bag filled with pastries, demonstrating its versatility for various food items.

Figure 5.3: Sealing dry goods like beans.

This image shows the vacuum sealer sealing a bag of beans, highlighting its use for dry food items.

5.3 Using the External Connector (Inflation)

The vacuum sealer comes with an external connector that allows it to be used for inflation purposes, such as inflating basketballs or swimming rings.

1. Locate the external connector port on the side of the vacuum sealer.
2. Attach the appropriate inflation nozzle (e.g., for basketballs or swimming rings) to the external connector.
3. Insert the nozzle into the item you wish to inflate.
4. Press the relevant button (e.g., "Poweron" or a specific inflation mode if available) to begin inflation.




Figure 5.4: External connector for inflation.

This image details the external connector accessory, which can be attached to the vacuum sealer for purposes other than vacuuming, such as inflating items.

5.4 Three Adjustable Modes

The device offers three adjustable modes to cater to different sealing requirements. While specific details for each mode are not provided, these typically include:

- **Dry Mode:** For solid items without moisture.
- **Moist Mode:** For items with some moisture, requiring a stronger seal.
- **Seal Only Mode:** For sealing bags without vacuuming.

Refer to the digital display and button labels for mode selection and confirmation.

6. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your vacuum sealer.

6.1 Cleaning the Sealing Bar

After each use, especially if sealing moist items, inspect the sealing bar and surrounding area for any food residue or moisture. Wipe clean with a damp cloth. Ensure the sealing bar is dry before storing or next use.

6.2 General Cleaning

Wipe the exterior of the appliance with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water. Ensure the appliance is completely dry before storage.

7. Troubleshooting

If you encounter issues with your vacuum sealer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Machine does not power on.	Battery is low or depleted.	Charge the device fully using the Type-C cable.
Bag is not vacuuming properly.	Bag not positioned correctly; Bag is damaged; Sealing area is dirty.	Reposition the bag, ensuring it is flat and within the sealing channel. Check bag for holes or tears. Clean the sealing area.
Bag is not sealing.	Sealing bar is dirty or wet; Incorrect mode selected.	Clean and dry the sealing bar. Ensure the correct sealing mode is selected for the bag type.
Vacuum is weak.	Battery is low; Air leakage from bag or seal.	Charge the device. Check the bag for proper placement and integrity.

If the problem persists after attempting these solutions, please contact customer service for further assistance.

8. Specifications

The following are the technical specifications for the YHFTAJX Portable Vacuum Sealer (Model: B0DP6SK4JF):

Attribute	Value
Brand	YHFTAJX
Model	B0DP6SK4JF
Material	ABS
Color	Beige
Item Weight	0.34 Kilograms (12 ounces)
Power Source	Hand Powered (Rechargeable)
Voltage	5 Volts
UPC	709347998512

Attribute	Value
Package Dimensions	6.46 x 2.2 x 1.69 inches
First Available Date	November 28, 2024



Figure 8.1: Product Dimensions.

This image provides a visual representation of the vacuum sealer's dimensions, indicating a length of 164mm, a height of 56mm, and a width of 43mm.

9. Warranty and Support

While specific warranty details are not provided in this manual, YHFTAJX is committed to customer satisfaction. If you have any questions, concerns, or require technical support regarding your Portable Vacuum Sealer, please contact the seller or YHFTAJX customer service as soon as possible. They will reply to you as soon as possible to address your inquiries.

For the most up-to-date warranty information and support options, please refer to the product listing on Amazon or contact the seller directly through your Amazon order history.

© 2024 YHFTAJX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DP6SMWD9

More documents and user manuals: **https://manuals.plus/**