Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE RMF-TX310E

User Manual

XINFUTE RMF-TX310E Replacement Remote Control

Product Overview

The XINFUTE RMF-TX310E is a high-quality replacement remote control designed for various Sony Bravia TV models. It is constructed from durable ABS material and offers both infrared and Bluetooth connectivity, including voice search functionality for enhanced user experience. This remote is a direct replacement and functions identically to the original unit.

Compatible Sony TV Models: XBR-43X800G, XBR-49X800G, XBR-49X900F, XBR-55X800G, XBR-65X900F, XBR-65X800G, XBR-75X900F, XBR-75X800G, XBR-85X900F, KD-43XF7596, KD-43XF8096.



Figure 1: Front view of the XINFUTE RMF-TX310E replacement remote control, showing all buttons including dedicated Google Play and Netflix buttons, and the voice search microphone button.

Setup and Installation

This remote control requires two AA batteries for operation. Batteries are not included with the purchase.

1. **Open the Battery Compartment:** Locate the battery cover on the back of the remote control. Gently slide the cover downwards to open it.



Figure 2: View of the remote control with the battery compartment open, showing slots for two AA batteries.

2. **Insert Batteries:** Insert two AA batteries into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
3. **Close the Battery Compartment:** Slide the battery cover back into place until it clicks securely.
4. **Initial Pairing (for Voice/Bluetooth features):** For voice control and other Bluetooth functionalities, your TV may require initial pairing. Refer to your Sony Bravia TV's user manual for specific instructions on pairing a new remote control via Bluetooth. Typically, this involves navigating to the TV's settings menu (e.g., "Settings" > "Remote & Accessories" > "Bluetooth settings" or "Add device") and following the on-screen prompts.

Operating Instructions

The RMF-TX310E remote control is designed to replicate the functionality of your original Sony Bravia TV remote. Most buttons will function intuitively.

- **Power Button:** Located at the top right (green button), press to turn the TV on or off.
- **Voice Search Button:** Located at the top center (microphone icon), press and hold to activate voice commands for searching content or controlling your TV. Ensure the remote is paired via Bluetooth for this feature to work.
- **Navigation Pad:** Use the circular pad with directional arrows (Up, Down, Left, Right) and the central "Enter" button to navigate menus and select options.
- **Back Button:** Returns to the previous screen or menu.
- **Home Button:** Accesses the TV's main home screen or smart TV interface.
- **Volume +/-:** Adjusts the TV volume.
- **Channel +/-:** Changes TV channels.
- **Dedicated App Buttons:** Includes direct access buttons for popular streaming services like Google Play and Netflix.
- **Numeric Keypad:** For direct channel input or other numerical entries.



Figure 3: Angled view of the remote control, highlighting the ergonomic design and button layout for easy access.

Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control regularly with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's responsiveness decreases or it stops functioning. Always replace both batteries at the same time with new AA batteries. Do not mix old and new batteries, or different types of batteries.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.

- **Avoid Drops:** Protect the remote from physical impact. Dropping the remote can damage internal components or the casing.

Troubleshooting

Problem	Possible Cause / Solution
Remote not responding.	• **Batteries:** Check if batteries are inserted correctly. Replace with new AA batteries. • **Line of Sight:** Ensure there are no obstructions between the remote and the TV's IR sensor. • **Distance:** Make sure you are within the effective range of the TV.
Voice control not working.	• **Bluetooth Pairing:** The remote needs to be paired with your TV via Bluetooth for voice functionality. Refer to the "Setup and Installation" section for pairing instructions. • **Microphone:** Ensure nothing is obstructing the microphone on the remote.
Buttons are sticky or unresponsive.	• **Dirt/Debris:** Clean the remote surface and around the buttons with a soft, slightly damp cloth. • **Battery Corrosion:** Check the battery compartment for any signs of corrosion. Clean with a cotton swab dipped in rubbing alcohol if present.

Specifications

- **Model:** RMF-TX310E
- **Brand:** XINFUTE
- **Material:** ABS
- **Connectivity:** Infrared (IR), Bluetooth
- **Special Features:** Ergonomic design, Voice Search capability
- **Power Source:** 2 x AA Batteries (not included)
- **Product Dimensions:** 6 x 3 x 1 inches (approximately)
- **Item Weight:** 2.82 ounces
- **Compatible Devices:** Sony Bravia Televisions
- **Max Number of Supported Devices:** 1

Warranty and Support

The XINFUTE RMF-TX310E remote control comes with a **one-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as described.
All products are inspected before shipment. If you are not satisfied with your purchase, please contact the seller within 24 hours of receipt. For warranty claims or technical support, please refer to the seller's contact information provided at the time of purchase or visit the official XINFUTE store on Amazon: XINFUTE Store.

© 2024 XINFUTE. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DPCC48Z3

More documents and user manuals: **https://manuals.plus/**