Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY CV-AKB76045005-MR24GA-SH

User Manual

ALLIMITY AKB76045005 MR24GA Voice Replaced Remote Control

Model: CV-AKB76045005-MR24GA-SH

Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your ALLIMITY AKB76045005 MR24GA Voice Replaced Remote Control. This remote is designed as a replacement for specific LG TV models, offering voice control capabilities.

Package Contents

- 1 x ALLIMITY AKB76045005 MR24GA Voice Replaced Remote Control
- *Note: Batteries are not included.*

Setup

1. Battery Installation

The remote control requires two (2) 1.5V AA batteries for operation. Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two 1.5V AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Figure 1: Battery compartment with cover removed.

2. Pairing with Your LG TV

This replacement remote control requires pairing with your LG TV before full functionality, especially for voice control and pointer features, can be utilized. Refer to your LG TV's user manual for specific pairing instructions, as the process may vary slightly by TV model. Generally, the pairing process involves:

- Ensure your TV is powered on.
- Point the remote control towards the TV.
- Press and hold the **HOME** button and the **BACK** button simultaneously for approximately 5 seconds until the LED indicator on the remote blinks.
- A message should appear on your TV screen indicating successful pairing.







Figure 2: Remote control with emphasis on voice control functionality.

Operating Instructions

The ALLIMITY AKB76045005 MR24GA remote control provides comprehensive control over your compatible LG TV. Below are the primary functions of key buttons:





Figure 3: Overview of the remote control buttons.

- **Power Button** ( ): Turns the TV on or off.
- **Number Pad (0-9)**: Directly input channel numbers or other numerical data.
- **GUIDE Button**: Access the electronic program guide.
- **LIST Button**: Display a list of channels or inputs.
- **QUICK ACCESS Button**: Provides quick access to frequently used apps or functions.
- **AD/SAP Button**: Access audio description or secondary audio program options.
- **Volume Up/Down (+/-)**: Adjust the TV volume.
- **Mute Button** ( ): Mutes or unmutes the TV audio.
- **Channel Up/Down (▲/▼)**: Change TV channels.
- **Microphone Button** ( ): Activates voice control for commands and searches.
- **Home Button** (⌂): Returns to the TV's home screen or smart hub.
- **Back Button** (↶): Returns to the previous screen or menu.
- **Settings Button** (⚙): Accesses TV settings menu.

- **Navigation Wheel/Buttons**: Used to navigate menus and select items.
- **Netflix, Prime Video, Disney+, Movies, L channels, alea Buttons** Dedicated buttons for quick access to streaming services and specific functions.

Compatible Models

This remote control is compatible with a wide range of LG TV models, including but not limited to those originally supplied with AKB76045005 MR24GA or AKB76043112 MR23GA remotes. Compatible series and specific models include:

- AKB76045005 MR24GA, AKB76043112 MR23GA
- G4, C4, B4, UT80, 99T, 90T, 85T, 80T, QNED UT75 Series
- Specific models: 65QNED90TUA, 50QNED85TUA, 86QNED85TUA, OLED48B4PUA, OLED65G4SUB, 65QNED85TUA, 75QNED85TUA, 43UT8000AUA, 50QNED85TUA, 55QNED85TUA, 65QNED85TUA, 75QNED85TUA, 86QNED85TUA, 43UT8000AUA, 50UT8000AUA, 75UT8000AUA, 55UT8000AUA, 65UT8000AUA, 70UT8000AUA, 86UT8000AUA, 86QNED90TUA, OLED65C4PUA, OLED77B4AUA, OLED77B4PUA, OLED77C4AUA, OLED77C4PUA, OLED83C4AUA, OLED83C4PUA, OLED83G4WUA, OLED97G4WUA, OLED42C4AUA, OLED42C4PUA, OLED48B4AUA, OLED48C4AUA, 55QNED85TUA, OLED48C4PUA, OLED55B4AUA, OLED55B4PUA, OLED55C4AUA, OLED55C4PUA, 50UT8000AUA, OLED55G4SUB, OLED65B4AUA, OLED65B4PUA, OLED65C4AUA, OLED83B4PUA, OLED55B4EUA, 75QNED90TUA, OLED77G4WUA.

Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the remote. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

Troubleshooting

If you encounter issues with your remote control, try the following solutions:

Problem	Solution
Remote not responding.	◦ Check if batteries are inserted correctly with correct polarity. ◦ Replace old batteries with new ones. ◦ Ensure there are no obstructions between the remote and the TV's IR receiver.
Voice control or pointer not working.	◦ Ensure the remote is properly paired with your LG TV. Refer to the "Pairing with Your LG TV" section. ◦ Check TV settings to ensure voice control and pointer features are enabled.

Problem	Solution
Some buttons not functioning.	◦ Clean the remote's surface, especially around the non-functioning buttons, to remove any debris. ◦ Re-pair the remote with the TV.

Specifications

Feature	Detail
Model Number	CV-AKB76045005-MR24GA-SH
Power Supply	2 x 1.5V AA Batteries (not included)
Connectivity	Wireless
Color	Black
Product Dimensions	5 x 1.38 x 0.72 inches (12.7 x 3.5 x 1.8 cm)
Item Weight	3.52 ounces (99.79 grams)
Compatible Devices	LG Televisions (specific models listed in "Compatible Models" section)



Figure 4: General view of the remote control.

Warranty and Support

For information regarding warranty coverage or technical support, please refer to the seller or manufacturer's official documentation provided at the time of purchase. You may also visit the ALLIMITY official website for further assistance.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DPH2ZWCR

More documents and user manuals: **https://manuals.plus/**