Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Effireli YK-ERF3F86H

User Manual

ERF3F86H Infrared Replacement Remote for Hisense Smart TV

Model: YK-ERF3F86H | Brand: Effireli

Introduction

This manual provides instructions for the Effireli ERF3F86H Infrared Replacement Remote, designed for Hisense Smart TVs. This remote control offers a straightforward, plug-and-play experience without the need for complex programming or setup. Simply insert batteries and begin operation.
Please note that this is an infrared remote control and does not support voice control functions.

Setup

The ERF3F86H remote control is designed for immediate use with compatible Hisense Smart TVs. No programming or pairing is required.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely.

Once batteries are installed, the remote is ready for use.

Operating Instructions

Familiarize yourself with the buttons on your ERF3F86H remote control:



Image: Front view of the Effireli ERF3F86H Infrared Replacement Remote Control. The remote is black with various circular and oval-

shaped buttons, clearly labeled for different functions.

Button Functions

Button	Function
Power (Red Circle with Line)	Turns the TV on or off.
INPUT	Selects the input source (HDMI, AV, etc.).
App Buttons (Disny, M+, Prime Video, YouTube, NBA League Pass, Rakuten TV, Mitel, Deezer, Netflix, VDAA TV, VDAA Free)	Direct access to specific streaming services and applications.
Color Buttons (Red, Green, Yellow, Blue)	Context-sensitive functions within menus or applications.
Menu (Three Horizontal Lines)	Opens the main menu or settings.
Navigation Pad (Up, Down, Left, Right, OK)	Navigates through menus and confirms selections.
Back (Curved Arrow)	Returns to the previous screen or menu.
EXIT	Exits the current menu or application.
Volume Up (+) / Volume Down (-)	Adjusts the audio volume.
Channel Up (CH ^) / Channel Down (CH v)	Changes TV channels.
Home (House Icon)	Returns to the TV's home screen.
Mute (Speaker with Slash)	Mutes or unmutes the TV audio.
SUBTITLE	Toggles subtitles on or off.
TEXT	Accesses teletext or text-based services.
Number Buttons (0-9)	Direct channel input or numerical entry.
GUIDE	Displays the electronic program guide (EPG).
CH.LIST (Channel List)	Displays the list of available channels.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and damage.

- **Environment:** Avoid exposing the remote to extreme temperatures, direct sunlight, or high humidity.

Troubleshooting

Problem	Solution
Remote is not responding.	• Check if the batteries are inserted correctly with the correct polarity (+/-). • Replace old batteries with new ones. • Ensure there are no obstructions between the remote and the TV's infrared sensor. • Make sure you are within the effective range of the TV's IR sensor.
Some buttons are not working.	• Clean the remote control surface, especially around the unresponsive buttons, to remove any dirt or debris. • Ensure the remote is compatible with your specific TV model.
Remote works intermittently.	• Batteries may be low; replace them. • Ensure a clear line of sight to the TV's IR sensor.

Specifications

Feature	Detail
Model Number	YK-ERF3F86H
Brand	Effireli
Connectivity Technology	Infrared (IR)
Special Feature	No Programming Required
Compatible Devices	Hisense Smart Televisions (specifically ERF3F86H compatible models)
Power Source	2 x AAA Batteries (not included)

Warranty and Support

Warranty Information

This product comes with a**30-day money-back guarantee** and a **12-month warranty** covering manufacturing defects. Returns and exchanges are accepted within the warranty period.

Customer Support

If your TV model number is not listed as compatible, or if your original remote control appears different, please contact Effireli customer support directly to confirm compatibility before purchase or for assistance with any issues.
For support inquiries, please refer to the contact information provided with your purchase or on the Effireli official website.

© 2024 Effireli. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DPLBTBQG

More documents and user manuals: **https://manuals.plus/**