SUPERLEX B0DPLY2WNJ

SUPERLEX 750W Multi-Function Sandwich, Waffle, and Grill Maker

Instruction Manual

Introduction

Thank you for purchasing the SUPERLEX 750W Multi-Function Sandwich, Waffle, and Grill Maker. This appliance is designed for preparing delicious sandwiches, waffles, and grilled items with ease. Please read this instruction manual carefully before first use to ensure safe and optimal operation. Keep this manual for future reference.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions before operating the appliance.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
6. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
12. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to

"off," then remove plug from wall outlet.

13. Do not use appliance for other than intended use.
14. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
15. Children should be supervised to ensure that they do not play with the appliance.

Product Overview

The SUPERLEX Multi-Function Maker features a compact design with interchangeable non-stick plates for versatile cooking. It operates at 750W for efficient heating.



This image shows the SUPERLEX Multi-Function Maker with its interchangeable plates, including sandwich, waffle, and grill plates, highlighting its versatility.



The appliance open, revealing the non-stick sandwich plates

with two perfectly toasted sandwiches.

Key Components:

- **Housing:** The main body of the appliance.
- **Interchangeable Cooking Plates:** Non-stick plates for sandwiches, waffles, and grilling.
- **Handle with Safety Lock:** For secure closing during cooking and convenient storage.
- **Indicator Lights:** Red (Power) and Green (Ready/Temperature).
- **Power Cord:** For connecting to an electrical outlet.

Setup

1. **Unpacking:** Carefully remove the appliance and all accessories from the packaging. Retain packaging for storage or disposal.
2. **Initial Cleaning:** Before first use, wipe the cooking plates with a damp cloth or sponge. Dry thoroughly.
3. **Plate Installation:** Ensure the desired cooking plates (sandwich, waffle, or grill) are correctly inserted and locked into place.
4. **Placement:** Place the appliance on a stable, heat-resistant, and dry surface, away from walls and flammable materials. Ensure adequate ventilation.
5. **Power Connection:** Plug the power cord into a suitable 230V electrical outlet. The red indicator light will illuminate, signaling that the appliance is powered on and beginning to preheat.

Operating Instructions

This appliance features automatic temperature control for consistent cooking results.

1. **Preheating:** After plugging in, the red indicator light will turn on. Allow the appliance to preheat for approximately 30 seconds. The green indicator light will illuminate when the desired cooking temperature is reached, indicating it is ready for use.
2. **Preparing Food:** Lightly grease the cooking plates with a small amount of cooking oil or butter, if desired, especially for the first use or for specific recipes.
3. **Adding Ingredients:** Open the appliance using the cool-touch handle. Place your ingredients (e.g., bread with filling for sandwiches, batter for waffles, or items for grilling) onto the lower cooking plate.
4. **Closing and Locking:** Carefully close the lid, ensuring the handle's safety lock engages. This prevents ingredients from spilling and ensures even pressure for cooking.
5. **Cooking:** Cook for approximately 3 to 5 minutes, or until your food is golden brown and cooked to your preference. The green indicator light may cycle on and off during cooking as the appliance maintains its temperature.
6. **Removing Food:** Once cooked, open the appliance and carefully remove the food using a heat-resistant plastic or wooden utensil. **Do not use metal utensils** as they can damage the non-stick coating.
7. **Finishing:** Unplug the appliance from the power outlet after use.



The handle features a safety lock mechanism, allowing the appliance to be securely closed during operation and for compact storage.



The 750W heating elements ensure rapid and even cooking across both plates, preparing two sandwiches simultaneously.

Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your appliance.

1. **Cool Down:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Cleaning Plates:** The non-stick cooking plates are removable for easy cleaning. They can be washed directly with water and mild dish soap or placed in a dishwasher. For stubborn residue, soak the plates in warm, soapy water before cleaning.
3. **Exterior Cleaning:** Wipe the exterior of the appliance with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may damage the finish.

4. **Do Not Immerse:** Never immerse the main body of the appliance, cord, or plug in water or any other liquid.
5. **Storage:** Once clean and dry, store the appliance in a cool, dry place. The safety lock on the handle allows for convenient upright storage.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker.
Food not cooking evenly or taking too long.	Insufficient preheating; too much food; cold ingredients.	Allow full preheating until the green light illuminates. Do not overfill. Use room temperature ingredients where possible.
Green indicator light not illuminating.	Appliance still preheating or not reaching temperature.	Wait for the appliance to reach operating temperature. If it never illuminates, contact customer support.
Smoke or unusual odor during first use.	Protective oils burning off.	This is normal for first use. Ensure good ventilation. If it persists, unplug and contact support.

Specifications

- **Brand:** SUPERLEX
- **Model:** B0DPLY2WNJ
- **Color:** Silver
- **Dimensions (L x W x H):** 27.26 x 26.23 x 12.44 cm
- **Power:** 750 Watts
- **Voltage:** 230 Volts
- **Material:** Metal
- **Weight:** 1.33 Kilograms
- **Special Features:** Rapid double-sided heating, cool-touch handle, lightweight, removable non-stick plates (sandwich, waffle, grill).
- **Components Included:** Sandwich/toast plates, Waffle plates, Grill plates.

Warranty and Support

SUPERLEX products are designed for quality and reliability. For any questions, technical support, or warranty claims, please refer to the contact information provided with your purchase or visit the official SUPERLEX website. Please have your model number (B0DPLY2WNJ) and purchase date ready when contacting support.

© 2025 SUPERLEX. All rights reserved.