Kinhank Super Console X2 pro

Kinhank Super Console X2 pro User Manual

Model: Super Console X2 pro

1. Introduction

Welcome to the Kinhank Super Console X2 pro user manual. This guide provides essential information for setting up, operating, maintaining, and troubleshooting your new retro game console. The Super Console X2 pro is a versatile entertainment system, combining a powerful retro gaming platform (EmuELEC 4.5) with a full-featured Android 9.0 smart TV box, offering access to over 60,000 classic games and modern streaming applications. Please read this manual thoroughly before using the device to ensure optimal performance and longevity.



Image 1.1: Kinhank Super Console X2 pro with accessories and display.

2. Product Overview

2.1 Package Contents

Upon unboxing, please verify that all the following items are included in your package:

- Super Console X2 pro Console (x1)
- TF Card (x1)
- Game Card (x1, typically 256GB with 60000+ games)
- Game Controller (x2)
- Receiver (x1, for wireless controllers)
- Power Adapter (x1)
- HD Cable (x1)
- User Manual (x1)

- Remote Control (x1)



Image 2.1: Super Console X2 pro Package Contents.

2.2 Key Features

The Kinhank Super Console X2 pro offers a robust set of features designed for an immersive entertainment experience:

- **Dual System Integration:** Seamlessly switch between EmuELEC 4.5 for retro gaming and Android 9.0 for smart TV functionalities.
- **Extensive Game Library:** Pre-installed with over 60,000 classic games and support for adding more. Compatible with over 60 emulators.
- **High Performance:** Powered by an upgraded S905X2 chip, providing smooth gameplay and 4K@60fps video output.
- **Advanced Connectivity:** Features Dual-Band 2.4G/5G Wi-Fi, Bluetooth 5.0, and 1000M Ethernet for fast and stable connections.
- **Memory:** Equipped with 2GB DDR4 RAM and 8GB eMMC storage for quick loading and efficient operation.

- **Multi-language Support:** Supports over 26 languages for user interface and system navigation.



Image 2.2: Three Systems All in One.



Image 2.3: Extensive Game Library.

3. Setup Guide

Follow these steps to set up your Kinhank Super Console X2 pro:

1. **Connect to TV:** Insert one end of the provided HD cable into the HDMI port on the Super Console X2 pro and the other end into an available HDMI input on your television or monitor.
2. **Connect Power:** Plug the power adapter into the DC IN port on the console, then plug the adapter into a wall outlet. The console should power on automatically or can be turned on using the remote control.
3. **Connect Controllers:** Insert the wireless receiver for the gamepads into one of the USB ports on the console. The gamepads should automatically pair. If not, ensure the gamepads are charged and follow their specific pairing instructions.
4. **Initial Boot:** The console will boot up. You may be prompted to select a language or configure network settings. Follow the on-screen instructions.
5. **Network Connection (Optional but Recommended):** For Android features and potential system updates,

connect the console to your network via Wi-Fi or Ethernet. Go to the Android system settings, then Network & Internet, and select your preferred connection method.

4. Operating Instructions

4.1 Switching Between Systems

The Super Console X2 pro allows you to easily switch between the EmuELEC game system and the Android TV system using the included remote control.

- **From Android to EmuELEC:** On the Android home screen, locate and select the EmuELEC application icon. This will launch the game system.
- **From EmuELEC to Android:** While in the EmuELEC system, press the 'Menu' or 'Start' button on your gamepad to access the system menu. Look for an option like 'Quit' or 'Exit' and then select 'Reboot to Android' or 'Switch to Android'. Alternatively, you can use the remote control to navigate to the Android system.



Image 4.1: Switching between EmuELEC and Android.

4.2 Navigating EmuELEC (Game System)

- Use the directional pad (D-pad) or left analog stick on your gamepad to navigate through game systems (consoles) and game lists.
- Press the 'A' or 'X' button (depending on controller type) to select a game or enter a system.
- Press the 'B' or 'O' button to go back to the previous menu.
- Press the 'Start' button to access the main EmuELEC menu for system settings, game options, and more.
- Press the 'Select' button for context-sensitive options, often related to the currently highlighted game.

4.3 Navigating Android 9.0 (Smart TV System)

- Use the remote control's directional buttons and 'OK' button to navigate the Android interface.
- Access pre-installed apps like streaming services, web browsers, and media players.
- Download additional applications from the Google Play Store (requires a Google account and internet connection).

4.4 Adding Games

The console supports adding more games. This typically involves transferring ROM files to the appropriate folders on the game card via a computer. Refer to online resources or the detailed digital manual (if available) for specific instructions on adding games for EmuELEC.

5. Maintenance

Proper maintenance ensures the longevity and optimal performance of your console:

- **Cleaning:** Use a soft, dry cloth to clean the console and controllers. Avoid using liquid cleaners or abrasive materials.
- **Ventilation:** Ensure the console is placed in a well-ventilated area to prevent overheating. Do not block any ventilation openings.
- **Storage:** When not in use for extended periods, store the console in a cool, dry place away from direct sunlight and extreme temperatures.
- **Software Updates:** Periodically check for system updates for both EmuELEC and Android to ensure you have the latest features and bug fixes. Updates are typically performed via the system settings when connected to the internet.
- **Power Off Properly:** Always power off the console using the remote control or system menu options rather than simply unplugging it, to prevent data corruption.

6. Troubleshooting

If you encounter issues with your Super Console X2 pro, refer to the following common problems and solutions:

- **No Power:**
  - Ensure the power adapter is securely connected to the console and a working power outlet.
  - Try a different power outlet.
- **No Signal on TV:**
  - Verify the HD cable is securely connected to both the console and the TV.

- Ensure your TV input source is set to the correct HDMI port.
- Try a different HD cable or HDMI port on your TV.

- **Controllers Not Responding:**
  - Check if the wireless receiver is properly inserted into a USB port on the console.
  - Ensure the controllers are charged or have fresh batteries.
  - Try re-pairing the controllers according to their specific instructions.
- **Game Lag or Slow Performance:**
  - Ensure the console has adequate ventilation and is not overheating.
  - Close any unnecessary applications running in the Android system before switching to EmuELEC.
  - For Android, ensure a stable internet connection for streaming content.
- **Cannot Switch Systems:**
  - Ensure you are following the correct procedure for switching (refer to Section 4.1).
  - Restart the console.

7. Specifications

Detailed technical specifications for the Kinhank Super Console X2 pro:

Feature	Specification
Model	Super Console X2 pro
Operating Systems	EmuELEC 4.5, Android 9.0
Processor	S905X2 Chip
RAM	2GB DDR4
Storage	8GB eMMC (internal), supports Game Card (up to 256GB)
Game Library	60,000+ pre-installed games, 60+ emulators
Video Output	HDMI, up to 4K@60fps
Wi-Fi	Dual-Band 2.4G/5G
Bluetooth	BT 5.0
Ethernet	1000M
Product Dimensions	5.91 x 5.91 x 1.18 inches
Item Weight	1.8 pounds
Language Support	English, 26+ other languages



Image 7.1: Memory and Performance.



Image 7.2: Connectivity Features.

8. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your product or contact Kinhank customer service directly. Warranty terms and conditions may vary by region and retailer.
It is recommended to register your product on the manufacturer's official website, if available, to receive updates and support.

© 2024 Kinhank. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question