Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Evmore J03PRO

Evmore Electric Scooter User Manual

Model: J03PRO

1. Introduction

Thank you for choosing the Evmore Electric Scooter J03PRO. This manual provides essential information for the safe operation, assembly, maintenance, and troubleshooting of your new electric scooter. Please read this manual thoroughly before your first ride to ensure proper use and to maximize the lifespan of your product.



Image: The Evmore Electric Scooter J03PRO, showcasing its sleek black design and the accompanying mobile application interface on a smartphone.

2. Safety Information

Your safety is paramount. Always wear a helmet and appropriate protective gear when riding. Adhere to local traffic laws

and regulations. This scooter is designed for adults and teens, with a maximum weight limit of 308 lbs.

2.1 Important Safety Guidelines

- Always inspect the scooter before each ride, checking brakes, tires, and all connections.
- Do not ride in heavy rain, on slippery surfaces, or through standing water.
- Maintain a safe distance from other vehicles and pedestrians.
- Avoid sudden turns or maneuvers at high speeds.
- Ensure the battery is adequately charged before long rides.
- This product has passed stringent UL 2272 testing, ensuring electrical safety.



Image: A visual representation of the UL 2272 test report and the product's identification label, confirming compliance with safety standards.

3. Package Contents

Upon opening the package, please verify that all components are present and in good condition:

- Evmore Electric Scooter J03PRO
- Power Adapter/Charger
- User Manual
- Necessary Assembly Tools (if applicable)

4. Setup and Assembly

The Evmore Electric Scooter J03PRO features a portable folding design for easy transport and storage. Initial setup primarily involves unfolding and securing the handlebar stem.

4.1 Unfolding the Scooter

1. Place the scooter on a flat, stable surface.
2. Locate the folding mechanism near the base of the handlebar stem.
3. Release the locking lever or pin according to the diagram (refer to the quick start guide if provided).
4. Carefully lift the handlebar stem until it clicks into its upright, locked position.
5. Ensure the locking mechanism is fully engaged and secure before riding.



Image: A person effortlessly carrying the Evmore Electric Scooter in its folded state, highlighting its portability and the simple 1-touch folding system.

5. Operating Instructions

5.1 Powering On/Off

Press and hold the power button on the display to turn the scooter on or off.

5.2 Speed Settings

The scooter offers four adjustable speed settings: 12.5 MPH, 15.5 MPH, and 18.5 MPH. Use the mode button on the display to cycle through these settings and select your desired speed.

5.3 Braking System

The Evmore J03PRO is equipped with a dual braking system for maximum safety, combining a front electric brake with a rear disc brake. Apply both brakes simultaneously for effective and controlled stopping.



Image: A detailed view of the scooter's rear wheel, illustrating the dual braking system with both electric and disc brake components for enhanced safety.

5.4 Smart LED Display

The integrated Smart LED Display provides real-time information including current speed, battery level, and selected riding mode. It also allows for lighting control.



Image: A close-up of the scooter's smart LED display, clearly showing the digital readouts for speed, battery charge, and various control indicators.

5.5 APP Connectivity

Connect your scooter to the "Scootor APP" via Bluetooth for enhanced control and monitoring. The app allows you to track battery life, adjust speed settings, and customize riding modes for a personalized experience.



Image: A user interacting with the Evmore Electric Scooter via a smartphone application, demonstrating the smart control features like Bluetooth pairing, locking, headlight control, and speed mode switching.

5.6 Charging

The scooter is powered by a 36V 10.4AH high-capacity battery, offering a maximum range of 26 miles under optimum conditions. A full charge typically takes 5-6 hours. Always use the provided charger.



Image: An illustration of the scooter's battery compartment, highlighting the 36V 10.4Ah battery and indicating a 26-mile range with a 5-6 hour fast charging time.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your Evmore Electric Scooter.

6.1 Cleaning

Wipe the scooter with a damp cloth after each use. Do not use high-pressure water jets or corrosive cleaners.

6.2 Tire Care

The scooter features 10-inch pneumatic tires. Regularly check tire pressure and inflate to the recommended PSI (usually found on the tire sidewall) to ensure optimal ride comfort and efficiency.



Image: A close-up of the scooter's 10-inch pneumatic tire demonstrating its ability to absorb ground impact and vibration, ensuring a smoother ride over obstacles like speed bumps.

6.3 Battery Care

To prolong battery life, avoid fully discharging the battery. Charge it regularly, even if not in use for extended periods. Store the scooter in a cool, dry place.

6.4 Shock Absorbers

The scooter is equipped with hydraulic shock absorbers on the front wheels and suspension spring shock absorbers on the rear, providing dual suspension for a smooth ride. Periodically check for any visible damage or leaks.



Image: An exploded view highlighting the scooter's dual suspension system, featuring hydraulic dampers at the front and double spring suspension at the rear, designed for confident exploration on various city roads.

7. Troubleshooting

If you encounter issues with your Evmore Electric Scooter, refer to the following common troubleshooting steps:

- **Scooter not turning on:** Ensure the battery is charged. Check all cable connections.
- **Reduced range/speed:** Verify tire pressure. Ensure battery is fully charged. Riding conditions (hills, rider weight, temperature) can affect performance.
- **Brakes not responding:** Check brake levers and cables for proper tension and connection.
- **Unusual noises:** Inspect wheels, motor, and suspension for loose parts or obstructions.

For persistent issues not resolved by these steps, please contact customer support.

8. Specifications

Feature	Specification
Brand	Evmore
Model Name	J03PRO
Motor Power	500W Brushless Motor
Top Speed	Up to 18.5 MPH
Max Distance Range	26 Miles (under optimum conditions)
Battery Capacity	36V 10.4AH
Charging Time	Approximately 5-6 Hours
Weight Limit	308 Pounds
Wheel Size	10 Inches
Wheel Type	Pneumatic

Feature	Specification
Brake Style	Front Electric Brake, Rear Disc Brake
Suspension Type	Dual Suspension (Hydraulic front, Spring rear)
Frame Material	Aluminum Alloy Steel
Special Feature	Foldable
Color	Black
UL Certification	UL 2272 Certified



Image: An internal view of the scooter's motor, highlighting its 500W peak power, 18 MPH max speed, and 15-degree max climbing ability.

9. Warranty and Support

9.1 Warranty Information

The Evmore Electric Scooter J03PRO comes with a limited warranty of 6 months from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

9.2 Customer Support

For warranty claims, technical assistance, or any questions regarding your Evmore Electric Scooter, please contact Evmore customer support through the retailer's platform or the official Evmore website. Please have your purchase receipt and product model number (J03PRO) ready when contacting support.

© 2024 Evmore. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DPPLZHNX

More documents and user manuals: **https://manuals.plus/**