**VOCA V141**

# VOCA 4G Big Button Mobile Phone V141 User Manual

Model: V141

## 1. Introduction

This manual provides essential instructions for setting up, operating, and maintaining your VOCA V141 4G Big Button Mobile Phone. Please read this guide carefully to ensure proper use and to maximize the phone's features. The VOCA V141 is designed for ease of use, featuring large buttons, an amplified volume, and a user-friendly interface, making it suitable for elderly users or those who prefer a simpler mobile experience.

## 2. Product Overview

The VOCA V141 is a 4G LTE unlocked mobile phone with a focus on accessibility and essential communication. It features a redesigned user interface with larger characters and clear menu icons for improved readability.




Figure 2.1: Front view of the VOCA V141 phone, highlighting its large buttons and clear display.

## Key Features:

- **4G LTE Connectivity:** Supports 4G networks for reliable communication.
- **Large Buttons and Display:** Enhanced visibility and ease of dialing.
- **Amplified Volume:** Clearer audio for calls and ringtones.
- **SOS Emergency Button:** For immediate contact in urgent situations.
- **Quick Dial Function:** Assign frequently called numbers for easy access.
- **Long-Lasting Battery:** Extended usage time between charges.
- **User-Friendly Interface:** Simplified menu navigation with large green characters (eye protection mode).
- **Lightweight Design:** Easy to handle and carry.
- **Low Battery SMS Notification:** Automatically alerts emergency contacts when battery is low.

- **Built-in Flashlight:** Convenient for low-light situations.
- **Basic Camera:** For simple photo capture.




Figure 2.2: VOCA V141 highlighting key features such as SOS button and eye protection mode.

## 3. Setup

### 3.1. SIM Card and Battery Installation

1. **Remove Back Cover:** Gently slide or pry off the back cover of the phone.
2. **Insert SIM Card:** Locate the SIM card slot(s). Insert your 4G compatible SIM card(s) into the designated slot(s) with the gold contacts facing down, following the diagram usually found near the slot.
3. **Insert Battery:** Place the Lithium-ion battery into the battery compartment, ensuring the contacts align correctly with the phone's terminals.
4. **Replace Back Cover:** Securely reattach the back cover.

### 3.2. Initial Power On and Charging

1. **Power On:** Press and hold the Power/End Call button (usually red) until the screen lights up.
2. **Initial Charge:** Connect the phone to the charger using the USB Type C cable. It is recommended to fully charge the battery before first use.

### 3.3. Basic Settings

- **Language:** Upon first startup, you may be prompted to select your preferred language. Navigate using the directional keys and confirm with the central button.
- **Date and Time:** Set the correct date and time through the phone's settings menu.

## 4. Operating Instructions

### 4.1. Making and Receiving Calls

- **To Make a Call:** Enter the phone number using the keypad and press the Green Call button.
- **To Answer a Call:** Press the Green Call button when the phone rings.
- **To End a Call:** Press the Red End Call button.

### 4.2. Sending and Receiving SMS Messages

- **To Send SMS:** Navigate to the 'Messages' menu. Select 'New Message', enter the recipient's number or select from contacts, type your message, and send.
- **To Read SMS:** New messages will typically appear as a notification. Access them through the 'Messages' menu.

### 4.3. SOS Emergency Function

The V141 features a dedicated SOS button on the back for emergencies. When activated, it will automatically dial a pre-set emergency contact number.



Figure 4.1: The dedicated SOS button on the back of the phone.

1. **Setting SOS Numbers:** Access the 'SOS Settings' in the phone's menu to program up to 5 emergency contact numbers.
2. **Activating SOS:** Press and hold the SOS button on the back of the phone for a few seconds. The phone will automatically dial the first emergency contact. If unanswered, it will proceed to dial the next number in the list.

## 4.4. Quick Dial (M1/M2 Buttons)

The M1 and M2 buttons allow for quick dialing of two important contacts.




Figure 4.2: Setting up quick dial numbers.

1. **Setting M1/M2:** Go to 'Settings' > 'Speed Dial' or 'M1/M2 Settings' to assign a contact to each button.
2. **Using Quick Dial:** Simply press and hold the M1 or M2 button to call the assigned contact.

## 4.5. Flashlight

The phone includes a built-in flashlight for convenience.




Figure 4.3: Activating the flashlight.

- **To Turn On/Off:** Press and hold the '0' key for 2 seconds to activate or deactivate the flashlight.

## 4.6. Low Battery SMS Notification

The phone can automatically send an SMS alert to pre-selected contacts when the battery level drops to 15%.




Figure 4.4: Setting up low battery SMS notifications.

1. **Configure Contacts:** Go to 'Settings' > 'Battery Alert' or similar menu to set up the emergency contacts who will

receive the SMS.

2. **Customize Message:** You may have the option to customize the low battery alert message.

### 4.7. Retro Games

The phone includes several classic retro games for entertainment.




Figure 4.5: The phone features classic retro games like Snake, Tetris, and Sokoban.

- **Access Games:** Navigate to the 'Games' menu from the main screen to select and play available games.

## 5. Maintenance

### 5.1. Cleaning

- Use a soft, dry cloth to clean the phone's screen and body.

- Avoid using liquid cleaners or abrasive materials, as they may damage the phone.

### 5.2. Battery Care

- To prolong battery life, avoid exposing the phone to extreme temperatures.
- Charge the phone regularly, but avoid leaving it connected to the charger for excessively long periods after it's fully charged.
- If the phone will not be used for an extended period, charge it to about 50% before storing.

## 6. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Phone does not power on | Low battery; Battery not inserted correctly; Phone damaged. | Charge the battery; Reinsert battery; Contact support. |
| Cannot make/receive calls | No SIM card; SIM card not inserted correctly; No network signal; SIM card not activated. | Insert SIM card; Reinsert SIM card; Move to an area with better signal; Contact your network provider. |
| Poor call quality | Weak network signal; Obstructions; Speaker/microphone issues. | Move to an open area; Check for physical obstructions; Contact support if issue persists. |
| Battery drains quickly | Excessive usage; Background applications; Old battery. | Reduce screen brightness; Close unused applications; Consider replacing the battery if it's old. |
| SOS button not working | No SOS numbers programmed; Incorrect programming. | Ensure SOS numbers are correctly set in the settings menu. |

## 7. Specifications

| Feature | Detail |
|---|---|
| Brand | VOCA |
| Model Number | V141 |
| Product Type | Bar Phone |
| Operating System | Android (Simplified UI) |
| Cellular Technology | 4G LTE |
| Wireless Carrier | Unlocked (All carriers) |
| Charging Port | USB Type C |
| Battery Composition | Lithium-ion |
| Installed RAM Size | 48 MB |
| Memory Storage Capacity | 1 GB |

| Feature | Detail |
| --- | --- |
| Display Resolution | 800 x 480 pixels |

## 8. Warranty and Support

For warranty information, please refer to the documentation included with your purchase or contact the retailer. For technical support or further assistance, please contact VOCA customer service through their official website or the contact details provided in your product packaging.
Keep your purchase receipt and product packaging for warranty claims.

© 2024 VOCA. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question