**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Fullwill 170B**

# Fullwill 6QT Air Fryer with Viewing Window (Model 170B) Instruction Manual

Model: 170B | Brand: Fullwill

## 1. Introduction

This manual provides essential information for the safe and efficient operation of your Fullwill 6QT Air Fryer with Viewing Window. Please read these instructions thoroughly before first use and retain for future reference. This appliance is designed for household use only.




*Image 1.1: The Fullwill 6QT Air Fryer, showcasing its main unit, cooking basket with a steak and vegetables, crisper plate, and an included recipe booklet.*

## 2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.

- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

## 3. Product Overview

The Fullwill 6QT Air Fryer is a versatile kitchen appliance designed for healthier cooking. It features a 6-quart capacity and multiple functions including air frying, roasting, baking, reheating, and dehydrating. The integrated viewing window allows for easy monitoring of food during cooking.

### Components:

- Main Air Fryer Unit
- 6-Quart Non-stick Cooking Basket
- Crisper Plate
- Integrated Viewing Window
- Digital Touch Control Panel




*Image 3.1: The air fryer's viewing window, allowing users to monitor cooking progress without opening the basket.*




*Image 3.2: The digital touch control panel displaying different cooking functions and food-specific presets.*

## 4. Setup and First Use

1. **Unpacking:** Carefully remove all packaging materials, stickers, and labels from the appliance.
2. **Cleaning:** Wash the cooking basket and crisper plate with hot water, dish soap, and a non-abrasive sponge. Rinse thoroughly and dry completely. Wipe the inside and outside of the main unit with a damp cloth.
3. **Placement:** Place the air fryer on a stable, heat-resistant, and level surface, away from walls or other appliances to ensure proper air circulation.
4. **Preheating (Optional but Recommended):** For the first use, it is recommended to run the air fryer empty for about 10-15 minutes at 350°F (175°C) to eliminate any manufacturing odors. A slight odor may be present, which is normal.

## 5. Operating Instructions

## General Operation:

1. **Plug In:** Connect the power cord to a grounded electrical outlet. The display will illuminate.
2. **Place Food:** Insert the crisper plate into the cooking basket, then place your food into the basket. Slide the basket back into the air fryer until it clicks into place.
3. **Select Function/Preset:**
    - **Manual Setting:** Press the "Menu" button to cycle through functions (Air Fry, Roast, Bake, Reheat, Dehydrate). Use the temperature and time adjustment buttons (**+** / **-**) to set your desired temperature (105°F to 400°F) and time (1 minute to 12 hours, depending on function).
    - **One-Touch Presets:** The air fryer includes 7 one-touch presets for common foods: Chicken, Fries, Steak, Custard Tart, Wings, Seafood, and Vegetables. Simply press the corresponding icon on the control panel. The appliance will automatically set the optimal time and temperature.
4. **Start Cooking:** Press the "Start/Pause" button to begin the cooking cycle.
5. **Monitor Progress:** Use the viewing window to check on your food without interrupting the cooking process.
6. **Shake Reminder (for some foods):** For certain recipes, the air fryer may beep halfway through the cooking time to remind you to shake or flip the food for even cooking.
7. **Completion:** The air fryer will beep several times when the cooking cycle is complete. Carefully pull out the basket using the handle.
8. **Serve:** Remove food from the basket using tongs. Avoid direct contact with the hot basket.

## Cooking Functions:

- **Air Fry:** Ideal for crispy results with minimal oil.
- **Roast:** Perfect for meats and vegetables.
- **Bake:** Suitable for cakes, pastries, and other baked goods.
- **Reheat:** Warms up leftovers quickly and efficiently.
- **Dehydrate:** For drying fruits, vegetables, and making jerky.




*Image 5.1: The 6-quart capacity of the air fryer is suitable for preparing meals for families.*




*Image 5.2: The air fryer uses advanced air circulation technology to achieve crispy results with up to 85% less oil.*

## 6. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. **Unplug and Cool:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Basket and Crisper Plate:** The non-stick cooking basket and crisper plate are dishwasher safe. Alternatively, they can be washed by hand with hot water, dish soap, and a non-abrasive sponge. Rinse thoroughly and dry completely.
3. **Main Unit:** Wipe the exterior and interior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid.
4. **Heating Element:** Use a soft brush to remove any food residue from the heating element, located inside the top of the air fryer.
5. **Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.




*Image 6.1: The non-stick basket and crisper plate are designed for easy cleaning and are dishwasher safe.*

## 7. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Air fryer does not turn on. | Appliance is not plugged in. Power outlet is not working. | Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. |
| Food is not cooked evenly. | Basket is overloaded. Food pieces are too large. Food was not shaken/flipped. | Cook food in smaller batches. Cut food into smaller, uniform pieces. Shake or flip food halfway through cooking. |
| White smoke comes from the appliance. | Grease residue from previous use. Fatty ingredients are being cooked. | Clean the basket and crisper plate thoroughly after each use. Remove excess oil from food before air frying. |

| Problem | Possible Cause | Solution |
|---|---|---|
| Food is not crispy. | Too much moisture in food. Not enough oil (for some foods). Temperature too low or time too short. | Pat food dry before cooking. Lightly brush or spray with oil. Increase temperature or cooking time. |

## 8. Specifications

**Model Name:** Vision

**Model Number:** 170B

**Brand:** Fullwill

**Capacity:** 6 Quarts

**Functions:** Air Fry, Roast, Bake, Reheat, Dehydrate

**Output Wattage:** 1700 Watts

**Voltage:** 120 Volts

**Control Method:** Touch

**Temperature Range:** 105°F to 400°F (approx.)

**Product Dimensions:** 12.24"D x 15.51"W x 14.92"H

**Item Weight:** 9.7 Pounds (approx. 9.68 lbs)

**Material:** Polypropylene (PP)

**Nonstick Coating:** Yes

**Dishwasher Safe Parts:** Basket, Crisper Plate

**UPC:** 850066761038

## 9. Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or contact Fullwill customer service directly. You can typically find contact details on the manufacturer's official website or through your purchase platform.
Please have your model number (170B) and proof of purchase ready when contacting support.

© 2025 Fullwill. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0DPZZ8FY2**

More documents and user manuals: **https://manuals.plus/**