Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Aramox Q8S

Aramox Q8S Home Security Camera User Manual

Model: Q8S / Aramoxinpkgw34y6

1. Introduction

Thank you for choosing the Aramox Q8S Home Security Camera. This compact device is designed to provide reliable surveillance with features such as 4MP high-definition video, full-color night monitoring, two-way audio, and intelligent motion detection. This manual provides detailed instructions for setting up, operating, and maintaining your camera to ensure optimal performance.

2. Product Features

- **4MP High-Definition Lens:** Captures clear and detailed video footage.
- **Full-Color Night Monitoring:** Utilizes a large F1.0 aperture for high-definition full-color video in low-light conditions.
- **Two-Way Voice Intercom:** Enables clear, noise-reduced communication with personalized voice broadcasting.
- **Intelligent Chip:** Provides fast computation and strong image parsing for smooth video and audio.
- **Wireless Connectivity:** Supports easy network configuration for better reception.
- **Multi-User Device Sharing:** Allows multiple individuals to view and monitor simultaneously.
- **Intelligent Motion Detection Alarm:** Pushes real-time alarm information and captures images when movement is detected within a user-defined area.
- **Built-in Battery:** Features a 3.7V 650mAh lithium battery, providing approximately 3 hours of continuous recording on a full charge.
- **Magnet Suction Bottom:** Offers flexible and easy installation without traditional wiring.
- **100° Wide Angle:** Provides a broad field of view for comprehensive monitoring.

3. Package Contents

Verify that all items are present in your package:

- Aramox Q8S Home Security Camera

- USB Type-C Charging Cable
- Magnetic Suction Mount
- Adhesive Pad
- Reset Pin



Image: The Aramox Q8S camera, USB-C cable, magnetic suction mount, adhesive pad, and reset pin are included in the package.

4. Device Overview

Familiarize yourself with the camera's components:



Image: Top view of the Aramox Q8S camera, showing the main lens on the top surface.

- **Front Lens:** The primary camera lens for video capture.
- **Speaker Grille:** Located on the side, for audio output during two-way intercom.
- **Microphone:** Integrated for audio input during two-way intercom.
- **ON/OFF Switch:** Power control for the device.
- **Type-C Port:** Used for charging the internal battery.
- **Reset Button:** A small pinhole button for factory reset (requires reset pin).
- **Magnetic Base:** The bottom surface of the camera, designed for magnetic attachment.



Image: Side view of the Aramox Q8S camera, highlighting the ON/OFF switch, Type-C charging port, and reset pinhole.

5. Setup

5.1 Charging the Battery

Before first use, fully charge the camera's built-in 650mAh lithium battery. Connect the provided USB Type-C cable to the camera's Type-C port and a standard USB power adapter (not included). The charging indicator light will show the charging status.

5.2 App Installation and Network Configuration

1. Download the companion app (e.g., 'For APP' as indicated in product description) from your mobile device's app store (iOS or Android).

2. Register an account and log in.
3. Power on the camera using the ON/OFF switch.
4. Follow the in-app instructions to add your camera. This typically involves scanning a QR code on the camera or connecting to the camera's temporary Wi-Fi hotspot for initial setup.
5. Connect the camera to your home's 2.4G Wi-Fi network. Ensure a strong signal for optimal performance.

5.3 Mounting the Camera

The camera features a magnetic suction bottom for flexible placement.

- **Magnetic Surface:** Directly attach the camera to any suitable metallic surface.
- **Using the Magnetic Suction Mount:** Attach the camera to the magnetic suction mount. The mount can then be placed on a flat surface or secured using the adhesive pad for non-magnetic surfaces.



Image: The Aramox Q8S camera attached to its magnetic suction mount, ready for placement.

6. Operating Instructions

6.1 Live View and Recording

Once connected to the app, you can access the live video feed from your camera. The app allows you to initiate manual recordings, take screenshots, and review recorded footage.

6.2 Two-Way Audio

Tap the microphone icon in the app to activate the two-way intercom. Speak into your phone to transmit audio through the camera's speaker, and listen to audio from the camera's microphone.

6.3 Night Monitoring

The camera automatically switches to full-color night monitoring mode in low-light conditions. Ensure the camera lens is unobstructed for optimal night vision performance.

6.4 Motion Detection Alarm

1. In the app settings, navigate to the motion detection section.
2. Enable intelligent motion detection.
3. Delineate the specific detection area on the mobile phone screen to minimize false alarms.
4. Configure alarm notifications to receive real-time alerts and captured images on your mobile device.

7. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the camera lens and body. Avoid abrasive cleaners or solvents.
- **Battery Care:** For optimal battery life, avoid extreme temperatures. Recharge the battery regularly, even if the camera is not in constant use.
- **Firmware Updates:** Periodically check the companion app for available firmware updates to ensure your camera has the latest features and security enhancements.

8. Troubleshooting

- **Camera Not Powering On:** Ensure the battery is charged. Connect the camera to a power source using the Type-C cable.
- **Cannot Connect to Wi-Fi:** Verify that your Wi-Fi network is 2.4G. Ensure the camera is within range of your router. Try resetting the camera using the reset pin and re-attempting the setup process.
- **Poor Image Quality:** Check if the lens is clean and free from obstructions. Ensure adequate lighting, especially for night monitoring.
- **Motion Detection Not Working:** Confirm that motion detection is enabled in the app and the detection area is correctly configured. Check notification settings on your phone.
- **No Audio / Poor Audio:** Ensure the microphone and speaker are not obstructed. Check audio settings within the app.
- **Camera Unresponsive:** Use the reset pin to press and hold the reset button for approximately 5-10 seconds until the camera restarts.

9. Specifications

Feature	Specification

Model	Q8S / Aramoxinpkgw34y6
Pixels	4MP
Resolution	3MP
Frequency Band	2.4G Wi-Fi
Night Function	Full Color Night Monitoring
Detection	Small Motion Detection
USB Port	Type-C
Recording Angle (Diagonal)	100° Wide Angle
Battery Capacity	3.7V Lithium Battery 650mAh (built-in)
Continuous Recording	Approx. 3 hours (fully charged)
Sound Pickup Distance	Approx. 5m / 16.4ft
Package Dimensions	4.72 x 4.72 x 1.97 inches
Item Weight	6.4 ounces
Recommended Uses	Indoor/Outdoor

10. Warranty and Support

Aramox products are designed for reliability and performance. For warranty information, please refer to the documentation included with your purchase or contact Aramox customer support. If you encounter any issues or have questions not covered in this manual, please reach out to our support team for assistance.

Contact Information: Please refer to the official Aramox website or your purchase platform for the most current customer support contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DQ27P6KK

More documents and user manuals: **https://manuals.plus/**