CLEANmaxx 15097

CLEANmaxx Cordless 2-in-1 Vacuum Cleaner User Manual

Model: 15097

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your CLEANmaxx Cordless 2-in-1 Vacuum Cleaner. Please read it thoroughly before first use and keep it for future reference. The CLEANmaxx Cordless 2-in-1 Vacuum Cleaner is a versatile cleaning device designed for both floor and handheld use. It features cyclone technology, a powerful 22.2V battery, and an EPA-11 filter for effective dust collection and air purification.



Image: The CLEANmaxx 2-in-1 Cordless Vacuum Cleaner shown in its full stick vacuum configuration on the left, and as a compact handheld vacuum on the right, demonstrating its versatile design.

Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Do not use the appliance outdoors or on wet surfaces.
- Do not allow children to operate the vacuum cleaner.
- Unplug the charger from the outlet when not in use and before cleaning.
- Do not pick up flammable or combustible materials, hot ashes, or sharp objects.
- Ensure all filters are properly installed before operation.

- Use only manufacturer-recommended attachments.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.

Package Contents

Verify that all items are present in the package:

- 1 x Cordless Cyclone Vacuum Cleaner unit
- 1 x Aluminum Telescopic Tube (80 cm extension)
- 1 x Floor Nozzle (Power 3000)
- 1 x Crevice Nozzle
- 1 x Combination Nozzle
- 1 x Nozzle Adapter
- 1 x Power Adapter/Charger
- 1 x Wall Mount including fastening material
- 1 x User Manual (this document)



Image: A comprehensive view of all components included in the CLEANmaxx vacuum cleaner set, laid out on a flat surface, including the main unit, various nozzles, extension tube, charger, and wall mount.

Setup and Assembly

1. **Charging the Battery:** Before first use, fully charge the vacuum cleaner's battery. Connect the power adapter to the charging port on the main unit and plug it into a wall outlet. The charging indicator light will show the charging status. A full charge provides up to 35 minutes of runtime.
2. **Assembling the Stick Vacuum:**
    - Attach the aluminum telescopic tube to the main vacuum unit by aligning the connectors and pushing until it clicks into place.
    - Attach the floor nozzle (Power 3000) to the other end of the telescopic tube.
3. **Assembling the Handheld Vacuum:** For handheld use, detach the telescopic tube. You can directly attach any of the smaller nozzles (crevice nozzle, combination nozzle) to the main vacuum unit.

4. **Wall Mount Installation:** Choose a suitable location for the wall mount. Use the provided fastening material to securely attach the wall mount to a wall. This allows for convenient storage and charging.



Image: The CLEANmaxx vacuum cleaner is shown neatly stored on its wall mount, demonstrating its space-saving storage solution.

Operating Instructions

Powering On/Off and Suction Levels

Press the power button to turn the vacuum cleaner on. It features a 2-stage suction power regulation. Press the button again to switch between the two suction levels (standard and maximum). Press a third time to turn the unit off.

Using Attachments

- **Floor Nozzle (Power 3000):** Ideal for thorough cleaning of carpets, laminate, tiles, and other hard floors. Its special

design provides extra suction power.

- **Crevice Nozzle:** Perfect for reaching narrow gaps, corners, and tight spaces, such as between sofa cushions or car seats.
- **Combination Nozzle:** A versatile tool for cleaning upholstery, furniture, keyboards, and other delicate surfaces.
- **Aluminum Telescopic Tube:** Use with the floor nozzle for floor cleaning, or with other nozzles for high-reach areas like ceilings to remove cobwebs.



Image: The CLEANmaxx vacuum cleaner demonstrating its flexibility and power with various attachments: the 80 cm extension tube for high reach, the brush nozzle for upholstery, the crevice nozzle for tight spots, and the floor nozzle for general floor cleaning.



Image: A close-up of the CLEANmaxx Power 3000 floor nozzle effectively cleaning a carpet, highlighting its extra suction power for thorough dirt removal.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

Emptying the Dust Container

The 800 ml dust container should be emptied regularly, especially when the dirt level reaches the MAX line. To empty:

1. Ensure the vacuum cleaner is turned off.
2. Press the release button to detach the dust container from the main unit.
3. Open the bottom flap of the dust container and empty the contents into a waste bin.
4. Close the flap and reattach the dust container to the main unit until it clicks into place.



Image: An illustration of the CLEANmaxx vacuum cleaner highlighting its key features: the removable dust container for easy emptying, the EPA11 filter for effective air purification, and the cordless design.

Cleaning the Filters

The vacuum cleaner is equipped with an EPA-11 filter and a stainless steel filter. These should be cleaned periodically to maintain suction power and air quality.

- Remove the dust container.
- Carefully remove the EPA-11 filter and the stainless steel filter from the dust container.
- Tap the filters gently to remove loose dust. For a more thorough cleaning, rinse them under running water.
- **Important:** Ensure the filters are completely dry before reinserting them into the vacuum cleaner. This may take up to 24 hours. Using wet filters can damage the motor.
- Reassemble the filters and dust container in reverse order.



Image: A visual representation of the CLEANmaxx vacuum cleaner's EPA 11 filter system, illustrating how it effectively filters up to 95% of fine dust, making it ideal for allergy sufferers.

General Cleaning

- Wipe the exterior of the vacuum cleaner with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Check the nozzles and tubes for any blockages and remove them if found.

Troubleshooting

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	Battery is not charged.	Charge the battery fully.

Problem	Possible Cause	Solution
Reduced suction power.	Dust container is full. Filters are clogged. Nozzle/tube is blocked.	Empty the dust container. Clean or replace filters. Check and clear any blockages in nozzles or tubes.
Short operating time.	Battery not fully charged. Battery life degraded.	Ensure battery is fully charged before use. If battery life is significantly reduced, contact customer support for replacement options.
Unusual noise during operation.	Blockage in the air path. Foreign object in the brush roll (if applicable).	Turn off and unplug the unit. Check for and remove any blockages in the nozzles, tubes, or dust container.

Specifications

- **Model:** 15097
- **Brand:** CLEANmaxx
- **Battery:** 22.2V, 2000 mAh Li-Ion
- **Suction Power:** Up to 10 kPa
- **Runtime:** Up to 35 minutes (depending on suction level)
- **Dust Container Capacity:** 800 ml
- **Filter Type:** EPA-11 and Cyclone Technology, Stainless Steel Filter
- **Weight:** Approximately 1.4 Kilograms
- **Extension Tube Length:** 80 cm (aluminum telescopic)
- **Color:** Black / Purple



Image: An internal view of the CLEANmaxx vacuum cleaner highlighting its powerful 22.2 Volt battery, which provides up to 35 minutes of continuous operation.

Warranty and Support

For information regarding warranty coverage, product registration, or technical support, please refer to the warranty card included with your purchase or visit the official CLEANmaxx website. Keep your proof of purchase for warranty claims. If you encounter issues not covered in the troubleshooting section, please contact CLEANmaxx customer service for assistance.

© 2024 CLEANmaxx. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question