Complete Cuisine Deluxe Blender

Complete Cuisine 2-Speed 48-oz Deluxe Blender

Model: Deluxe Blender

1. Introduction

Thank you for purchasing the Complete Cuisine 2-Speed 48-oz Deluxe Blender. This appliance is designed for efficient blending of various ingredients, from smoothies to sauces. Please read this manual thoroughly before first use to ensure safe and optimal operation. Keep these instructions for future reference.

2. Important Safety Information

WARNING: To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before operating the blender.
- Do not immerse the motor base in water or other liquids.
- Unplug from outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts. Blades are sharp. Handle with care.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Always operate the blender with the lid in place.
- Do not blend hot liquids in the blender pitcher as pressure buildup may cause the lid to eject and result in burns.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory

or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. Parts List

Familiarize yourself with the components of your Complete Cuisine Deluxe Blender:

- **Blender Base:** Contains the motor and control dial.
- **48-oz (1.4 L) Pitcher:** Transparent blending container with measurement markings and a spout.
- **Lid:** Secures to the pitcher to prevent spills during operation.
- **Stainless Steel Blade Assembly:** Permanently installed at the bottom of the pitcher for efficient blending.



Image 3.1: Overview of the Complete Cuisine Deluxe Blender components.



Image 3.2: Detailed view of the 48-oz pitcher, showing capacity markings and ingredients.

4. Setup

1. **Unpack:** Carefully remove all parts from the packaging. Dispose of packaging materials responsibly.
2. **Clean:** Before first use, wash the pitcher and lid in warm, soapy water. Rinse thoroughly and dry. Wipe the blender base with a damp cloth.
3. **Assemble:** Place the pitcher securely onto the blender base. Ensure it is seated correctly.
4. **Position:** Place the blender on a clean, dry, and stable surface. The skid-resistant feet will help keep it in place during operation.

5. Operating Instructions

Follow these steps to operate your blender:

1. **Add Ingredients:** Place your desired ingredients into the 48-oz pitcher. Do not exceed the maximum fill line. For best results, add liquids first, then soft ingredients, followed by harder ingredients and ice.

2. **Secure Lid:** Place the lid firmly onto the pitcher. Ensure it is properly sealed to prevent splashing.
3. **Plug In:** Plug the blender into a standard electrical outlet.
4. **Select Speed:** Turn the control dial to your desired speed setting (Speed 1 or Speed 2). For short bursts of power, use the Pulse function by turning the dial to 'P' and releasing.
5. **Blend:** Allow the blender to run until your desired consistency is achieved. Do not operate continuously for more than 60 seconds to prevent overheating. If blending for longer, allow a short break between cycles.
6. **Stop:** Turn the control dial to the 'OFF' position when blending is complete.
7. **Unplug:** Unplug the blender from the outlet before removing the pitcher or pouring contents.



Image 5.1: User adjusting the control dial on the blender base.



Image 5.2: Detail of the blender's control dial for speed and pulse functions.

6. Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your blender.

1. **Unplug:** Always ensure the blender is unplugged before cleaning.
2. **Disassemble:** Remove the pitcher and lid from the motor base.
3. **Clean Pitcher and Lid:** The 48-oz pitcher and lid are dishwasher safe. Alternatively, wash them in warm, soapy water using a non-abrasive sponge. Rinse thoroughly and dry. Be cautious around the blades.
4. **Clean Motor Base:** Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid.
5. **Storage:** Store the blender in a dry place, assembled or disassembled, as preferred.



Image 6.1: The blender pitcher and lid are dishwasher safe for easy cleaning.

7. Troubleshooting

If you encounter issues with your blender, refer to the following table:

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; power outlet not working; pitcher not correctly seated.	Ensure plug is firmly in outlet; check outlet with another appliance; ensure pitcher is securely locked onto the base.
Ingredients are not blending smoothly.	Too many ingredients; not enough liquid; ingredients are too large.	Reduce quantity of ingredients; add more liquid; cut ingredients into smaller pieces; use the Pulse function.
Blender stops during operation.	Overheating protection activated.	Turn off and unplug the blender. Allow it to cool down for at least 15-20 minutes before restarting. Reduce load for next use.
Loud noise or vibration.	Pitcher not seated correctly; foreign object in pitcher; blender on an uneven surface.	Ensure pitcher is securely locked; check for foreign objects (unplug first!); place blender on a flat, stable surface.

8. Specifications

- **Model:** Deluxe Blender
- **Capacity:** 48 oz (1.4 L)
- **Speed Settings:** 2 Speeds + Pulse Control
- **Blade Material:** Durable Stainless Steel

- **Pitcher Material:** BPA-free Plastic
- **Feet:** Skid-resistant
- **Package Dimensions:** 13.5 x 7 x 6.5 inches

9. Warranty and Support

Complete Cuisine products are manufactured to high-quality standards. For warranty information, technical support, or customer service inquiries, please refer to the contact information provided on your product packaging or visit the official Complete Cuisine website.