Enchen Mini 6

Enchen Mini 6 Electric Shaver User Manual

Model: **Mini 6** | Brand: **Enchen**

Introduction

This manual provides comprehensive instructions for the safe and effective use, maintenance, and troubleshooting of your Enchen Mini 6 Electric Shaver. Please read this manual thoroughly before first use and retain it for future reference.



The Enchen Mini 6 Electric Shaver, a compact and portable grooming device.

Safety Information

Please read and understand all safety warnings before using this product.
Avoid contact with eyes and skin. Do not use while charging or near water. Always unplug and allow to cool before cleaning. Keep out of reach of children. Use with caution to avoid cuts and skin irritation.

Product Overview

Key Features:

- **Alloy Casting Body:** Durable and environmentally friendly alloy material, precision die-cast and electroplated for a premium finish.
- **Dual Precision Magnetic Head:** Designed for close and smooth shaves, ensuring no fine hair is left behind.
- **Type-C Charging:** Universal compatibility with various charging methods.
- **Long Battery Life:** 60 minutes of continuous use on a full charge (1.5 hours charging time).
- **IP6 Waterproof:** Allows for full body washing and is suitable for both wet and dry shaving.
- **Powerful Motor:** Rotates up to 28,000 revolutions per minute for rapid trimming while protecting the skin.
- **Noise-Suppression Design:** Provides a quiet and pleasant shaving experience.

Components:

The Enchen Mini 6 Electric Shaver features a compact design with dual rotary blades and a central power button. It

includes a Type-C charging port for convenient power input.



The shaver features 2-direction flex heads for a flexible shave and independent movement.



Detail of the double track curved cutter net for efficient shaving.

Setup

Initial Charge:

1. Before first use, ensure the shaver is fully charged.
2. Connect the provided Type-C charging cable to the shaver's charging port.
3. Plug the other end of the cable into a compatible USB power adapter (not included) or a USB port.
4. The charging indicator light will illuminate. A full charge takes approximately 1.5 hours.
5. Once fully charged, disconnect the shaver from the power source.



The shaver features Type-C universal charging and a powerful Li-Ion battery for up to 60 minutes of cordless shaving.

Operating Instructions

Turning On/Off:

- To turn on the shaver, press the power button located on the front of the device.
- To turn off the shaver, press the power button again.

Shaving:

- For best results, hold the shaver at a right angle to your skin.
- Move the shaver in small, circular motions or straight strokes against the direction of hair growth.
- The dual precision magnetic heads adapt to your facial contours for a close and comfortable shave.
- The shaver can be used for both dry and wet shaving, including with shaving foam or gel.



The compact design allows for convenient use anywhere, simplifying your grooming routine.

Maintenance

Cleaning the Shaver:

The Enchen Mini 6 is IP6 waterproof, allowing for easy cleaning under running water.

1. Ensure the shaver is turned off and disconnected from any charging cable before cleaning.
2. Gently remove the magnetic cutter head.
3. Rinse the cutter head and the shaver body under running water to remove hair clippings and debris.
4. For a more thorough clean, you may use a small brush (not included) to dislodge stubborn particles.
5. Allow all parts to air dry completely before reattaching the cutter head and storing the shaver.



The shaver is 100% waterproof for easy cleaning.



The magnetic cutter head is easily removable for thorough cleaning.

Blade Replacement:

The self-sharpening blades are designed for long-lasting performance. If you notice a decrease in shaving efficiency, replacement heads may be available from authorized retailers. Refer to the product packaging or manufacturer's website for specific replacement part information.

Troubleshooting

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver for at least 1.5 hours.
Poor shaving performance.	Cutter head is dirty or blades are dull.	Clean the cutter head thoroughly. Consider replacing the cutter head if performance does not improve.

Problem	Possible Cause	Solution
Shaver makes unusual noise.	Hair clippings stuck in the blades or internal issue.	Clean the shaver thoroughly. If the noise persists, contact customer support.

Specifications

Feature	Detail
Model Name	Electric shaver (Mini 6)
Power Source	Battery Powered (Li-Ion)
Special Features	Cordless, Portable, Rechargeable, Washable, Waterproof (IP6)
Recommended Uses	Beard, Face
Brand	Enchen
Run Time	Up to 60 minutes
Charging Time	Approx. 1.5 hours
Motor Speed	Up to 28,000 revolutions
Package Dimensions	4.02 x 3.82 x 1.61 inches
Item Weight	5.93 ounces



Product parameters including dimensions, run time, and charging time.

Warranty and Support

For warranty information and customer support, please refer to the product packaging or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.

Legal Disclaimer

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

© 2024 Enchen. All rights reserved.