Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tamagotchi 42991

Tamagotchi Original - Tama Smile Instruction Manual

Brand: Tamagotchi | Model: 42991

Introduction

Welcome to the world of Tamagotchi! The Tamagotchi Original - Tama Smile is a digital pet that requires your care and attention. This manual provides essential instructions to help you enjoy your virtual companion.



Image: The Tamagotchi Original - Tama Smile device, featuring a blue shell with colorful smile-themed patterns and a digital screen displaying a pixelated character.

What's in the Box

- Tamagotchi Original - Tama Smile device
- CR2032 x1 Battery (pre-installed)

Setup

Initial Activation

Your Tamagotchi device comes with a pre-installed CR2032 battery. To activate your Tamagotchi for the first time, pull the plastic tab from the battery compartment. The device will then display an egg, ready to hatch.

Setting the Time

After hatching, you will need to set the current time. Use the buttons (A, B, C) to navigate and set the correct hour and minute. Refer to the button functions in the Operating Instructions section.



Image: A close-up of the Tamagotchi device, highlighting the three control buttons (A, B, C) at the bottom of the screen.

Operating Instructions

Your Tamagotchi requires daily interaction to grow and thrive. Use the three buttons (A, B, C) to perform various actions:

- **Button A (Left):** Selects options or scrolls through menus.
- **Button B (Middle):** Confirms selection or enters a menu.
- **Button C (Right):** Cancels selection or returns to the previous screen.

Key Functions:

- **Feeding:** Provide meals and snacks to keep your Tamagotchi full and happy.
- **Lights On/Off:** Turn off the lights when your Tamagotchi is sleeping to ensure proper rest.
- **Play:** Engage in the Character game to keep your Tamagotchi entertained. Guess which way the Tamagotchi will move next to win.
- **Medicine:** Administer medicine if your Tamagotchi becomes sick.
- **Toilet:** Clean up after your Tamagotchi when it uses the bathroom.
- **Health Check:** Monitor your Tamagotchi's health, hunger, and happiness levels.
- **Discipline:** Discipline your Tamagotchi if it misbehaves, such as bothering you when it's happy, fed, and clean.

How you care for your Tamagotchi will influence its growth from egg to child to adult, determining which of the 7 adult characters it will become.

Maintenance

Cleaning

Regularly clean the exterior of your Tamagotchi device with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials that could damage the screen or casing.

Battery Replacement

The Tamagotchi uses one CR2032 battery. When the display becomes dim or the device stops responding, it's time to replace the battery. Use a small screwdriver to open the battery compartment on the back, replace the old battery with a new CR2032, and securely close the compartment.

Troubleshooting

Muting the Device

To mute your Tamagotchi, press and hold the left button (A), then press the right button (C) simultaneously. Repeat the process to unmute.

Pausing the Game

To pause your Tamagotchi and prevent it from aging, dying, or needing care, press the middle button (B) to access the time screen. Once on the time screen, press the left button (A) and then the right button (C) simultaneously. The screen will display "SET". Leave it on this screen to pause the game. To resume, press the right button (C) to exit "SET" mode, then the middle button (B) to return to the main screen.

Specifications

Model Number	42991
UPC	045557429911
Dimensions (L x W x H)	1.75"L x 2.13"W x 0.75"H
Power Source	1 x CR2032 Battery (included)
Display Type	LCD
Material Type	Acrylonitrile Butadiene Styrene, Metal, Polycarbonate, Silicone
Age Range	8+ years

Safety Information

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.
The device contains a button or coin cell battery. If swallowed, seek immediate medical attention. Always supervise young children during play.

Warranty and Support

Specific warranty information for the Tamagotchi Original - Tama Smile is not provided in the product details. For support or warranty inquiries, please refer to the manufacturer's official website or contact their customer service directly.

© 2026 Tamagotchi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DQ9S5RK9

More documents and user manuals: **https://manuals.plus/**