Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MIlse RX580 8GB

MIlse RX580 8GB Graphics Card User Manual

Model: RX580 8GB

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your MIlse RX580 8GB Graphics Card. Please read this manual thoroughly before installation and use to ensure optimal performance and longevity of your product.



Image: The Mllse RX580 8GB Graphics Card, featuring dual white fans, alongside its retail packaging.

Safety Information

Always observe the following safety precautions:

- Ensure your computer is powered off and unplugged from the wall outlet before installing or removing the graphics card.
- Discharge static electricity from your body by touching a grounded metal object (e.g., the computer case) before handling the card.
- Handle the graphics card by its edges to avoid touching sensitive components.
- Do not expose the card to moisture or extreme temperatures.
- Keep out of reach of children.

Package Contents

Verify that all items are present in your package:

- Mllse RX580 8GB Graphics Card
- User Manual (this document)
- Driver CD (may not be included, drivers are typically downloaded online)

Setup and Installation

System Requirements

- PCI Express x16 slot on motherboard
- Minimum 500W power supply with one 6-pin PCIe power connector
- Operating System: Windows 7/8/10/11 (64-bit recommended) or Linux
- 8GB system RAM recommended

Physical Installation

1. **Prepare Your System:** Power off your computer and unplug the power cord. Open the computer case.
2. **Locate PCIe Slot:** Identify an available PCI Express x16 slot on your motherboard. Remove any expansion slot covers that block the slot.
3. **Insert Graphics Card:** Carefully align the graphics card with the PCIe slot and press down firmly until it is fully seated. A click may be heard as the retention clip engages.
4. **Secure the Card:** Secure the graphics card to the computer case using the screw or latch mechanism provided by your case.
5. **Connect Power:** Connect the 6-pin PCIe power connector from your power supply to the corresponding port on the graphics card.



Image: Close-up view of the Mllse RX580 8GB Graphics Card showing the direct copper contact heatsink and the 6-pin power interface.

6. **Close Case and Connect Display:** Close your computer case. Connect your monitor(s) to the graphics card's display outputs (DVI, HDMI, or DisplayPort).



Image: The rear I/O panel of the Mllse RX580 8GB Graphics Card, illustrating the DisplayPort (DP), HDMI, and DVI-D output ports for connecting monitors.

7. **Power On:** Plug in your computer's power cord and power on the system.

Driver Installation

After physical installation, you must install the graphics drivers for optimal performance.

1. **Download Drivers:** Visit the official AMD website or the Mllse support page to download the latest Radeon RX 580 drivers for your operating system.
2. **Run Installer:** Execute the downloaded driver installer. Follow the on-screen prompts to complete the installation.
3. **Restart System:** Restart your computer after the driver installation is complete.

Operating the Graphics Card

Basic Operation

Once drivers are installed, your operating system should automatically detect and utilize the RX580 graphics card. You can verify this in your system's Device Manager (Windows) or display settings.

Multi-Display Setup

The RX580 supports multiple monitors for an expanded desktop experience. Connect up to three monitors using the available DisplayPort, HDMI, and DVI-D outputs. Configure your display settings within your operating system to extend or duplicate your desktop.



Image: An illustration of a multi-monitor setup, demonstrating the capability of the graphics card to support up to three displays simultaneously for an immersive computing experience.

Performance Considerations

The Mllse RX580 8GB Graphics Card is designed for strong performance in gaming and demanding applications, particularly at 1080p resolution. Its dual-fan cooling system helps maintain optimal temperatures during heavy loads.



Image: A bar chart illustrating the frames per second (FPS) achieved by the RX580 at 1080p maximum settings in various popular games, including PUBG, Fortnite, and Call of Duty Black Ops 4.

Maintenance

Proper maintenance ensures the longevity and performance of your graphics card.

- **Cleaning:** Periodically clean dust from the fans and heatsink using compressed air. Ensure the computer is powered off and unplugged before cleaning.
- **Airflow:** Ensure good airflow within your computer case. Keep cables tidy and ensure case fans are functioning correctly to prevent heat buildup.
- **Driver Updates:** Regularly check for and install the latest graphics drivers from AMD to benefit from performance improvements and bug fixes.




Image: The Mllse RX580 8GB Graphics Card, highlighting its dual-fan cooling system designed for efficient heat dissipation.

Troubleshooting

If you encounter issues, try the following steps:

- **No Display Output:**
  - Ensure the monitor cable is securely connected to both the graphics card and the monitor.
  - Verify the 6-pin PCIe power connector is fully seated on the graphics card.
  - Check if the monitor is set to the correct input source.
  - Try reseating the graphics card in its PCIe slot.
- **Driver Issues / Low Performance:**
  - Ensure you have installed the correct and latest drivers from AMD.
  - Uninstall any previous graphics drivers using a utility like DDU (Display Driver Uninstaller) before reinstalling.
  - Check your system's power settings to ensure it's set to "High Performance."

- **System Instability / Crashes:**
  - Ensure your power supply meets the minimum wattage requirement.
  - Monitor temperatures using third-party software to check for overheating.
  - Verify the card is securely seated and all power connections are firm.

Specifications

Key technical specifications for the Mllse RX580 8GB Graphics Card:

Feature	Detail
Graphics Coprocessor	AMD Radeon RX 580
Graphics RAM Size	8 GB GDDR5
GPU Clock Speed	1284 MHz (Boost Engine Clock)
Memory Clock	1750 MHz
Stream Processors	2048SP
Memory Bandwidth	224 GB/s
Memory Interface	256-bit
Power Interface	6-pin
Video Output Interface	DVI, HDMI, DisplayPort
Product Dimensions	8.58 x 4.8 x 0.04 inches
Item Weight	2 pounds




Image: A visual summary of the Mllse RX580 8GB Graphics Card's key specifications, including power interface, stream processors, memory clock, boost engine clock, GDDR5 memory, memory bandwidth, and memory interface.

Warranty and Support

For warranty information and technical support, please refer to the documentation included with your purchase or visit the official Mllse website. Keep your proof of purchase for warranty claims.
For further assistance, contact Mllse customer service through their official channels.

© 2025 Mllse. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DQCW6VVY

More documents and user manuals: **https://manuals.plus/**