Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Samsung VG-PRSP120S/ZA

Samsung The Premiere 120-inch Rollable Projector Screen User Manual

Model: VG-PRSP120S/ZA

1. Introduction

This manual provides essential information for the setup, operation, maintenance, and troubleshooting of your Samsung The Premiere 120-inch Rollable Projector Screen (Model VG-PRSP120S/ZA). Please read this manual thoroughly before using the product to ensure proper function and longevity.

The Samsung The Premiere Rollable Screen is designed to complement The Premiere Laser Projector (LSP9 / LSP7, sold separately), offering an immersive home theater experience. Its automatic rollable design allows the screen to deploy and retract seamlessly, preserving your wall space when not in use. The Ambient Light Rejection (ALR) screen material ensures a vivid and clear picture by minimizing interference from ambient room lighting.



Figure 1: Samsung The Premiere 120-inch Rollable Projector Screen in a living room setting, displaying a high-quality image.

2. Package Contents

Verify that all components are present in the box:

- Samsung VG-PRSP120S/ZA The Premiere 120" Rollable Screen (2022)
- Power Cable
- User Manual (this document)
- Remote Control (if applicable, not explicitly mentioned but common for automatic screens)

3. Setup

The Samsung The Premiere Rollable Screen is designed for easy setup without requiring professional installation. Follow these steps:

1. **Unpacking:** Carefully remove the screen from its packaging. Ensure the screen material is not creased or damaged during removal.
2. **Placement:** Position the screen on a flat, stable surface. The screen is designed for floor mounting. Ensure there is adequate space for the screen to fully deploy.
3. **Power Connection:** Connect the power cable to the screen unit and then to a suitable power outlet.
4. **Projector Placement:** Place your compatible Samsung The Premiere Laser Projector (LSP9 / LSP7) in front of the screen. Refer to your projector's manual for optimal throw distance and alignment.
5. **Initial Deployment:** Power on your projector. The screen is designed to automatically deploy when the projector is turned on.



Figure 2: Simplified setup process, demonstrating the placement of the projector relative to the screen.

4. Operating Instructions

The Samsung The Premiere Rollable Projector Screen operates automatically, simplifying your home theater experience.

- **Automatic Deployment:** When a compatible Samsung The Premiere Laser Projector (LSP9 / LSP7) is powered on, the screen will automatically rise from its base to the full 120-inch viewing size.
- **Automatic Retraction:** When the connected projector is powered off, the screen will automatically retract back into its base, leaving your wall space clear.
- **Manual Override (if applicable):** If your screen includes a remote control (check package contents), you may use it to manually deploy or retract the screen, or to adjust its height. Refer to the remote control's specific instructions for details.



Figure 3: The rollable screen mechanism, illustrating the automatic deployment and retraction feature.

5. Maintenance

Proper maintenance ensures the longevity and optimal performance of your projector screen.

- **Screen Surface Cleaning:**
  - Gently wipe the screen surface with a soft, lint-free cloth.
  - For stubborn marks, lightly dampen the cloth with distilled water. Do not use harsh chemicals, abrasive cleaners, or excessive moisture, as this can damage the ALR coating.
  - Avoid touching the screen surface directly with your fingers to prevent oil transfer.
- **Housing and Base Cleaning:** Wipe the exterior housing and base with a dry or slightly damp cloth to remove dust.
- **Mechanism Care:** Ensure the area around the screen's rolling mechanism is free from obstructions. Do not force the screen to retract or deploy manually if it encounters resistance.
- **Storage:** When not in use for extended periods, ensure the screen is fully retracted into its protective base.

6. Troubleshooting

If you encounter issues with your projector screen, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Screen does not deploy or retract automatically.	• No power to the screen. • Projector not turned on or not compatible. • Obstruction in the screen's path.	• Check power cable connection and outlet. • Ensure the compatible Samsung The Premiere projector is powered on. • Remove any objects blocking the screen's movement.
Image appears dim or washed out.	• Excessive ambient light. • Projector settings incorrect. • Screen surface dirty.	• Minimize ambient light in the room (e.g., close curtains). • Adjust brightness, contrast, and color settings on your projector. • Clean the screen surface as per maintenance instructions.

Problem	Possible Cause	Solution
Screen surface has wrinkles or creases.	• Improper handling during setup. • Foreign object caught in rolling mechanism.	• Ensure careful handling. • Inspect the rolling mechanism for any obstructions. If creases persist or are severe, contact customer support.

If the problem persists after attempting these solutions, please contact Samsung customer support for further assistance.

7. Specifications

Detailed technical specifications for the Samsung The Premiere 120-inch Rollable Projector Screen (Model VG-PRSP120S/ZA):

Model Number	VG-PRSP120S/ZA
Brand	Samsung
Screen Size	120 inches (diagonal)
Deployed Screen Dimensions (W x H)	114.57"W x 74.17"H
Housing Dimensions (W x D x H)	114.57"W x 4.72"D x 15.08"H
Material	Ambient Light Rejecting (ALR)
Screen Finish	ALR
Mounting Type	Floor Mount
Viewing Angle	170 Degrees
Operation Mode	Automatic
Item Weight	75 Pounds
Manufacturer	Samsung

8. Warranty Information

This Samsung The Premiere 120-inch Rollable Projector Screen (Model VG-PRSP120S/ZA) comes with a Limited 2-Year Manufacturer Protection.
For detailed terms and conditions of the warranty, please refer to the warranty card included with your product or visit the official Samsung support website.

9. Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact Samsung customer support:

- **Website:** Visit the official Samsung support website for your region.

- **Phone:** Refer to the contact information provided in your product documentation or on the Samsung website.

When contacting support, please have your product model number (VG-PRSP120S/ZA) and serial number ready.

© 2026 Samsung. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DQLRHGT5

More documents and user manuals: **https://manuals.plus/**