## SteamOne EUSN400B

# SteamOne EUSN400B Travel Garment Steamer

User Manual

## 1. Important Safety Instructions

Please read all instructions carefully before using the appliance. Keep this manual for future reference.

- Always unplug the steamer from the electrical outlet when filling with water, emptying, or when not in use.
- Do not operate the steamer with a damaged cord or plug, or if the appliance has been dropped or damaged.
- To avoid the risk of electric shock, do not immerse the steamer in water or other liquids.
- Use the appliance only for its intended purpose as described in this manual.
- Keep the steamer and its cord out of reach of children.
- Never direct steam at people or pets. Steam is hot and can cause burns.
- Always ensure the water tank is securely attached before operation.
- Use only distilled or demineralized water to prevent mineral buildup and prolong the life of the appliance.

## 2. Product Overview

### Components

- Steamer Unit with Handle
- Removable Water Tank (400 ml capacity)
- Steam Head with Stainless Steel Soleplate
- Power Cord (3 meters)
- Fabric Brush Accessory




Image: The SteamOne EUSN400B steamer shown with its fabric brush accessory, highlighting the ergonomic design and included tool.

## Key Features

- **Powerful Performance:** 2000W for rapid and efficient steam production.
- **High Steam Output:** 30 g/min of gentle 98°C steam to de-wrinkle and sanitize fabrics without burning or glazing.
- **Quick Heat-up:** Ready to use in just 40 seconds.
- **Large Water Tank:** 400ml capacity allows for up to 27 minutes of continuous steaming.
- **Versatile:** Effective on all fabric types, including delicate materials.
- **Hygienic:** Naturally eliminates 99.99% of germs, viruses, and bacteria. Helps kill mites and bed bugs, and removes up to 70% of odors.
- **Compact and Portable:** Lightweight design makes it ideal for travel.
- **Dual Power Modes:** Max and Eco settings for different fabric needs.




Image: An internal view of the SteamOne EUSN400B steamer, illustrating the advanced technology that eliminates 99% of viruses, germs, and bacteria.




Image: The compact SteamOne EUSN400B steamer is shown packed in a suitcase and alongside neatly folded clothes, emphasizing its portability for travel.

## 3. Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Fill Water Tank:** Remove the 400ml water tank from the base. Open the cap and fill with distilled or demineralized water. Do not overfill. Securely close the cap and reattach the tank to the steamer base.
3. **Attach Accessories:** If desired, attach the fabric brush accessory to the steam head.
4. **Position:** Place the steamer on a stable, flat surface.

## 4. Operating Instructions

1. **Power On:** Plug the 3-meter power cord into a suitable electrical outlet (230V). The indicator light will illuminate.
2. **Heat Up:** The steamer will begin to heat up. It will be ready for use in approximately 40 seconds.

3. **Select Steam Mode:** Choose between Max or Eco power modes depending on the fabric type and desired steam intensity.
4. **Steam Application:** Hold the garment taut with one hand. With the other hand, hold the steamer upright and gently press the steam trigger to release steam. Move the steam head slowly over the fabric, from top to bottom.
5. **Continuous Steam:** The ergonomic trigger allows for steam on demand or can be locked for continuous steam flow.
6. **After Use:** Once steaming is complete, release the steam trigger and unplug the appliance. Allow it to cool down completely before emptying the water tank and storing.




Image: A user demonstrating the SteamOne EUSN400B steamer on a striped shirt, highlighting its powerful 2000W performance and 30g/min steam output.




Image: The SteamOne EUSN400B steamer in action on a shirt, with visual cues indicating its effectiveness on diverse fabrics such as cotton, wool, polyester, denim, muslin, silk, and linen.

## 5. Maintenance

- **Cleaning the Exterior:** Wipe the exterior of the steamer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Emptying the Water Tank:** After each use, ensure the steamer is unplugged and cool. Remove the water tank and empty any remaining water. This prevents mineral buildup.
- **Descaling (if necessary):** If you notice reduced steam output or mineral residue, a descaling solution designed for steamers can be used. Follow the descaling product's instructions carefully.
- **Storage:** Store the steamer in a cool, dry place, away from direct sunlight and moisture. Ensure the water tank is empty before storage.

## 6. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| No steam or low steam output | Water tank empty; Mineral buildup; Steamer not heated sufficiently | Refill water tank; Descale the steamer; Allow 40 seconds for heat-up |
| Water leaking from steam head | Overfilled water tank; Steamer not fully heated; Mineral buildup | Do not overfill; Wait for full heat-up; Descale the steamer |
| Steamer not turning on | Not plugged in; Power outlet issue; Damaged cord/plug | Ensure plug is fully inserted; Test outlet with another appliance; Contact customer support if cord/plug is damaged |

## 7. Specifications

**Model Number:** EUSN400B

**Power:** 2000 Watts

**Voltage:** 230 Volts

**Steam Output:** 30 g/min

**Water Tank Capacity:** 400 ml

**Heat-up Time:** Approximately 40 seconds

**Cable Length:** 3 meters

**Dimensions (L x W x H):** 14 cm x 12 cm x 25 cm

**Weight:** 1.03 Kilograms

**Color:** Black

**Country of Origin:** China

**Spare Parts Availability (EU):** 7 Years




Image: The SteamOne EUSN400B steamer displayed with its key dimensions (140mm width, 245mm height), illustrating its compact size.

## 8. Warranty and Support

Your SteamOne EUSN400B Travel Garment Steamer is covered by a legal warranty of conformity for 2 years from the date of purchase, covering malfunctions and breakdowns. Additionally, spare parts are available in the EU for 7 years.

For product support, troubleshooting assistance, or warranty claims, please contact SteamOne customer service through their official website or the retailer where the product was purchased. Please have your proof of purchase and model number (EUSN400B) ready when contacting support.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**