Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

topzee AFT05018

TOPZEE 5.5 QT 12-in-1 Compact Air Fryer

Model: AFT05018

Introduction

Thank you for choosing the TOPZEE 5.5 QT 12-in-1 Compact Air Fryer. This appliance utilizes 360° hot air circulation technology to cook your favorite foods with up to 95% less oil, offering a healthier alternative to traditional deep frying. With its intuitive touch screen and 12 preset functions, preparing a variety of meals is simple and efficient. Please read this manual thoroughly before first use to ensure safe and optimal operation.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury.

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block any ventilation openings.

Product Overview

The TOPZEE Air Fryer features a sleek design with a user-friendly touch control panel and a convenient viewing window.



Image: The TOPZEE 5.5 QT Air Fryer, showcasing its compact black design, touch control panel, and a transparent viewing window that allows monitoring of the cooking process.

Components:

- Main Unit with Touch Control Panel

- Removable Frying Basket (5.5 QT Capacity)
- Crisper Plate (Non-stick)
- Power Cord



Image: The air fryer with its large 5.5-quart capacity basket pulled out, demonstrating its ability to hold a significant amount of food, such as a batch of french fries, suitable for 3-4 people.

Setup and First Use

Unpacking:

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Carefully remove the air fryer and its accessories from the box.
3. Wash the frying basket and crisper plate with hot water, dish soap, and a non-abrasive sponge.
4. Wipe the inside and outside of the appliance with a damp cloth.

Placement:

- Place the air fryer on a stable, horizontal, and heat-resistant surface.
- Ensure there is at least 4 inches (10 cm) of free space on the back and sides of the appliance, and 4 inches (10 cm) above it, to allow for proper air circulation.
- Do not place the appliance against a wall or other appliances.

Initial Operation (Burn-in):

It is recommended to run the air fryer empty for about 10-15 minutes on its highest temperature setting (400°F / 200°C) before first use. This helps to burn off any manufacturing residues and eliminate initial odors. Ensure the area is well-ventilated during this process.

Operating Instructions

Control Panel:

The TOPZEE Air Fryer features a high-definition touch screen for easy operation. The panel includes controls for power, temperature adjustment, time adjustment, preheat function, and various preset cooking modes.



Image: The TOPZEE Air Fryer highlighting its key features: energy saving capabilities, high-definition touch screen interface, durable aluminum alloy interior, and a large viewing window for monitoring food.

Basic Operation:

1. Place the crisper plate inside the frying basket.
2. Place your food on the crisper plate. Do not overfill the basket to ensure even cooking.
3. Slide the frying basket back into the air fryer until it clicks into place.
4. Plug the power cord into a grounded wall outlet. The power button will illuminate.
5. Press the power button to turn on the appliance.
6. **Manual Mode:** Use the temperature and time adjustment buttons to set your desired cooking temperature (100-400°F / 40-200°C) and time.
7. **Preset Modes:** Select one of the 12 preset icons for common dishes. The air fryer will automatically set the optimal temperature and time for that food.
8. Press the start/pause button to begin cooking.
9. During cooking, you can pull out the basket to shake or flip food. The air fryer will pause automatically and resume when the

basket is reinserted.

10. Once cooking is complete, the air fryer will beep. Carefully pull out the basket and remove the food.

Preheat Function:

The preheat function helps to achieve optimal cooking results by bringing the air fryer to the desired temperature before adding food. This is especially useful for items that benefit from immediate high heat, such as frozen foods, ensuring a crispy exterior and juicy interior.



Image: The air fryer with cooked chicken drumsticks, illustrating the preheat function which helps lock in moisture and tenderness, making it ideal for cooking items from frozen quickly.

12-in-1 Preset Functions:

The air fryer comes with 12 pre-programmed settings for various dishes, simplifying your cooking process.



Image: The TOPZEE Air Fryer displayed with a variety of meals, including steak, french fries, vegetables, chicken drumsticks, dried fruit, salmon, seafood, rib roast, and sausage, demonstrating the versatility of its 12 preset cooking functions.

- French Fries
- Veggies
- Steak
- Drumstick
- Dried Fruit (Dehydrate)
- Salmon
- Seafood
- Rib Roast
- Sausage
- Bake
- Reheat

- Broil

For specific cooking times and temperatures for various foods, refer to the included recipe book or common air frying guides.

Maintenance and Cleaning

Regular cleaning of your air fryer will ensure optimal performance and extend its lifespan.



Image: The removable frying basket of the TOPZEE Air Fryer being placed into a dishwasher, illustrating its dishwasher-safe design and non-stick coating for easy cleaning.

Cleaning Steps:

1. Always unplug the air fryer and allow it to cool completely before cleaning.
2. Remove the frying basket and crisper plate.
3. The frying basket and crisper plate are dishwasher safe. Alternatively, they can be washed by hand with hot water, dish soap, and a non-abrasive sponge.

4. For stubborn food residue, soak the basket and plate in warm, soapy water for about 10-15 minutes.
5. Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or scouring pads, as they may damage the surface.
6. Clean the interior of the appliance with a damp cloth and mild detergent.
7. Ensure all parts are thoroughly dry before reassembling and storing the air fryer.

Storage:

Store the air fryer in a cool, dry place. Its compact design makes it easy to store on countertops or in cabinets.

Troubleshooting

If you encounter issues with your TOPZEE Air Fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in; power outlet malfunction; basket not properly inserted.	Ensure the power cord is securely plugged into a working outlet. Check if the frying basket is fully inserted until it clicks.
Food is not cooked evenly.	Basket is overfilled; food not shaken/flipped; incorrect temperature/time.	Do not overfill the basket. Shake or flip food halfway through cooking. Adjust temperature and time as needed.
White smoke coming from the appliance.	Grease residue from previous use; high-fat food cooking.	Clean the basket and crisper plate thoroughly after each use. For high-fat foods, drain excess oil from the basket.
Food is not crispy.	Too much moisture in food; not enough oil (for certain foods); basket overfilled.	Pat food dry before air frying. Lightly coat some foods with oil. Do not overfill the basket. Consider using the preheat function.

Specifications

Feature	Detail
Model Name	AFT05018
Capacity	5.5 Quarts
Product Dimensions	13.7"D x 13.7"W x 13.7"H
Item Weight	10.5 Pounds
Color	Black
Material	Non-Stick (coating)
Output Wattage	1500 Watts
Temperature Range	100-400°F (40-200°C)

Feature	Detail
Control Method	Touch
Air Frying Technology	360° Hot Air Circulation
Special Features	Programmable Temperature Control, Automatic Shut-Off, Non-Stick, Air fryer with window, Preheat Function, 12-in-1 Presets
Dishwasher Safe Parts	Yes (Removable basket and crisper plate)
UPC	860013281144

Warranty and Support

Specific warranty details for the TOPZEE 5.5 QT 12-in-1 Compact Air Fryer are not provided in the available product information. For warranty claims, technical support, or replacement parts, please contact the manufacturer directly through their official website or the retailer from whom the product was purchased.
No official product videos from the seller were found in the provided data to be embedded in this manual.

© 2025 TOPZEE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DQWNW3TK

More documents and user manuals: **https://manuals.plus/**