Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

UNINELL HOME UV5

UNINELL HOME UV5 Cordless Vacuum Cleaner Replacement Battery and Power Adapter User Manual

Model: UV5

Introduction Safety Instructions Components Installation Charging Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

This manual provides essential information for the safe and efficient use of your UNINELL HOME UV5 Cordless Vacuum Cleaner Replacement Battery and Power Adapter. Please read it thoroughly before use and retain it for future reference.

2. Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury, especially concerning batteries and power adapters.

- Read all instructions before using the appliance.
- Use only as described in this manual. Use only manufacturer’s recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Turn off all controls before unplugging.
- Use only the charger specified by the manufacturer to recharge. A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.
- Prevent unintentional starting. Ensure the switch is in the OFF-position before connecting to battery pack, picking up or carrying the appliance. Carrying the appliance with your finger on the switch or energizing appliance that have the switch ON invites accidents.
- Disconnect the battery pack from the appliance before making any adjustments, changing accessories, or storing appliance. Such preventive safety measures reduce the risk of starting the appliance accidentally.
- Recharge only with the charger specified by the manufacturer. A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.

- Use appliances only with specifically designated battery packs. Use of any other battery packs may create a risk of injury and fire.
- When battery pack is not in use, keep it away from other metal objects, like paper clips, coins, keys, nails, screws or other small metal objects, that can make a connection from one terminal to another. Shorting the battery terminals together may cause burns or a fire.
- Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help. Liquid ejected from the battery may cause irritation or burns.
- Do not use a battery pack or appliance that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- Do not expose a battery pack or appliance to fire or excessive temperature. Exposure to fire or temperature above 130°C (265°F) may cause explosion.
- Follow all charging instructions and do not charge the battery pack or appliance outside of the temperature range specified in the instructions. Charging improperly or at temperatures outside of the specified range may damage the battery and increase the risk of fire.
- Have servicing performed by a qualified repair person using only identical replacement parts. This will ensure that the safety of the product is maintained.
- Do not modify or attempt to repair the appliance or the battery pack (as applicable) except as indicated in the instructions for use and care.

3. Product Components

Your UNINELL HOME UV5 package includes the following:

- Replacement Battery ×1
- Replacement Power Adapter ×1



Image: UNINELL HOME UV5 Replacement Battery and Power Adapter.

4. Installation

4.1. Installing the Replacement Battery

To install the replacement battery into your UNINELL HOME UV5 Cordless Vacuum Cleaner:

1. Ensure the vacuum cleaner is powered off and unplugged from any charging source.
2. Locate the battery compartment on the vacuum cleaner (refer to your vacuum cleaner's main user manual for exact location).
3. If an old battery is present, press the release button (if applicable) and slide it out.
4. Align the new replacement battery with the compartment and slide it in until it clicks securely into place.
5. Gently tug on the battery to ensure it is firmly seated and will not dislodge during use.

5. Charging Instructions

5.1. Using the Replacement Power Adapter

To charge your UNINELL HOME UV5 replacement battery using the provided power adapter:

1. Ensure the replacement battery is securely installed in the vacuum cleaner or detached for separate charging (if your vacuum model supports this).
2. Connect the small end of the replacement power adapter to the charging port on the battery or the vacuum's charging base.
3. Plug the larger end of the power adapter into a standard 100-240V AC electrical outlet.
4. The battery indicator light on the vacuum's display will show the charging status. A full charge typically takes approximately 4 hours.
5. Once fully charged, disconnect the power adapter from the outlet and the vacuum/battery.

6. Maintenance

6.1. Battery Care

Proper care extends battery life:

- Avoid fully discharging the battery before recharging.
- Store the battery in a cool, dry place when not in use.
- Do not expose the battery to extreme temperatures.
- If storing for an extended period, charge the battery to about 50% capacity.

6.2. Power Adapter Care

To ensure longevity of your power adapter:

- Inspect the cord and plug regularly for any signs of damage.
- Do not use if the cord is frayed or the plug is bent.
- Keep the adapter away from water and moisture.

7. Troubleshooting

If you encounter issues with your replacement battery or power adapter:

- **Battery Not Charging:** Ensure the power adapter is securely plugged into both the battery/vacuum and the wall outlet. Check if the outlet is functional. Verify the battery is correctly installed in the vacuum.
- **Vacuum Not Powering On with New Battery:** Ensure the battery is fully charged and correctly installed. Check the vacuum's main user manual for specific power-on instructions.
- **Power Adapter Overheating:** Discontinue use immediately. Unplug the adapter and contact customer support.

For persistent issues, contact customer support.

8. Specifications

Feature	Detail
Brand	UNINELL HOME

Model Name	UV5
Special Feature	Replacement Battery and Replacement Power Adapter
Included Components	Replacement Battery ×1, Replacement Power Adapter ×1
Power Source	Battery Powered
Product Dimensions	6.29"L x 3.62"W x 2.16"H
Item Weight	3.52 ounces

9. Warranty and Support

UNINELL HOME offers a 2-Year After-sales Service for your product. For any inquiries or support, please contact our customer service team. We provide 24/7 mail support and a 30-day free return policy.



Image: Visual representation of UNINELL HOME's customer support and warranty details.

© 2026 UNINELL HOME. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DQWRDGC1

More documents and user manuals: **https://manuals.plus/**