ChooChoo B0DR2KVQYH

ChooChoo Mission Coffee Table User Manual

Model: B0DR2KVQYH

Important Safety Information

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Keep assembly tools and small parts out of reach of children and pets.
- Ensure all screws and fasteners are securely tightened before use.
- Do not overload the table or shelves.
- Place the table on a flat, stable surface.
- Avoid exposing the table to excessive moisture or direct sunlight for prolonged periods.

Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer service.

- Table Top
- Side Panels (Slatted)
- Bottom Shelf
- Legs
- Hardware (Screws, Dowels, etc.)
- Assembly Tools (if included)
- Assembly Guide

Assembly Instructions

Tools required: Phillips head screwdriver (not included, but recommended).

1. **Step 1: Identify Components.** Unpack all parts and hardware. Refer to the included parts list to ensure all pieces are present and undamaged. Separate hardware by type.



Image: Top view of the coffee table, showing its overall structure and the main components that will be assembled.

2. **Step 2: Attach Side Panels to Table Top.** Carefully align the pre-drilled holes on the side panels with the corresponding holes on the underside of the table top. Secure using the provided screws. Do not overtighten.



Image: Close-up view of the coffee table's slatted side panel connecting to the underside of the table top, illustrating the assembly point.

3. **Step 3: Install Bottom Shelf.** Slide the bottom shelf into the grooves or align with the pre-drilled holes on the lower section of the side panels. Secure with screws, ensuring it is level and stable.



Image: Detailed view of the bottom shelf of the coffee table, showing its integration with the side panels and the wood grain finish.

4. **Step 4: Final Tightening and Inspection.** Once all components are assembled, gently tighten all screws to ensure maximum stability. Do not overtighten. Verify that the table is stable and level before placing items on it.



Image: The fully assembled ChooChoo Mission Coffee Table placed in a living room, showcasing its design and functionality.

Operating Instructions

The ChooChoo Mission Coffee Table is designed for indoor use as a functional and decorative piece of furniture.

- Use the top surface for placing beverages, books, or decorative items.
- The lower shelf provides additional storage space for magazines, baskets, or other living room essentials.
- Avoid placing hot items directly on the surface; use coasters or protective pads.
- Do not stand or sit on the table.



Image: The coffee table displaying various items on its top surface and lower shelf, demonstrating its practical use in a living room setting.

Maintenance and Care

Proper care will extend the life and appearance of your coffee table.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Blot spills immediately with a clean, dry cloth to prevent staining.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or warping.
- **Humidity:** Maintain a stable humidity level in the room to prevent wood from cracking or swelling.
- **Tightening:** Periodically check and retighten all screws and fasteners to ensure stability.



Image: A close-up view of the coffee table's black wood grain surface, highlighting its texture and finish, which requires gentle cleaning.

Troubleshooting

Problem	Possible Cause	Solution
Table is wobbly.	Screws are loose; uneven floor.	Tighten all assembly screws. Move table to a level surface or use shims under legs.
Parts do not fit.	Incorrect orientation; wrong parts used.	Review assembly instructions and diagrams carefully. Ensure correct parts are used for each step.
Surface scratches or marks.	Sharp objects; abrasive cleaning.	Use coasters and placemats. Clean with soft cloth only. Minor scratches may be touched up with furniture repair markers.

Specifications

Brand: ChooChoo

Model: B0DR2KVQYH

Material: Wood

Color: Black

Table Design: Coffee Table (Mission Style)

Length: 36 Inches

Usage: Indoor

Assembly Required: Yes

Tools Recommended: Screw Driver

Warranty and Support

ChooChoo provides customer service before and after your purchase. For any questions regarding this coffee table, please contact ChooChoo customer support.

- **Customer Service:** Refer to your purchase documentation or the ChooChoo brand store for contact information.
- **Warranty:** Specific warranty details may vary. Please retain your proof of purchase for any warranty claims.

Note: Product specifications are subject to change without notice.

© 2025 ChooChoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question