XINFUTE RM-AAU029

Instruction Manual for XINFUTE RM-AAU029 Remote Control

Model: RM-AAU029 | Brand: XINFUTE

1. Product Overview

This manual provides detailed instructions for the XINFUTE RM-AAU029 replacement remote control. This remote is designed to function as a direct replacement for original remote controls used with specific Sony Home Audio/AV systems, including models HT-CT100, SS-MCT100, and SA-WCT100.

It is constructed from durable ABS material and features an ergonomic design for comfortable handling. The remote control operates on 2 AA batteries (not included).



Figure 1: Angled view of the RM-AAU029 remote control, showcasing its ergonomic design.

2. Setup and Battery Installation

Before using your new remote control, you must install the batteries. This remote requires two (2) AA batteries.

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two AA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings

inside the compartment. Incorrect battery orientation can prevent the remote from functioning.

4. Slide the battery cover back into place until it clicks securely.



Figure 2: Rear view of the remote control with the battery cover open, illustrating the correct placement for two AA batteries.

3. Operating Instructions

The RM-AAU029 remote control is designed to provide full functionality for compatible Sony Home Audio/AV systems. Ensure there is a clear line of sight between the remote control and the infrared receiver on your audio/AV unit.



Figure 3: Front view of the RM-AAU029 remote control, displaying all control buttons and their labels.

Key Functions:

- **Power Button (I/O):** Turns the audio/AV system on or off.
- **Input Selectors (TV, TVI/O, BD, DVD, SAT):** Switches between different input sources connected to your system.
- **Volume Control (MASTER VOL +/-):** Adjusts the master volume level.
- **Muting:** Mutes or unmutes the audio output.
- **Navigation Pad (Arrows and ENTER):** Used to navigate menus and confirm selections.
- **MENU/HOME:** Accesses the main menu or home screen of the connected device.
- **RETURN/EXIT:** Returns to the previous screen or exits a menu.

- **Playback Controls (Play, Pause, Stop, Fast Forward, Rewind, Skip):** Controls media playback for compatible devices.
- **Number Buttons (0-9):** For direct input of channel numbers or other numerical selections.
- **DISPLAY:** Shows on-screen information.
- **TOOLS/OPTIONS:** Accesses additional tools or options.

For specific functions related to your Sony HT-CT100, SS-MCT100, or SA-WCT100 system, refer to the original user manual of your audio/AV unit in conjunction with this remote control.

4. Maintenance and Care

To ensure the longevity and optimal performance of your remote control, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the remote control regularly with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as they can damage the surface.
- **Battery Replacement:** Replace batteries when the remote's responsiveness decreases or it stops functioning. Always replace both batteries at the same time with new ones of the same type (AA). Do not mix old and new batteries, or different types of batteries.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** Protect the remote from physical impact. Dropping it can damage internal components or the casing.

5. Troubleshooting

If you experience issues with your RM-AAU029 remote control, try the following troubleshooting steps:

1. **Remote Not Responding:**
    - Check the batteries. Ensure they are inserted correctly with the correct polarity (+/-).
    - Replace old batteries with new ones. Weak batteries are a common cause of remote control issues.
2. **Intermittent Functionality:**
    - Ensure there are no obstructions between the remote control and the audio/AV system's infrared receiver.
    - Make sure you are within the effective operating range of the remote control.
3. **Specific Buttons Not Working:**
    - Clean the remote control, especially around the unresponsive buttons, to remove any dirt or debris that might be preventing proper contact.
    - If only certain buttons are unresponsive after battery replacement and cleaning, the remote may be damaged.

If the problem persists after attempting these steps, please refer to the Warranty and Support section for further assistance.

6. Specifications

Feature	Detail
Model Number	RM-AAU029

Brand	XINFUTE
Compatible Devices	Sony Home Audio/AV Systems (HT-CT100, SS-MCT100, SA-WCT100)
Material	ABS Material
Color	Black (As Shown)
Power Source	2 x AA Batteries (not included)
Product Dimensions	6 x 3 x 1 inches (approximate)
Item Weight	2.82 ounces (approximate)
Special Feature	Ergonomic Design
Max Number of Supported Devices	1

7. Warranty and Support

Warranty Information:

XINFUTE offers a one-year warranty on all purchases of the RM-AAU029 remote control. This warranty covers manufacturing defects and ensures that the product will function as intended under normal use.

Customer Support:

All products are inspected before shipment to ensure quality. If you are not satisfied with your purchase or encounter any issues, please contact the seller, Xinfute, within 24 hours of receiving your product for assistance. Provide your order details and a description of the issue to facilitate a quick resolution.

For further inquiries or technical support, please refer to the contact information provided by your retailer or on the XINFUTE official store page.

© 2024 XINFUTE. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question