Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Mini Brands 77731

Mini Brands Fill The Fridge Mini Minis Series 1 Instruction Manual

Brand: Mini Brands by ZURU | Model: 77731

Product Overview

The Mini Brands Fill the Fridge Mini Minis are designed to complement your Mini Brands Fill the Fridge Playset, allowing you to create a detailed miniature kitchen setup. This series features over 80 unique miniature collectibles, ranging from popular snacks to essential kitchen items, all in a compact and highly detailed form. Each capsule contains a surprise mini, adding an element of discovery to your collection.

Key Features

- Designed for seamless integration with the Mini Brands Fill the Fridge Playset.
- Collection includes over 80 distinct miniature food and kitchen items.
- Each capsule contains one surprise mini collectible.
- Features rare "Creatable Minis" for custom miniature creations.
- Capsules are manufactured using certified recycled plastic.

What's in the Box

- 2 x Mini Brands Fill The Fridge Mini Minis Series 1 Capsules (each containing surprise minis)

Safety Information

WARNING: Choking hazard - Small pieces. Not for children under 3 years.

Setup

Unboxing Your Mini Fridge

Carefully remove the Mini Brands Fill The Fridge Playset from its packaging. Ensure all components, including the mini fridge unit and any included accessories, are present. The packaging itself may feature a kitchen backdrop, which can be used as part of your display.



Image: The Mini Brands Fill The Fridge Playset, showing the miniature fridge, capsules, and some of the collectible mini items.

Arranging Your Fridge

The mini fridge features multiple compartments and shelves for organizing your miniature collection. Adjust the shelves as desired to accommodate different sizes of minis. The fridge door also has shelves for smaller items. The exterior of the fridge is magnetic, allowing for decorative magnets (if included or collected separately) to be placed on its surface.



Image: A fully stocked Mini Brands Fill The Fridge Playset, showcasing the various miniature food and drink items arranged inside and around the fridge.

Operating Your Mini Fridge

Collecting Mini Minis

Each Mini Brands Fill The Fridge Mini Minis capsule contains several surprise miniature items. To unbox, carefully separate the two halves of the capsule. Inside, you will find individually wrapped minis. Unwrap each mini to reveal your new collectible. There are over 80 unique minis to collect in Series 1.



Image: An open Mini Brands capsule, showing several miniature food items such as broccoli florets, fresh fish, pretzel dogs, and ice cream.

Displaying Your Collection

Once unboxed, place your miniature items inside the Mini Brands fridge. Utilize the various shelves and compartments to arrange your collection. Some minis, like the "Creatable Minis," may require simple assembly or UV light curing (if applicable, refer to specific mini instructions). The magnetic exterior allows for additional decorative elements.



Image: A wide assortment of Mini Brands miniature items, including various food, drink, and household product replicas, laid out for display.

Maintenance

Cleaning Your Mini Fridge and Minis

To clean the mini fridge and miniature items, gently wipe them with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed immediately by drying. Avoid using harsh chemicals or abrasive cleaners, as these may damage the product's finish or details. Ensure all parts are completely dry before reassembling or storing.

Troubleshooting

Common Inquiries

- **Minis not fitting in fridge:** Ensure shelves are correctly positioned. Some larger minis may be intended for display outside the fridge.
- **Missing parts:** Verify contents against the "What's in the Box" section. Contact customer support if items are

genuinely missing.

- **"Creatable Minis" not curing:** If your set includes "Creatable Minis" that require UV light, ensure you are using the correct UV light source and exposing the mini for the recommended duration as per its specific instructions.

Specifications

Product Dimensions	4.06 x 4.06 x 7.87 inches
Item Weight	6.5 ounces
Model Number	77731
Manufacturer Recommended Age	8 years and up
Manufacturer	ZURU

Warranty and Support

For information regarding product warranty or customer support, please refer to the contact details provided on the product packaging or visit the official ZURU website. Keep your purchase receipt as proof of purchase.

© 2025 Mini Brands by ZURU. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

What should I do if my Mini Brands Fill The Fridge Mini Minis (Model 77731) set is missing parts, such as stickers and packaging?

If your Mini Brands Fill The Fridge Mini Minis (Model 77731) set is missing parts like stickers or specific packaging components, please follow these steps: Verify Contents: Check the "What's in the Box" section...

Read full answer

Open the live page

https://manuals.plus/asin/B0DR3SZ2QP

More documents and user manuals: **https://manuals.plus/**