Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

topzee AFT05018

topzee 5.5-Qt Air Fryer User Manual

Model: AFT05018

Introduction

This user manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your topzee 5.5-Qt Air Fryer. Please read this manual thoroughly before first use and retain it for future reference.

Important Safety Instructions

WARNING: To avoid electric shock, fire, or injury, always follow basic safety precautions when using electrical appliances.

- Do not immerse the main unit, cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use attachments not recommended by the appliance manufacturer, as this may cause injuries.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use the appliance for other than intended use.
- This appliance is for household use only.

Product Overview

The topzee 5.5-Qt Air Fryer is designed for healthy cooking with 360° hot air circulation, reducing oil usage by up to 95%. It features a precise temperature control range of 100-400°F and 12 preset functions for versatile cooking.



Figure 1: Front view of the topzee 5.5-Qt Air Fryer in Dark Grey, showing the control panel and viewing window.

Components:

- Main Unit with Control Panel
- Removable Frying Basket (5.5-Qt capacity)
- Non-stick Crisper Plate
- Power Cord
- Viewing Window

Setup

1. **Unpacking:** Carefully remove all packaging materials and promotional labels from the air fryer.
2. **Initial Cleaning:** Before first use, wash the removable frying basket and crisper plate with hot soapy water. Rinse thoroughly and dry completely. Wipe the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the air fryer on a stable, heat-resistant, and level surface. Ensure there is at least 6 inches of clear space around the back and sides of the unit to allow for proper air circulation. Do not place it directly against a wall or under cabinets.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

Operating Instructions

Preheating:

Preheating is recommended for most recipes to ensure even cooking and crispiness. To preheat:

1. Place the empty frying basket with the crisper plate inside the air fryer.
2. Turn on the air fryer.
3. Set the desired temperature (e.g., 375°F) and time (e.g., 3-5 minutes).
4. Press the start button. The air fryer will indicate when preheating is complete.



Figure 2: Illustration of the preheating function, showing the air fryer ready to cook.

Cooking with Presets:

The topzee Air Fryer features 12 preset functions for common dishes. These presets automatically set optimal temperature and time, which can be adjusted manually if needed.



Figure 3: The air fryer with a variety of dishes, demonstrating the versatility of its 12 preset functions.

1. Place food in the frying basket. Do not overfill. For best results, ensure food is in a single layer or shaken halfway through cooking.
2. Insert the basket into the air fryer.
3. Select the desired preset function from the control panel.
4. Press the start button. The air fryer will begin cooking.
5. Monitor cooking progress through the viewing window.
6. Some recipes may require shaking or flipping food halfway through. The air fryer may beep to remind you.
7. Once cooking is complete, carefully remove the basket using the handle.



Figure 4: The 5.5-quart capacity basket filled with french fries, suitable for 3-4 people.



Figure 5: Internal view of the air fryer demonstrating the 360° hot air circulation for even cooking.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
2. **Removable Parts:** The frying basket and crisper plate are non-stick and dishwasher safe. For manual cleaning, wash them with hot soapy water and a non-abrasive sponge. Rinse thoroughly and dry completely.
3. **Main Unit:** Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or scouring pads. Never immerse the main unit in water or any other liquid.
4. **Interior:** For the interior, wipe with a damp cloth. For stubborn food residue, a small amount of mild dish soap can be used. Ensure the interior is dry before next use.



Figure 6: The removable frying basket is shown being placed into a dishwasher, highlighting its dishwasher-safe feature.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet malfunction; unit not properly assembled.	Ensure plug is securely in a working outlet. Check if the basket is fully inserted.
Food is not cooked evenly.	Basket is overfilled; food not shaken/flipped.	Do not overfill the basket. Shake or flip food halfway through cooking.

Problem	Possible Cause	Solution
Food is not crispy.	Not enough oil (for certain foods); temperature too low; cooking time too short.	Lightly coat food with oil. Increase temperature or cooking time. Ensure preheating.
White smoke coming from the appliance.	Grease residue from previous use; high-fat food cooking.	Clean the basket and crisper plate thoroughly. For high-fat foods, drain excess fat during cooking.

Specifications

Feature	Detail
Model Name	AFT05018
Brand	topzee
Capacity	5.5 Quarts
Product Dimensions	11.4"D x 10.3"W x 14.1"H
Color	Dark Grey
Material	Non-Stick
Wattage	1500 Watts
Temperature Range	100-400°F
Special Features	Programmable Temperature Control, Automatic Shut-Off, 360° Hot Air Circulation, Non-Stick, Air fryer with window, Includes Manual & Recipe Book
Item Weight	10.45 Pounds
UPC	860013281151

Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official topzee website. You may also contact customer service via the contact information provided in your purchase documentation.

For additional resources and recipes, visit the topzee Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DR7RT54P

More documents and user manuals: **https://manuals.plus/**